Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dreamworks Dragons 6072541

Dreamworks Dragons Ultimate Plasma Blast Toothless Action Figure Instruction Manual

Model: 6072541

Introduction

This manual provides essential information for the safe and proper use of your Dreamworks Dragons Ultimate Plasma Blast Toothless action figure. Please read all instructions carefully before assembly and operation.



Image: The Ultimate Plasma Blast Toothless action figure displayed with its packaging, showcasing its design and features.

What's Included

Verify that all components are present:

- 1 x Ultimate Plasma Blast Toothless Dragon Figure
- 3 x AAA Batteries (pre-installed or included separately)



Image: The Toothless action figure shown within its retail packaging, indicating the product as it appears when purchased.

Setup

1. Battery Installation/Replacement

The Toothless figure requires 3 AAA batteries. These are typically included and pre-installed. If replacement is needed:

1. Locate the battery compartment on the underside of the figure.
2. Using a small Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 3 new AAA batteries, ensuring correct polarity (+/-).
4. Replace the cover and secure it with the screw.

Warning:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

- Remove batteries if the toy is not used for an extended period.

2. Wing Assembly

The wings are designed to be attached to the main body of the Toothless figure. Ensure they are securely clicked into place for proper function.



Image: An overhead view of the Toothless figure, highlighting its impressive 25-inch wingspan when fully extended.

Operating Instructions

1. Activating Lights and Sounds

The Toothless figure features interactive lights and sounds:

1. Locate the activation button on Toothless's back.
2. Press the button once to "charge" the plasma blast.
3. Press the button a second time to activate the blue plasma light in his mouth and trigger chomping sounds.



Image: A hand pressing the activation button on the back of the Toothless figure, demonstrating how to initiate the plasma blast feature.



Image: A detailed close-up of Toothless's open mouth, showing the illuminated blue plasma light effect.



Image: A child playing with the Toothless figure, illustrating the sound and light effects and emphasizing the 25-inch wingspan.

Maintenance

- **Cleaning:** Wipe the figure with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
No lights or sounds	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Wings or tail detach easily	Components not fully secured during assembly.	Ensure wings and tail are firmly clicked into their respective slots. Apply gentle pressure until a click is heard/felt.
Intermittent function	Loose battery connection or low battery power.	Check battery compartment for secure fit. Replace batteries if necessary.

Specifications

- **Model Number:** 6072541
- **Product Dimensions:** 15.17 x 11.8 x 9.44 inches
- **Item Weight:** 1.82 pounds
- **Recommended Age:** 4 - 14 years
- **Batteries:** 3 x AAA (included)

- **Manufacturer:** Spin Master

Safety Information

- **Choking Hazard:** Small parts may be generated. Not for children under 3 years.
- **Battery Safety:** Follow battery installation instructions carefully. Keep batteries away from small children. If swallowed, seek immediate medical attention.
- **Supervision:** Adult supervision is recommended during play.
- **Intended Use:** This product is an action figure toy and is not intended for real flight or other uses.

Warranty and Support

This product is covered by the Spin Master Care Commitment. For detailed warranty information or support, please refer to the official Spin Master website or contact their customer service directly.
For additional product information or to explore other Dreamworks Dragons toys, visit theDreamworks Dragons Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I change the wing position on the Dreamworks Dragons Ultimate Plasma Blast Toothless (Model 6072541)?

To change the position of the wings on the Dreamworks Dragons Ultimate Plasma Blast Toothless (Model 6072541), follow these steps: Transformation: This figure is designed to transform from a "dive" position to a "glide"...

Read full answer

Open the live page

https://manuals.plus/asin/B0DBLS81FR

More documents and user manuals: **https://manuals.plus/**