Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FOTOSOK FTSMD128US

FOTOSOK Kids Bookshelf with Reading Nook and Toy Storage Organizer

Model: FTSMD128US

1. Important Safety Information

Please read and understand all instructions before assembly and use. Retain this manual for future reference.

- It is recommended to read and follow the assembly and use instructions provided with the product.
- Keep out of reach of children during assembly to prevent access to small parts.
- Do not overload the shelf compartments or drawers. Distribute weight evenly.
- Keep the bookshelf away from sources of heat and excessive moisture to prevent damage to the engineered wood.
- Ensure all connections are securely fastened after assembly and periodically check for tightness.
- Utilize the anti-tipping design features for enhanced stability, especially in households with children.

2. Product Overview

The FOTOSOK Kids Bookshelf with Reading Nook is designed to provide a versatile storage and reading solution for children's rooms. It combines a bookshelf, a comfortable reading nook, and movable toy storage drawers.

Key Features:

- Integrated bookshelf for organizing books.
- Comfortable reading nook with a seat cushion.
- Three movable drawers with hidden wheels for toy storage.
- Additional storage cubbies for various items.
- Sturdy and stable design made from high-quality MDF board.

- Rounded corners for enhanced safety.

Components and Dimensions:

Familiarize yourself with the main components and overall dimensions of the unit.



Image 2.1: Product dimensions and component breakdown. The overall unit measures approximately 55.1 inches (140 cm) in length, 31.5 inches (80 cm) in height, and 15.6 inches (39.5 cm) in depth. Each movable drawer is approximately 17.4 inches (44.2 cm) wide, 14.6 inches (37 cm) deep, and 10.6 inches (26.8 cm) high.



Image 2.2: Overview of the 4-in-1 storage solution, highlighting the bookshelf, reading nook, movable drawers, and storage cubbies.

3. Setup and Assembly

This product requires assembly. A detailed instruction manual with labeled parts is included in the packaging to guide you through the process.

Before You Begin:

- Unpack all components and verify against the parts list in the included manual.
- Ensure you have the necessary tools (typically a screwdriver).
- Assemble on a soft, clean surface to prevent scratching the product.

- It is recommended to have two adults for assembly.

Assembly Steps:

1. Follow the step-by-step instructions provided in the separate assembly manual. Each part is labeled for easy identification.
2. Carefully connect the panels using the provided hardware. Do not overtighten screws.
3. Assemble the three movable drawers, attaching the hidden wheels to the bottom of each drawer.
4. Place the seat cushion into the designated reading nook area.
5. Once assembled, ensure the unit is stable and all connections are secure.
6. Attach any anti-tipping hardware to a wall stud as per the instructions to prevent accidental tipping.

4. Operating Instructions

This section provides guidance on how to effectively use the FOTOSOK Kids Bookshelf with Reading Nook.

Using the Bookshelf:

- Place books on the tiered shelves. The design allows for easy display and access for children.
- Organize books by size or category to encourage reading.

Using the Reading Nook:

- The central section with the seat cushion serves as a comfortable reading area.
- Ensure the cushion is properly seated before use.
- Supervise young children while they are using the reading nook.



Image 4.1: A child enjoying the integrated reading nook.

Using the Movable Drawers:

- The three drawers are equipped with hidden wheels, allowing them to be easily pulled out and moved.
- Use these drawers for storing toys, puzzles, art supplies, or other items.
- The mobility of the drawers allows children to transport toys to different play areas.
- On carpeted surfaces, the drawers may not roll as smoothly as on hard floors.



Image 4.2: Movable drawers providing convenient toy storage.

5. Maintenance

Proper care will ensure the longevity of your FOTOSOK Kids Bookshelf.

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills with a dry or slightly damp cloth to prevent water damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Cushion Care:** The seat cushion can be spot cleaned with a mild detergent and water. Allow to air dry completely.

6. Troubleshooting

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Unit feels unstable or wobbly.	Loose fasteners; uneven floor; anti-tipping hardware not installed.	Check and tighten all screws. Move the unit to a level surface. Install the anti-tipping hardware as per the assembly manual.
Drawers do not roll smoothly.	Obstruction under wheels; carpeted surface; wheels need cleaning.	Check for debris under the wheels. Note that rolling performance may be reduced on thick carpets. Clean wheels if necessary.
Missing parts during assembly.	Packaging not fully checked.	Carefully re-check all packaging materials. If parts are still missing, contact FOTOSOK customer support.

7. Product Specifications

Specification	Detail
Brand	FOTOSOK
Model Number	FTSMD128US
Color	White
Material	Engineered Wood
Item Weight	36.5 kg (approximately 80.4 lbs)
Dimensions (L x W x H)	55.1" x 15.6" x 31.5" (140 cm x 39.5 cm x 80 cm)
Mounting Type	Floor Mount
Room Type	Living Room, Playroom, Bedroom, Nursery
Care Instructions	Wipe with Dry Cloth

8. Warranty and Support

For warranty information, missing parts, or any product-related inquiries, please refer to the contact information provided in your product packaging or reach out to FOTOSOK customer support directly through the retailer where the product was purchased.

Please have your model number (FTSMD128US) and purchase date available when contacting support.

© 2025 FOTOSOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I find the instruction manual for the FOTOSOK FTSMD128US Kids Bookshelf with Reading Nook?

You can find the digital version of the instruction manual for the FOTOSOK FTSMD128US Kids Bookshelf with Reading Nook directly on Manuals+ at the following link: FOTOSOK FTSMD128US Instruction Manual. Key Assembly and Setup...

Read full answer

Where can I find the instruction manual for the FOTOSOK FTSMD128US Kids Bookshelf with Reading Nook?

You can find the digital version of the instruction manual for the FOTOSOK FTSMD128US Kids Bookshelf with Reading Nook directly on the Manuals+ page you were visiting: FOTOSOK FTSMD128US Instruction Manual.

Key Assembly and...

Read full answer

Open the live page

https://manuals.plus/asin/B0DBPXP81C

More documents and user manuals: **https://manuals.plus/**