Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OAKHAM HOME OFSC0015DD

OAKHAM HOME Hampstead Rattan 4-Door Storage Sideboard Cabinet

Model: OFSC0015DD

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your OAKHAM HOME Hampstead Rattan 4-Door Storage Sideboard Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: OAKHAM HOME Hampstead Rattan 4-Door Storage Sideboard Cabinet

2. Safety Information

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use.
- Do not overload shelves. Refer to specifications for weight limits.
- For stability, it is recommended to secure the cabinet to a wall using appropriate anti-tip hardware (if included or purchased separately).
- Keep small parts away from children during assembly.

3. Parts List

Please refer to the included assembly diagram and hardware list provided in your product packaging. Ensure all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support. For a visual guide to the assembly process, please refer to the official installation video below:

Your browser does not support the video tag.

Video 1: Rattan 4 Door Cabinet Installation Guide. This video demonstrates the step-by-step assembly process for the cabinet, including attaching hardware and panels.

4. Assembly Instructions

Follow the numbered steps in your provided assembly manual. The general process involves:

1. Attaching hardware to the main panels.
2. Connecting the base and side panels.
3. Installing the back panel and internal shelves.
4. Attaching the four rattan doors and their handles.

For detailed visual instructions, please refer to the installation video in Section 3.



Figure 2: Product Dimensions and Load Capacity



Figure 3: Adjustable Shelf Design and Internal Features

5. Operating Instructions

5.1 Adjustable Shelves

The cabinet features 3-level adjustable shelves. To adjust a shelf, remove all items from the shelf, then carefully lift the shelf and reposition the shelf pins to the desired height. Ensure all four pins are securely inserted into the corresponding holes before placing items back on the shelf.

5.2 Door Operation

The four doors are equipped with soft-close hinges for quiet and gentle closing. To open, gently pull the gold-tone handles. To close, push the door until the soft-close mechanism engages.

6. Maintenance

- Wipe the cabinet surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Regularly check all hardware connections and tighten if necessary to maintain stability.

- Avoid prolonged exposure to direct sunlight or extreme humidity to prevent material damage.

7. Troubleshooting

7.1 Door Alignment Issues

If the cabinet doors are not aligning correctly or there is an uneven gap between them, the hinges may need adjustment. The hinges allow for left/right, front/rear, and up/down adjustments.

- **Left/Right Adjustment:** Open the door panel. Use a screwdriver to turn the screw located on the hinge to the right to move the door panel to the right, or to the left to move it left.
- **Front/Rear Adjustment:** Open the door panel. Use a screwdriver to turn the screw on the hinge to the left to move the door panel inward, or to the right to move it outward.
- **Up/Down Adjustment:** Open the door panel. Use a screwdriver to turn the top and bottom screws on the hinge to the left to move the door panel down, or to the right to move it up.

For a visual guide on adjusting the door hinges, please refer to the official video below:

Your browser does not support the video tag.

Video 2: OAKHAM HOME Door Correction Guide. This video illustrates how to adjust the hinges for proper door alignment, covering left/right, front/rear, and up/down adjustments.

8. Specifications

Feature	Detail
Brand	OAKHAM HOME
Model Number	OFSC0015DD
Color	Special Walnut
Material	Exterior Grade MDF Board
Product Dimensions (D x W x H)	15.43" x 61.02" x 32.75"
Item Weight	41 Pounds
Number of Doors	4
Number of Shelves	1 (Adjustable to 3 levels)
Max Capacity (Top Panel)	100 lbs
Max Capacity (Adjustable Shelves)	50 lbs
Installation Type	Freestanding
Required Assembly	Yes

9. Warranty and Support

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the OAKHAM HOME official website. Keep your proof of purchase for any warranty claims.

© 2026 OAKHAM HOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DBVV3CNV

More documents and user manuals: **https://manuals.plus/**