Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cuisinart CK-10TR

Cuisinart Soho 1 Liter Double Wall Electric Kettle User Manual

Model: CK-10TR

Introduction

Thank you for purchasing the Cuisinart Soho 1 Liter Double Wall Electric Kettle. This appliance is designed to quickly and efficiently boil water for various uses, such as preparing tea, coffee, hot cocoa, or instant meals. Its double-walled construction ensures safety and maintains water temperature, while the compact design offers convenience and easy storage. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- **READ ALL INSTRUCTIONS.**
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized Cuisinart Service Facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by Cuisinart may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot water.
- The kettle is designed for boiling water only. Do not fill with other liquids.
- Do not operate the kettle without water.
- Ensure the lid is securely closed before operating.

Product Overview

Familiarize yourself with the components of your Cuisinart Soho Electric Kettle.



Figure 1: Front view of the Cuisinart Soho 1 Liter Double Wall Electric Kettle in Truffle color, showcasing its sleek design and Cuisinart logo.

- **Kettle Body:** Double-walled stainless steel interior for safety and heat retention.
- **Lid:** Securely covers the kettle opening.
- **Handle:** Ergonomically designed for comfortable pouring.
- **Power Base:** Provides power to the kettle and features integrated cord storage.
- **On/Off Switch:** Simple one-touch operation to start the boiling process.
- **Spout:** Designed for easy and controlled pouring.

Setup

Before first use, follow these steps:

1. **Unpack:** Carefully remove the kettle and all its components from the packaging. Retain packaging for future storage or shipping.
2. **Clean:** Before initial use, fill the kettle to the MAX fill line with fresh water. Bring the water to a boil, then discard it. Repeat this process two to three times to remove any manufacturing residues.
3. **Position:** Place the power base on a flat, stable, heat-resistant surface. Ensure the cord is not dangling where it can be pulled or tripped over.
4. **Cord Storage:** The power base features integrated cord storage. Adjust the cord length as needed for your countertop.



Figure 2: The Cuisinart Soho Electric Kettle positioned on a kitchen counter, demonstrating its compact design and the integrated cord storage within the base, which helps save space.

Operating Instructions

Follow these steps to boil water with your Cuisinart Soho Electric Kettle:

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of fresh, cold water. Do not fill below the MIN mark

or above the MAX mark (1 Liter). Ensure the lid is securely closed after filling.

2. **Place on Base:** Place the kettle firmly onto the power base.
3. **Plug In:** Plug the power cord into a standard electrical outlet.
4. **Start Boiling:** Press the On/Off switch located near the base of the handle. The indicator light will illuminate, indicating that the kettle is heating.
5. **Automatic Shut-Off:** The kettle will automatically shut off once the water reaches a rolling boil. The indicator light will turn off.
6. **Pour:** Carefully lift the kettle from the power base and pour the hot water. The double-wall design keeps the exterior cool to the touch.
7. **Unplug:** For safety and energy saving, unplug the kettle from the outlet when not in use.



Figure 3: A close-up view of a finger pressing the one-touch operation button located at the base of the Cuisinart Soho Electric Kettle's handle, initiating the heating process.



Figure 4: A hand pouring hot water from the Cuisinart Soho Electric Kettle into a white mug, demonstrating the innovative double-wall design that maintains boiling temperature inside while keeping the exterior cool to the touch.

Maintenance and Cleaning

Proper care ensures the longevity and performance of your kettle.

- **Always Unplug:** Before cleaning, always unplug the kettle from the electrical outlet and allow it to cool completely.
- **Exterior Cleaning:** Wipe the exterior of the kettle and the power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
- **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in areas with hard water. This can affect performance.
    - Fill the kettle with 2 cups of white vinegar and 2 cups of water.
    - Bring the mixture to a boil and let it stand for at least 30 minutes, or longer for heavy buildup.
    - Empty the kettle and rinse thoroughly with fresh water several times.
    - If necessary, repeat the process.

- **Do Not Immerse:** Never immerse the kettle or power base in water or any other liquid.
- **Storage:** When not in use, store the kettle in a clean, dry place. The integrated cord storage in the base helps keep your countertop tidy.

Troubleshooting

If you encounter issues with your kettle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power switch not pressed; kettle not properly seated on base; no water in kettle.	Ensure kettle is plugged in; press the On/Off switch; ensure kettle is correctly placed on the power base; add water to the kettle.
Water is not boiling.	Kettle not turned on; insufficient water; limescale buildup.	Press the On/Off switch; ensure water level is above MIN mark; descale the kettle as per cleaning instructions.
Kettle shuts off too quickly.	Limescale buildup.	Descale the kettle as per cleaning instructions.
Water tastes strange or has particles.	New kettle residue; limescale buildup.	Perform initial cleaning steps (boil and discard water); descale the kettle.

If the problem persists, please contact Cuisinart Customer Service for assistance.

Specifications

Brand	Cuisinart
Model Name	Soho 1 Liter Double Wall Electric Kettle
Model Number	CK-10TR
Color	Truffle
Capacity	1 Liter (1.1 Quarts)
Material	Stainless Steel Interior
Special Features	Automatic Shut-Off, Boil-Dry Protection, Double-Wall Construction, Integrated Cord Storage
Product Dimensions	8.07"L x 5.71"W x 8.46"H
Item Weight	2.2 Pounds
UPC	086279235091



Figure 5: The Cuisinart Soho 1-Liter Double Wall Electric Kettle shown with its key dimensions, including height (8.5"), width (5.7"), and length (8"), providing a clear understanding of its compact size.

Warranty and Support

Limited 3-Year Warranty:
Your Cuisinart Soho 1 Liter Double Wall Electric Kettle is covered by a limited 3-year warranty from the date of original purchase. This warranty covers defects in materials and workmanship under normal household use. It does not cover damage resulting from accident, misuse, abuse, commercial use, or unauthorized modification.

To Obtain Service:
If your appliance should prove to be defective within the warranty period, do not return it to the store. Please contact Cuisinart Customer Service directly for assistance. You may be required to provide proof of purchase and return the product for repair or replacement.

For further information, visit the official Cuisinart website or refer to the contact details provided in your product's warranty card. For more products and information, visit the Cuisinart Store on Amazon.

© 2025 Cuisinart. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DD5FH26S

More documents and user manuals: **https://manuals.plus/**