Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Erivess HA109B

Erivess Portable 2-in-1 Twin Tub Washing Machine (32 lbs) Instruction Manual

Model: HA109B

Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The Erivess Portable 2-in-1 Twin Tub Washing Machine (Model HA109B) is a semi-automatic compact laundry solution designed for small living spaces such as apartments, dorms, RVs, and for camping. It features separate tubs for washing and spin-drying, offering a convenient and efficient way to manage your laundry.

Key Features:

- Large Twin Tub Capacity: 22 lbs washing capacity and 10 lbs spinning capacity.
- Efficient Dual Motor Power: 280W washer motor and 135W spinner motor for powerful performance.
- User-Friendly Semi-Automatic System: Easy operation with adjustable wash (0-15 min) and spin (0-5 min) timers.
- Energy and Water Efficient: Designed to reduce utility consumption.



Image 1.1: Erivess Twin Tub Washing Machine showing dimensions (26.77" x 15.55" x 31.1") and example load capacities for various clothing items.

2. Setup Instructions

1. **Unpacking:** Carefully remove the washing machine from its packaging. Ensure all components, including the instruction manual, warranty card, washing machine, and drying rack, are present.
2. **Placement:** Place the washing machine on a flat, stable surface. Ensure it is near a water source (faucet) and a drain point (sink, tub, or bucket). The drain hose must be elevated a few inches off the floor to allow proper drainage.
3. **Connect Water Inlet:** Attach the inlet hose to the water inlet port on the washing machine (usually on the left side for the wash tub) and connect the other end to a suitable faucet. Ensure a secure connection to prevent leaks.



Image 2.1: Detail of the water inlet port on the washing machine.

4. **Position Drain Hose:** Place the drain hose into a sink, bathtub, or a large bucket. Ensure the hose is not submerged in water to prevent siphoning issues.



Image 2.2: Detail of the drain hose, showing its flexible design for placement into a drain.

5. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.

▶ **Watch video online**
Erivess Portable Mini Twin Tub Washing Machine(22 lbs)

Video 2.1: Demonstration of the Erivess Portable Mini Twin Tub Washing Machine (22 lbs) in operation, including water filling and washing cycles. Note: The video title indicates 22 lbs capacity, while this product is 32 lbs.

3. Operating Instructions

3.1. Washing Cycle

1. **Load Clothes:** Open the lid of the wash tub and place your clothes inside. Do not overload the machine; ensure clothes can move freely. The maximum washing capacity is 22 lbs.
2. **Add Water & Detergent:** Fill the wash tub with water to the desired level. Add the appropriate amount of laundry detergent.
3. **Set Wash Timer:** Turn the "WASH TIMER" knob to select the desired washing time (0-15 minutes). For normal loads, 10-15 minutes is usually sufficient.
4. **Select Wash Mode:** Use the "WASH SELECTOR" knob to choose between "SOFT" or "NORMAL" wash modes. "NORMAL" is suitable for most fabrics, while "SOFT" is for delicate items.



Image 3.1: Close-up of the control panel showing the wash timer, wash selector, and spin timer knobs.

5. **Start Washing:** The machine will begin the washing cycle.
6. **Drain Water:** Once the washing cycle is complete, turn the "WASH SELECTOR" knob to "DRAIN" to empty the dirty water from the wash tub.

3.2. Rinse Cycle (Optional)

For a thorough rinse, you can repeat steps 2-4 with clean water and no detergent. Typically, 3-4 minutes is sufficient for rinsing.

3.3. Spin Drying Cycle

1. **Transfer Clothes:** Carefully transfer the washed clothes from the wash tub to the spin dryer tub. Ensure clothes are evenly distributed to prevent imbalance during spinning. The maximum spinning capacity is 10 lbs.
2. **Place Spin Cap:** Place the white spin cap firmly on top of the clothes in the spin dryer tub to prevent small items from flying out.

Image 3.2: The spin cap placed inside the spin dryer tub to secure clothes during operation.

3. **Set Spin Timer:** Turn the "SPIN TIMER" knob to select the desired spin drying time (0-5 minutes).
4. **Start Spin Drying:** The spin dryer will begin. The motor and drain pump are equipped with overheating

protection; if they overheat, restart them after 30-60 minutes of cooling.

5. **Remove Clothes:** Once the spin cycle is complete, remove the clothes. They will be nearly dry and can be air-dried or hung on the included drying rack.

4. Maintenance

- **Cleaning the Lint Filter:** Regularly check and clean the lint filter located inside the wash tub. Remove any accumulated lint to ensure efficient operation.



Image 4.1: Internal view of the wash tub, highlighting the lint filter for regular cleaning.

- **Exterior Cleaning:** Wipe the exterior of the machine with a soft, damp cloth. Avoid using abrasive cleaners or solvents.
- **Interior Cleaning:** Periodically clean the interior of both tubs to prevent detergent residue buildup. Run a short wash cycle with just water and a small amount of vinegar if needed.
- **Storage:** If storing the machine for an extended period, ensure both tubs are completely dry. Disconnect hoses and store the machine in a cool, dry place.

5. Troubleshooting

Problem	Possible Cause	Solution
Machine does not start.	Power cord not plugged in; timer not set.	Ensure power cord is securely plugged in. Set the wash or spin timer.
Water does not drain.	Drain hose is blocked or improperly positioned.	Check for kinks or blockages in the drain hose. Ensure the drain hose is elevated above the water level in the tub.
Spin dryer is unbalanced or vibrates excessively.	Clothes are unevenly distributed in the spin tub.	Rearrange clothes evenly in the spin tub. Ensure the spin cap is properly placed.
Motor stops during operation.	Overheating protection activated.	Allow the motor to cool for 30-60 minutes before restarting. Reduce load size if consistently overheating.

6. Product Specifications

- **Brand:** Erivess
- **Model:** HA109B
- **Washing Capacity:** 22 lbs
- **Spinning Capacity:** 10 lbs
- **Washer Motor:** 280W
- **Spinner Motor:** 135W
- **Item Weight:** 34.2 pounds
- **Product Dimensions:** 26.77 x 15.55 x 31.1 inches
- **Voltage:** 120 Volts (AC)
- **Material:** Metal, Plastic
- **Installation Type:** Freestanding
- **Access Location:** Top Load
- **Included Components:** Instruction Manual, Warranty Card, Washing Machine, Drying Rack

7. Warranty and Support

Your Erivess Portable 2-in-1 Twin Tub Washing Machine comes with a warranty card. Please refer to the warranty card for specific terms and conditions regarding coverage and duration.
For technical support, troubleshooting assistance, or warranty claims, please contact Erivess customer service. Contact information can typically be found on the warranty card or the official Erivess website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DD7F8SH8

More documents and user manuals: **https://manuals.plus/**