Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PITIKI 61c7337e-bd92-49e1-ae7d-e4fc62f819b6

PITIKI 6K 64MP Vlogging Camcorder User Manual

Model: 61c7337e-bd92-49e1-ae7d-e4fc62f819b6

Introduction Package Contents Product Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the PITIKI 6K 64MP Vlogging Camcorder. This manual provides essential information for the safe and effective use of your device. Please read it thoroughly before operation and retain it for future reference.

Safety Information

- This camera is designed for amateur use.
- Do not expose the camera to water or extreme temperatures.
- Use only approved accessories and power adapters.
- Keep out of reach of children.
- Format the SD card before first use.

2. Package Contents

Verify that all items listed below are included in your package:

- 1 x 6K Video Camera
- 1 x 64GB SD Card
- 1 x 4500 mAh Lithium Battery
- 1 x Lens Hood
- 1 x 2.4G Remote Control
- 1 x Microphone
- 1 x USB Cable
- 1 x HDMI Cable
- 1 x User Manual
- 1 x Handheld Stabilizer

- 1 x Cleaning Cloth
- 1 x Velvet DV Bag



Image: The PITIKI 6K 64MP Vlogging Camcorder shown with its various accessories, including the external microphone, remote control, and handheld stabilizer.

3. Product Overview

Camera Components

Familiarize yourself with the main components of your camcorder:

- **Lens:** F/2, f=7.62mm
- **4.0-inch Touch Screen:** For navigation and preview.
- **Built-in Fill Light:** For improved brightness in low-light conditions.
- **IR Night Vision:** For recording in dark environments.
- **Hot Shoe Mount:** For external accessories like the microphone or LED light.

- **Tripod Thread Interface:** For mounting on a standard tripod (not included).
- **USB 2.0 Port:** For data transfer and charging.
- **HDMI Output:** For connecting to a TV or monitor.
- **Microphone Input:** For connecting the external microphone.
- **SD Card Slot:** Supports up to 256GB SD card (Class 10 or higher recommended).



Image: Front view of the camcorder, highlighting the lens and built-in fill light.

4. Setup

4.1. Charging the Battery

1. Insert the 4500 mAh lithium battery into the battery compartment.
2. Connect the camera to a power source using the provided USB cable.
3. The charging indicator will illuminate. Charge the battery completely before first use (approximately 4.5 hours for 6K recording).

4. The camera supports recording while charging.

4.2. Inserting the SD Card

1. Open the SD card slot cover.
2. Insert the 64GB SD card (or your own, up to 256GB, Class 10 or higher) with the metal contacts facing the correct direction until it clicks into place.
3. Close the SD card slot cover.
4. **Important:** Format the SD card via the camera's menu before initial use.

4.3. Attaching the Microphone

1. Slide the external microphone onto the hot shoe mount on top of the camera.
2. Connect the microphone cable to the microphone input port on the camera.
3. Ensure the microphone is securely attached for optimal audio recording.

4.4. Attaching the Handheld Stabilizer

1. Attach the camcorder to the handheld stabilizer using the tripod thread interface at the bottom of the camera.
2. Tighten securely to prevent wobbling during use.
3. The stabilizer helps achieve smoother, low-angle video recordings.

5. Operation

5.1. Power On/Off

Press and hold the Power button to turn the camera on or off.

5.2. Video Recording

1. Turn on the camera.
2. Select video mode on the touch screen.
3. Press the Record button to start recording. Press again to stop.
4. Supported video resolutions include 6K (30FPS), 5K (30FPS), 4.7K (30FPS), 4K (60/30FPS), 2.7K (30FPS), FHD (60/30FPS), HD (120/60/30FPS).
5. Use the 18X digital zoom by pressing the zoom controls.
6. The camera supports pause function during recording.

5.3. Photo Capture

1. Turn on the camera.
2. Select photo mode on the touch screen.
3. Press the Shutter button to take a photo.
4. Image resolution is 64MP.
5. Features include continuous shooting and face detection.

5.4. Playback

Access the playback mode via the touch screen to review recorded videos and photos.

5.5. WiFi Connection (Using "Hello Cam" App)

1. Download the "Hello Cam" app on your mobile phone or tablet.
2. Enable WiFi on the camcorder via the settings menu.
3. Connect your mobile device to the camera's WiFi network.
4. Use the app to control the camcorder, browse photo albums, and download files.

5.6. Webcam Mode

1. Connect the camera to your computer using the USB cable.
2. Select "Webcam Mode" on the camera's screen (if prompted).
3. The camera will function as a webcam for video calls or streaming.
4. Supports Windows 7/8/10/11 and MAC systems.

5.7. IR Night Vision

Activate IR Night Vision mode through the camera's menu to record clear black and white videos or photos in dark environments.

5.8. 2.4G Remote Control

1. Insert 2 AAA batteries (not included) into the 2.4G remote control.
2. The remote allows 360° wireless control of the camera from up to 60 feet away.
3. Use the remote for starting/stopping recording, taking photos, and other functions without touching the camera.

6. Maintenance

6.1. Cleaning

- Use the provided cleaning cloth to gently wipe the camera body and lens.
- Do not use liquid cleaners or solvents.
- Ensure the camera is powered off before cleaning.

6.2. Storage

- Store the camera in a cool, dry place, away from direct sunlight and humidity.
- Remove the battery if the camera will not be used for an extended period.
- Use the velvet DV bag for protection during storage and transport.

7. Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Battery is depleted or incorrectly inserted.	Charge the battery fully. Ensure the battery is inserted correctly.
SD card error.	SD card not formatted or incompatible.	Format the SD card in the camera. Use a Class 10 or higher SD card.
Poor audio quality.	External microphone not connected properly or faulty.	Ensure the external microphone is securely connected. Check microphone settings.

Problem	Possible Cause	Solution
Remote control not working.	Batteries depleted or not inserted. Out of range.	Insert 2 AAA batteries. Ensure you are within 60 feet of the camera.
Unclear or blurry images/videos.	Lens is dirty. Focus issue.	Clean the lens with the provided cloth. Ensure proper lighting conditions.

8. Specifications

- **Brand:** PITIKI
- **Model:** 61c7337e-bd92-49e1-ae7d-e4fc62f819b6 (DV95)
- **Video Resolution:** 6K (30FPS), 5K (30FPS), 4.7K (30FPS), 4K (60/30FPS), 2.7K (30FPS), FHD (60/30FPS), HD (120/60/30FPS)
- **Image Resolution:** 64 Megapixels
- **Digital Zoom:** 18X
- **Screen:** 4.0-inch Touch Screen
- **Lens Aperture:** F/2, f=7.62mm
- **Battery:** 4500 mAh Lithium-ion
- **Storage:** Supports SD Card up to 256GB (64GB included)
- **Video Format:** MP4
- **Photo Format:** JPEG
- **Computer Interface:** USB 2.0 (High Speed)
- **Connectivity:** WiFi, HDMI Output
- **Special Features:** IR Night Vision, Built-in Fill Light, Pause Function, Time-lapse, Slow Motion, Burst Shooting, Face Capture, Image Stabilization, Webcam Function, 2.4G Wireless Remote Control.
- **Dimensions (Package):** 20.9 x 20.9 x 11.4 cm
- **Weight (Package):** 1.46 kg

9. Warranty and Support

For warranty information and technical support, please refer to the contact details provided with your purchase or visit the official PITIKI website. Keep your proof of purchase for warranty claims.
Software updates are not guaranteed beyond the initial release. Spare parts availability information is not available.

© 2024 PITIKI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DFLG9GDQ

More documents and user manuals: **https://manuals.plus/**