Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Edillas 869LB

Edillas Kids Digital Watch Instruction Manual

Model: 869LB
Brand: Edillas

Introduction

Welcome to the instruction manual for your new Edillas Kids Digital Watch. This multifunctional wristwatch is designed for children, students, and teenagers aged 7-15, offering a blend of durability, style, and practical features. With 7 LED light colors, 50M water resistance, stopwatch, alarm, and time/date display, it's perfect for sport and outdoor activities. Please read this manual carefully to understand how to operate and maintain your watch.

The Edillas Kids Digital Watch, featuring its vibrant blue and black design and various LED light colors.

Key Features

- **50M/5BAR Water Resistance:** Suitable for daily use including hand washing, rain, splashing, cold baths, and swimming. *(Note: Avoid pressing buttons underwater.)*
- **7 Colorful LED Lights:** Features blue, green, red, sky blue, orange, purple, and white monochrome lights, plus flashing colored light modes. Easily switch lights by holding the upper-left backlight button for 3 seconds.
- **Multifunctional Design:** Includes alarm clock (non-vibrating), stopwatch, hour/minute/second/date/day/AM/PM display, and 12H/24H time format.
- **Japan Imported Movement:** Ensures accurate timekeeping and long battery life.
- **Durable Construction:** Designed for active children and teenagers.



The watch is 50M water resistant, making it suitable for swimming and water play.

Setup

Your Edillas Kids Digital Watch comes ready to use with a pre-installed battery. Upon receiving your watch, you may need to adjust the time and date to your local settings. The watch is packaged securely to prevent damage during transit.

▶ **Watch video online**
How do I set the time and date on my 869LB Digital Watch?

This video demonstrates how to set the time and date on your Edillas 869LB Digital Watch, a key step during initial setup.

Operating Instructions

Button Functions:

- **LIGHT (Top Left):** Activates backlight. Hold for 3 seconds to change light color.
- **MODE (Bottom Left):** Cycles through display modes (Time, Alarm, Stopwatch).
- **START (Top Right):** Used to start/stop stopwatch, adjust settings (increment value).
- **RESET (Bottom Right):** Used to reset stopwatch, adjust settings (move to next setting).

Setting Time and Date:

1. From normal time display, press the**MODE** button three times to enter time setting interface. The seconds will start blinking.
2. Press **RESET** twice to skip seconds and minutes settings. The hour will start blinking.
3. Press **START** to set the hour. Note: A=AM, P=PM, H=24H format.
4. Press **RESET** to switch to days setting. Press**START** to set the day.
5. Press **RESET** to switch to months setting. Press**START** to set the month.
6. Press **RESET** to switch to weeks setting. Press**START** to set the week.
7. Press **MODE** to confirm settings and return to normal time display.

▶ **Watch video online**
How do I set the time and date on my 869LB Digital Watch?

Detailed video guide on how to set the time and date on your Edillas 869LB Digital Watch.

Switching 12H/24H Time Format:

1. From normal time display, press and hold the**RESET** key, then press and hold the**MODE** key together.
2. The display will switch between 12-hour (AM/PM indicator) and 24-hour (H indicator) formats.
3. Release both buttons to set the desired format.

▶ **Watch video online**
How to switch 12H/24H time format on 869LB digital watch?

This video illustrates the process of switching between 12-hour and 24-hour time formats on the Edillas 869LB Digital Watch.

Using the Stopwatch Function:

1. Press the **MODE** button once to enter stopwatch mode. The display will show "0:00".
2. Press **START** to begin timing.
3. Press **START** again to pause the stopwatch.
4. While paused, press **RESET** to clear the stopwatch to "0:00".
5. Press **MODE** to exit stopwatch mode and return to normal time display.

▶ **Watch video online**
How do I use the stopwatch function on 869LB digital watch?

Learn how to activate, start, pause, and reset the stopwatch function on your Edillas Digital Watch with this helpful video.

Using the Light Function:

- Press the **LIGHT** button (top left) to illuminate the display.
- To change the backlight color, press and hold the**LIGHT** button for approximately 3 seconds. The color will cycle through the 7 available options. Release the button when your desired color is displayed.

▶ **Watch video online**
How do I use the light function on my 869LB Digital Watch?

This video demonstrates how to turn on the backlight and cycle through the 7 different LED colors on your Edillas Digital Watch.

Setting the Alarm:

The watch features a non-vibrating alarm. To set the alarm:

1. From normal time display, press the**MODE** button twice to enter alarm setting mode. The hour digits will start blinking.
2. Press **START** to adjust the alarm hour.
3. Press **RESET** to switch to the minute digits.
4. Press **START** to adjust the alarm minutes.
5. Press **MODE** to confirm the alarm setting and return to normal time display.
6. To turn the alarm on/off, press and hold**START** and then press **MODE**. An alarm icon will appear/disappear on the display.

MAINTENANCE

Water Resistance:

Your Edillas watch is 50M (5 BAR) water resistant. This means it can withstand splashes, rain, hand washing, cold baths, and swimming. However, to maintain its water resistance, **do not press any buttons while the watch is submerged in water.**
Avoid wearing the watch in hot baths, saunas, or other high-temperature environments, as this can compromise the water seals.

▶ **Watch video online**
50M Waterproof swimming watch

This video demonstrates the 50M water resistance of the Edillas watch under running water, showing its suitability for everyday water exposure.

Battery Replacement:

The watch uses Japan imported batteries for long-lasting performance. If you experience any issues with the battery or movement, please contact customer service for assistance. We can help you replace the watch with a new one if there is a problem covered under warranty.

General Care:

- Clean the watch regularly with a soft, dry cloth.
- Avoid exposing the watch to extreme temperatures or strong magnetic fields.
- Protect the watch from strong impacts.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery or battery needs replacement.	Contact customer service for battery replacement.
Time is inaccurate.	Time not set correctly or internal movement issue.	Re-set the time and date as per operating instructions. If issue persists, contact support.
Buttons are unresponsive or change settings accidentally.	Buttons may be stuck or sensitive.	Ensure buttons are not jammed. Avoid excessive force. If accidental changes occur, re-set the watch.
Water inside the watch.	Buttons pressed underwater or exposure to hot water/steam.	Stop using the watch immediately. Do not attempt to open it. Contact customer service.

Specifications

- **Model Number:** 869LB
- **Product Dimensions:** 8.86 x 0.63 x 0.47 inches
- **Item Weight:** 3.84 ounces
- **Water Resistance:** 50M / 5 BAR
- **Battery:** 1 C battery (included)
- **Clasp Type:** Buckle
- **Band Width:** 16 millimeters
- **Manufacturer:** Yadelai (Edillas)
- **Country of Origin:** China

Detailed dimensions of the Edillas Kids Digital Watch.

Warranty and Support

Edillas is committed to providing high-quality products and excellent customer service.

- **30-Day Refund:** If you are not satisfied with your purchase, you may be eligible for a refund within 30 days.
- **90-Day Free Replacement Service:** For any product defects or issues within 90 days of purchase, a free replacement service is available.
- **Lifetime Technical Support:** Should you encounter any problems while using the watch, or have questions about its functions, our customer service team is available to provide lifetime technical support.

Contact Customer Service:
Email: yadelaiaftersale@163.com

You can also consult our customer service team through Amazon for any assistance.

© 2023 Edillas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DFLXNPN9

More documents and user manuals: **https://manuals.plus/**