**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Dpofirs Dpofirsgefpi9xmdt-12

# Dpofirs 2.5K 72MP Digital Camera User Manual

Model: Dpofirsgefpi9xmdt-12

## 1. Introduction

This manual provides essential instructions for the safe and effective use of your Dpofirs 2.5K 72MP Digital Camera. Please read this manual thoroughly before operating the device and retain it for future reference.

The Dpofirs 2.5K 72MP Digital Camera is a portable imaging device designed for photography and video recording. It features a 72-megapixel image resolution, 2.5K video recording capability, 16x digital zoom, and autofocus functionality. The camera includes a 2.4-inch main display and a 1.54-inch secondary display for selfies, along with anti-shake technology for stable captures.

## 2. Package Contents

Verify that all items are present in the package:

- 1 x Dpofirs 2.5K 72MP Digital Camera
- 1 x Instruction Manual
- 1 x USB Type-C Charging Cable
- 1 x Wrist Strap





Image: Included accessories: USB Type-C charging cable and wrist strap.

## 3. Camera Overview

Familiarize yourself with the camera's components and controls.




Image: Front view of the camera, highlighting the lens and front display.




Image: Rear view of the camera, showing the main display and control layout.

## Key Components:

- **Lens:** Captures images and videos. Features automatic focus.
- **Flash:** Provides illumination in low-light conditions.
- **Front Display (1.54 inch):** Secondary screen for selfies and vlogging.
- **Main Display (2.4 inch IPS):** Primary screen for viewing, menu navigation, and playback.
- **Power Button:** Turns the camera on or off.
- **Shutter Button:** Takes photos.
- **Mode (M) Button:** Switches between photo and video modes, and long press to switch screens.
- **Directional Pad (Up/Down/Left/Right/OK):** Navigates menus and selects options.
- **Menu/Settings Button:** Accesses camera settings.
- **Zoom Buttons (+/-):** Adjusts digital zoom.
- **Type-C Port:** For charging and data transfer.
- **Memory Card Slot:** For inserting a small memory card (up to 128GB, not included).

- **Tripod Mount (1/4 Inch Threaded Hole):** For attaching to a tripod.

## 4. Setup

### 4.1 Charging the Battery

1. Connect the provided USB Type-C charging cable to the camera's Type-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator will illuminate. Once fully charged, the indicator may change color or turn off.

The camera has a built-in 750mAh Lithium Ion Battery.

### 4.2 Inserting a Memory Card

A small memory card (up to 128GB) is required for storing photos and videos. It is not included with the camera.

1. Locate the memory card slot on the side of the camera.
2. Insert the small memory card into the slot with the metal contacts facing the correct direction (refer to the diagram near the slot if available).
3. Push the card gently until it clicks into place. To remove, push the card again until it springs out.

### 4.3 Attaching the Wrist Strap

Thread the included wrist strap through the designated loop on the camera body to prevent accidental drops.

## 5. Operating Instructions

### 5.1 Powering On/Off

- To power on: Press and hold the Power button.
- To power off: Press and hold the Power button again until the camera shuts down.

### 5.2 Taking Photos

1. Ensure the camera is in photo mode. If not, press the **M** button to switch to photo mode.
2. Frame your shot using the main display. The camera features autofocus to ensure clarity.
3. Lightly press the Shutter button to take a picture.




Image: The camera's autofocus lens ensures clear images.

## 5.3 Recording Videos

1. Press the **M** button to switch to video recording mode.
2. Press the Shutter button to start recording. A recording indicator will appear on the screen.
3. Press the Shutter button again to stop recording.




Image: The camera's rear display showing video shooting mode with 2.5K HD recording.

## 5.4 Using the Selfie Screen

The camera features a 1.54-inch secondary display on the front, ideal for selfies and vlogging.

- To switch to the front screen: Long press the**M** button.
- The front screen will activate, allowing you to compose your shot while facing the camera.
- The camera supports automatic beauty and various filters for enhanced selfies.




Image: Demonstrating the front 2.4-inch HD display and the rear 1.54-inch HD display.

### 5.5 Menu Navigation and Settings

- Press the Menu/Settings button to access the camera's menu.
- Use the directional pad (Up, Down, Left, Right) to navigate through menu options.
- Press the **OK** button (center of directional pad) to select an option.
- Available settings include White Balance (Auto, Daylight, Cloudy, Tungsten, Fluorescent), image resolution, video resolution, and more.

## 6. Maintenance

### 6.1 Cleaning the Camera

- Use a soft, lint-free cloth to clean the camera body.

- For the lens and display screens, use a specialized lens cleaning cloth and solution. Avoid harsh chemicals.
- Ensure the camera is powered off before cleaning.

### 6.2 Storage

- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove the memory card and ensure the battery is partially charged (around 50%) to prolong its lifespan.

## 7. Troubleshooting

### Camera Does Not Turn On

- Check if the battery is charged. Connect the camera to a power source using the Type-C cable.
- Ensure the Power button is pressed and held sufficiently.

### Cannot Take Photos/Record Videos

- Verify that a memory card is inserted correctly and has sufficient free space.
- Check if the camera is in the correct mode (photo or video).
- Ensure the battery has enough charge.

### Images Are Blurry

- Ensure the lens is clean and free from smudges.
- Allow the autofocus system to lock onto the subject before fully pressing the shutter button.
- Utilize the anti-shake function for stable shots, especially in low light or with zoom.

### Screen Not Responding

- Try restarting the camera.
- Ensure the screen is not physically damaged.

## 8. Specifications

| Feature | Specification |
|---|---|
| Image Resolution | 72M (Maximum) |
| Video Resolution | 2.5K (Maximum) |
| Zoom Magnification | 16x Digital Zoom |
| Aperture | F/2.0 |
| White Balance | Auto, Daylight, Cloudy, Tungsten, Fluorescent |
| Autofocus | Supported |

| | |
|---|---|
| Battery Type | Built-in Lithium Ion Battery |
| Battery Capacity | 750mAh |
| Storage Support | Up to 128GB Small Memory Card (Excluded) |
| Fill Light | Supported |
| Menu Language | Multi-language support (Simplified Chinese, Traditional Chinese, English, etc.) |
| Charging Port | Type-C |
| Display Screen | 2.4 Inch Main Screen, 1.54 Inch Secondary Screen |
| USB Version | 2.0 |
| Bottom Connector | 1/4 Inch Threaded Hole |
| Wireless Transmission | Not Supported |
| Package Dimensions | 5.12 x 4.72 x 2.76 inches |
| Item Weight | 7.3 ounces |
| Model Number | Dpofirsgefpi9xmdt-12 |
| Manufacturer | Dpofirs |

## 9. Warranty and Support

Warranty information for your Dpofirs 2.5K 72MP Digital Camera is typically provided with your purchase documentation or on the product packaging. Please refer to these resources for details regarding warranty coverage and terms.
For technical support, troubleshooting assistance beyond this manual, or inquiries about replacement parts, please contact Dpofirs customer service through the retailer where the product was purchased or visit the official Dpofirs brand store online.

© 2025 Dpofirs. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0DFQBMLZY**

More documents and user manuals: **https://manuals.plus/**