Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BEFANS Christmas Tree M

BEFANS 15-Inch Holographic Christmas Tree with LED Lights Instruction Manual

Model: Christmas Tree M

1. Introduction

Thank you for choosing the BEFANS 15-Inch Holographic Christmas Tree with LED Lights. This product is designed to provide a captivating display of colors and lights, suitable for various indoor decorative purposes. This manual contains important information regarding the safe and proper use of your new Christmas tree. Please read it thoroughly before use and retain it for future reference.



Image 1: The BEFANS 15-Inch Holographic Christmas Tree with LED Lights.

2. Safety Information

- **Indoor Use Only:** This product is intended for indoor decoration. Do not use outdoors or expose to moisture.
- **Power Source:** Use only with a compatible USB power adapter (wall plug not included). Ensure the voltage matches the product requirements.
- **Cable Care:** Do not place the USB cable near heat sources or sharp objects. Avoid bending or kinking the cable excessively.
- **Children and Pets:** Keep the product out of reach of small children and pets to prevent accidental damage or injury.
- **Cleaning:** Disconnect from power before cleaning. Use a soft, dry cloth. Do not use liquid cleaners.
- **Disassembly:** Do not attempt to disassemble or modify the product. This may void the warranty and pose a safety risk.

3. Package Contents

Verify that all items are present in the package:

- 1 x Holographic Christmas Tree (Model: Christmas Tree M)
- 1 x USB Charger Cable (78-inch)
- 1 x On/Off USB Cable Switch

4. Setup Instructions

1. **Unpack:** Carefully remove the Holographic Christmas Tree from its packaging.
2. **Placement:** Place the tree on a stable, flat surface indoors, away from direct heat or moisture.
3. **Connect Power:** Locate the 78-inch USB charger cable and the On/Off USB cable switch. Connect the USB cable to the tree's power input.
4. **Power Source:** Plug the USB end of the cable into a compatible USB power adapter (not included) or a USB port on a device.
5. **Activate:** Use the On/Off switch located on the USB cable to turn the tree on.



Image 2: Illustration of the product's dimensions and the USB cable with integrated switch.

5. Operating Instructions

The Holographic Christmas Tree features 100 LED lights that create a dynamic, colorful display. To operate the tree:

1. **Power On/Off:** Use the On/Off switch on the USB cable to turn the lights on or off.
2. **Light Effects:** The tree is designed to automatically cycle through various light effects, reflecting off its iridescent PET material to create a crystal-like show of colors.

Observe the tree's light effects in the following video:

▶ **Watch video online**
Prismatic Christmas Tree with LED lights

Video 1: A demonstration of the BEFANS Prismatic Christmas Tree with LED lights in operation, showcasing its various light patterns and colors.

6. Maintenance

To ensure the longevity and appearance of your Holographic Christmas Tree:

- **Cleaning:** Gently wipe the surface with a soft, dry, lint-free cloth. Avoid abrasive materials or harsh chemicals that could damage the iridescent finish.
- **Storage:** When not in use, store the tree in its original packaging or a protective container in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Inspection:** Periodically inspect the USB cable and switch for any signs of wear or damage. If damage is found, discontinue use.

7. Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, or faulty USB adapter.	Ensure the USB cable is securely connected to the tree and the power source. Verify the USB adapter is working. Check the On/Off switch position.
Lights flicker or are dim.	Insufficient power or damaged cable.	Try a different USB power adapter. Inspect the USB cable for damage.

8. Specifications

Feature	Detail
Brand	BEFANS
Model Number	Christmas Tree M
Product Dimensions	15"D x 8.26"W x 7.16"H
Material	Polyethylene Terephthalate (PET)
Item Weight	4.8 ounces
Built-in Light	Yes
Light Color	Colorful
Included Components	USB cable, On/Off USB switch
Recommended Use	Christmas decoration
Date First Available	September 9, 2024

9. Warranty and Support

For product support or inquiries, please contact BEFANS customer service through the retailer's platform where the product was purchased. Please retain your proof of purchase for any warranty claims.

© 2025 BEFANS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGL41L8R

More documents and user manuals: **https://manuals.plus/**