Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Chicco 1

Chicco Polly Essential Evolutionary High Chair

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the Chicco Polly Essential Evolutionary High Chair. This high chair is designed to accompany your baby's growth from birth up to 15 kg (approximately 3 years). Its clean lines and intuitive structure ensure ease of use, combining practicality and sophistication. This manual provides important information for the safe and proper assembly, operation, and maintenance of your high chair.

2. Safety Information

Always follow these safety guidelines to ensure the well-being of your child:

- Never leave your child unattended in the high chair.
- Always use the safety harness to secure your child.
- Ensure the high chair is fully assembled and all locking mechanisms are engaged before placing your child in it.
- Do not use the high chair if any parts are broken, torn, or missing.
- Keep the high chair away from heat sources, open flames, and strong drafts.
- Do not allow children to play with the high chair.
- The maximum weight capacity for this high chair is 15 kg (approximately 3 years).
- Always place the high chair on a flat, stable surface.

3. Package Contents

Before assembly, please verify that all components are present:

- High Chair Frame (legs and main structure)

- Seat Unit with integrated harness
- Feeding Tray
- Footrest
- Instruction Manual (this document)

If any parts are missing or damaged, please contact Chicco customer support.

4. Setup

Assembly of the Chicco Polly Essential High Chair is designed to be intuitive, though some steps may benefit from two people. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble the Frame:** Connect the leg sections as indicated in the diagrams. Ensure all connections click securely into place.
3. **Attach the Seat Unit:** Align the seat unit with the main frame and push down firmly until it locks into position. Verify it is securely attached by gently pulling upwards.
4. **Install the Footrest:** Slide the footrest into its designated slots on the frame. Ensure it is properly seated.
5. **Attach the Tray:** Slide the feeding tray onto the armrests until it clicks into place. Ensure it is firmly attached before use.



Image: The Chicco Polly Essential High Chair in dark grey, fully assembled. It features a sturdy frame with wooden-look legs, a comfortable padded seat, a five-point harness, and an attached feeding tray. The footrest is visible below the seat.

5. Operating

5.1. Height Adjustment

The Polly Essential high chair features 7 levels of height adjustment to adapt to various table heights and uses. To adjust the height, locate the adjustment buttons on the side of the frame (usually near the top of the legs). Press these buttons simultaneously and slide the seat unit up or down to the desired position. Release the buttons to lock the chair in place. Ensure both sides are locked at the same height.

5.2. Reclining Backrest

The backrest can be reclined into 3 positions, providing comfort for newborns and allowing for relaxation after meals. To recline, locate the recline lever or buttons on the back of the seat. Press the lever/buttons and gently push or pull the backrest to the desired angle. Release to lock.

5.3. Adjustable Footrest

The footrest can be adjusted to ensure a comfortable and ergonomic posture for your child as they grow. Locate the adjustment points on the footrest supports. Press the release buttons (if present) and slide the footrest up or down. Ensure it clicks into a locked position.

5.4. Attaching and Removing the Tray

To attach the tray, align the tray guides with the slots on the armrests and slide it forward until it clicks securely into place. To remove, locate the release levers or buttons, typically underneath the tray or on the armrests. Press the levers/buttons and pull the tray away from the high chair.

5.5. Securing Your Child with the Harness

Always use the 5-point safety harness to secure your child. Place your child in the seat, bring the shoulder straps over their shoulders, and the waist straps around their waist. Connect the buckles and insert them into the central buckle until they click. Adjust the straps to ensure a snug, secure fit without being too tight. To release, press the button on the central buckle.



Image: A side view of the Chicco Polly Essential High Chair, highlighting its slim profile and the adjustable footrest. The dark grey fabric seat and light wooden-look legs are visible, demonstrating its modern design.

6. Maintenance

6.1. Cleaning

The Chicco Polly Essential High Chair is designed for easy cleaning. For daily cleaning, wipe down the seat, tray,

and frame with a damp cloth and mild soap. For more thorough cleaning, the seat fabric can be wiped with a damp cloth and a non-bleach disinfectant. The tray is removable and can be washed separately. Ensure all parts are dry before reassembly or storage.

6.2. Storage

The high chair features a compact closure mechanism, allowing it to be folded for space-saving storage. To fold, locate the folding release mechanisms (refer to the assembly instructions for specific points). Engage the mechanisms and collapse the high chair. Once folded, the high chair stands on its own, making it easy to store in a corner or closet.

7. Troubleshooting

- **Difficulty Folding/Unfolding:** Ensure all adjustment levers (height, recline) are in their correct positions before attempting to fold or unfold. Apply gentle, even pressure. Do not force the mechanism.
- **High Chair Feels Unstable:** Verify that all legs are fully extended and locked into place. Ensure the high chair is on a flat, level surface. Check that the seat unit is securely attached to the frame.
- **Tray Not Attaching Securely:** Ensure there are no obstructions in the tray's attachment slots. Verify that the tray is aligned correctly before pushing it into place.
- **Harness Not Securing Child:** Check that the harness straps are not twisted and that the buckles are fully inserted into the central buckle until they click. Adjust straps for a snug fit.

If you encounter issues not listed here or if troubleshooting steps do not resolve the problem, please contact Chicco customer support.

8. Specifications

Feature	Detail
Product Dimensions	35.04 x 19.88 x 42.13 inches
Item Weight	16.15 pounds
Material Type	Steel (Frame), Polyester (Fabric)
Recommended Age/Weight	Birth up to 15 kg (approx. 3 years)
Height Adjustment Levels	7
Backrest Recline Positions	3
Portability	Yes (Compact Closure)
Color	dark grey

9. Warranty and Support

For detailed warranty information, please refer to the documentation included with your purchase or visit the official Chicco website. Warranty terms and conditions may vary by region.

For customer support, spare parts, or further assistance, please contact Chicco directly or visit their official brand store:

Visit the Chicco Store on Amazon

© 2025 Chicco. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHCWWKHY

More documents and user manuals: **https://manuals.plus/**