Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK RP515DP

Instruction Manual for LEXiBOOK Disney Princess Rapunzel Projector Radio Clock

Model: RP515DP | Brand: LEXiBOOK

1. Introduction

This manual provides detailed instructions for the safe and effective use of your LEXiBOOK Disney Princess Rapunzel Projector Radio Clock, model RP515DP. Please read this manual thoroughly before operating the device and retain it for future reference.



Figure 1: Front view of the LEXiBOOK Disney Princess Rapunzel Projector Radio Clock.

What's in the Box:

- 1 x LEXiBOOK Disney Princess Rapunzel Projector Radio Clock (RP515DP)
- 1 x Instruction Manual



Figure 2: Packaging of the product, showing the clock and its features.

2. Important Safety Information

Please observe the following safety precautions to prevent injury or damage to the device:

- **Warning! This product is not a toy.**
- **Warning! For indoor use only.**
- Do not expose the device to water or excessive moisture.
- Do not disassemble or attempt to repair the device yourself. Refer all servicing to qualified personnel.
- Keep the device away from direct heat sources and open flames.
- Ensure proper battery installation and disposal as per local regulations.

3. Setup

3.1 Battery Installation

The LEXiBOOK Disney Princess Rapunzel Projector Radio Clock requires **4 LR6/AA batteries** (not included) for operation.

1. Locate the battery compartment on the underside of the clock.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert 4 new LR6/AA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Note: Always use new batteries of the same type. Do not mix old and new batteries, or different types of batteries.

4. Operating Instructions

4.1 Setting the Time

The digital time display is shown on the LCD screen. To set the time:

1. Press and hold the **MODE** button until the hour digits begin to flash.
2. Use the **UP** or **DOWN** buttons to adjust the hour.
3. Press the **MODE** button again to switch to minute setting.
4. Use the **UP** or **DOWN** buttons to adjust the minutes.
5. Press the **MODE** button one more time to confirm and exit time setting mode.

4.2 Time Projection onto the Ceiling

To project the time onto your ceiling or wall:

- Press the **PROJECT** button located near the projector lens. The time will be projected.
- Adjust the angle of the projector lens to achieve the desired projection position.



Figure 3: Example of time projection onto a ceiling.

4.3 Princess Sound Effects

The clock features 4 amazing Princess sound effects.

- Press on Rapunzel's figurine located on the top of the clock to activate the sound effects. Each press will cycle through the available sounds.

4.4 Night Light Function

The clock includes a cosy night light feature.

- Press the base of the clock (the main pink platform) to switch on the night light.
- The night light will automatically turn off after approximately 15 minutes.

4.5 FM Radio

To use the built-in FM radio:

1. Press the **RADIO** button to turn on the FM radio.
2. Use the **UP** or **DOWN** buttons to tune to your desired radio station.
3. Adjust the volume using the **VOL** button and the **UP** or **DOWN** buttons.
4. Press the **RADIO** button again to turn off the radio.

4.6 Alarm with Snooze Function

To set and use the alarm:

1. Press the **MODE** button repeatedly until the alarm time is displayed (usually indicated by an alarm icon).
2. Press and hold the **MODE** button until the alarm hour digits flash.
3. Use the **UP** or **DOWN** buttons to set the alarm hour.
4. Press **MODE** again to set the alarm minutes using**UP** or **DOWN**.
5. Press **MODE** to confirm the alarm setting.
6. When the alarm sounds, press the**SNOOZE** button (often the same as the base press for night light or a dedicated button) to temporarily silence it. The alarm will sound again after a few minutes.
7. To turn off the alarm completely, press any other button or let it sound for its full duration.

5. Maintenance

5.1 Cleaning

To clean your clock, use a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the surface or internal components.

5.2 Battery Care

If the clock will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device. Dispose of used batteries responsibly according to local environmental regulations.

6. Troubleshooting

Problem	Possible Cause	Solution
Clock does not turn on.	Batteries are dead or incorrectly installed.	Replace with new LR6/AA batteries, ensuring correct polarity.
Time projection is dim or unclear.	Low battery power; too much ambient light.	Replace batteries. Ensure the room is dark for optimal projection.
Sound effects are not playing.	Low battery power; Rapunzel figurine not pressed correctly.	Replace batteries. Ensure a firm press on the figurine.
FM radio static or no signal.	Poor reception; not tuned correctly.	Try repositioning the clock. Retune the station using UP/DOWN buttons.
Alarm does not sound.	Alarm not set or activated.	Verify alarm time and ensure alarm function is enabled.

7. Specifications

Brand: LEXiBOOK

Model: RP515DP

Product Dimensions: 7.1 x 6.3 x 6.9 inches (18 x 16 x 17.5 cm)

Item Weight: 14.4 ounces (0.41 kg)

Power Source: 4 x LR6/AA batteries (not included)

Display Type: Digital LCD

Features: Time projection, FM radio, 15-minute night light, 4 Princess sound effects, alarm with snooze function.

Material: Plastic

Color: Pink/Purple

Recommended Age: 6 years and up

8. Warranty and Support

8.1 Warranty Information

This LEXiBOOK product is covered by a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects and faulty materials under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact your retailer or visit the official LEXiBOOK website for support contact information. You may also refer to the LEXiBOOK Store on Amazon for additional product information.

9. Product Overview Video

Watch this official product video for a visual guide to the features and operation of the LEXiBOOK Disney Princess Rapunzel Projector Radio Clock.

▶ **Watch video online**

Lexibook Disney Princess Rapunzel Projector Radio clock RP515DP

Video: An overview of the Lexibook Disney Princess Rapunzel Projector Radio Clock, demonstrating its various functions.

© 2024 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHG5T2P1

More documents and user manuals: **https://manuals.plus/**