Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK K8330

LEXiBOOK iParty Portable Bluetooth Speaker with Microphone K8330 User Manual

Model: K8330

1. Introduction

Thank you for purchasing the LEXiBOOK iParty Portable Bluetooth Speaker with Microphone, Model K8330. This device is designed to provide a versatile audio experience with wireless connectivity, multi-color light effects, and a microphone for karaoke. This manual provides essential information for safe operation, setup, and maintenance of your speaker.

2. Safety Information

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- **WARNING!** Not suitable for children under 3 years. Choking hazard - small parts.
- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble or attempt to repair the device yourself. Contact qualified service personnel.
- Use only the provided charging cable and power adapter (if included) to prevent damage.
- Keep the device away from water or other liquids.

3. Package Contents

Ensure all items are present in the package:

- 1 x LEXiBOOK iParty Portable Bluetooth Speaker (K8330)
- 1 x Microphone
- 1 x USB Type-C Charging Cable
- 1 x 3.5mm Aux-in Cable
- 1 x User Manual (this document)



Image: The LEXiBOOK iParty speaker, microphone, and cables displayed alongside its retail packaging.

4. Product Overview

Familiarize yourself with the speaker's components and controls.



Image: Front view of the LEXiBOOK iParty speaker, showing its two speaker grilles, the 'iParty' logo, and the included microphone and connecting cables.

Control Panel



Image: Close-up of the speaker's top control panel, featuring buttons for power, LED light control, mode selection, track navigation, and volume, along with ports for microphone, AUX, USB, TF card, and DC 5V charging.

1. **OFF/ON Switch:** Powers the speaker on or off.
2. **LED Button:** Controls the multi-color light effects (9 modes).
3. **PREV/VOL- Button:** Short press for previous track, long press to decrease volume.
4. **PLAY/PAUSE Button:** Plays or pauses audio.
5. **NEXT/VOL+ Button:** Short press for next track, long press to increase volume.
6. **MODE Button:** Switches between Bluetooth, AUX, USB, and Micro SD/TF card modes.
7. **MIC Input:** 3.5mm jack for connecting the included microphone.
8. **AUX Input:** 3.5mm jack for connecting external audio devices.
9. **USB Port:** For playing audio from a USB drive (up to 32GB).
10. **TF Card Slot:** For playing audio from a Micro SD/TF card (up to 32GB).
11. **DC 5V Port:** USB Type-C port for charging the speaker.

5. Setup

5.1 Initial Charging

Before first use, fully charge the speaker. Connect the USB Type-C charging cable to the DC 5V port on the speaker and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator will show the charging status.

5.2 Powering On/Off

Slide the OFF/ON switch to the 'ON' position to power on the speaker. Slide it to 'OFF' to power off.

6. Operating Instructions

6.1 Bluetooth Mode

1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), search for available Bluetooth devices.
3. Select "LEXiBOOK iParty" from the list.
4. Once paired, the speaker will emit a confirmation sound, and the LED light will stop flashing.
5. You can now play music from your device through the speaker.

6.2 AUX Mode

1. Connect one end of the 3.5mm aux-in cable to the AUX input on the speaker.
2. Connect the other end to the audio output of your external device.
3. Press the MODE button until the speaker enters AUX mode.
4. Play audio from your external device.

6.3 USB / Micro SD/TF Card Mode

1. Insert a USB drive or a Micro SD/TF card (up to 32GB) into the respective port/slot.
2. The speaker will automatically switch to USB or TF card mode and begin playing audio. If not, press the MODE button to select the correct mode.

6.4 Using the Microphone

1. Plug the included microphone into the MIC input jack on the speaker.
2. Adjust the microphone volume using the controls on the microphone itself or the speaker's main volume controls.
3. The microphone can be used in any audio playback mode (Bluetooth, AUX, USB, TF card).



Image: A group of people enjoying karaoke, with one person singing into the microphone connected to the LEXiBOOK iParty speaker, which displays its multi-color light effects.

6.5 True Wireless Stereo (TWS) Function

The TWS function allows you to pair two K8330 speakers together for a stereo sound experience (second speaker sold

separately).

1. Ensure both K8330 speakers are powered on and in Bluetooth mode, but not yet paired with any device.
2. On one of the speakers (this will be the primary speaker), long press the PLAY/PAUSE button until you hear a pairing tone.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation sound.
4. Now, connect your Bluetooth device to the primary speaker as described in section 6.1. Audio will play through both speakers in stereo.

6.6 Multi-color Light Effects

Press the LED button on the control panel to cycle through 9 different multi-color light modes. Press it again to turn off the lights.

▶ **Watch video online**
Lexibook, iParty Portable Bluetooth speaker microphone K8330

Video: A short demonstration of the LEXiBOOK iParty speaker, showcasing its multi-color light effects and the connection of the microphone for karaoke use.

7. Charging the Speaker

When the battery is low, the speaker will indicate this (e.g., via an audible prompt or flashing light). To charge:

1. Connect the provided USB Type-C cable to the DC 5V charging port on the speaker.
2. Connect the other end of the cable to a compatible USB power source (e.g., 5V/1A USB wall adapter, computer USB port).
3. The charging indicator will illuminate during charging and typically turn off or change color when fully charged.
4. A full charge takes approximately 3-4 hours.

8. Maintenance

To ensure the longevity of your speaker:

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use.
- Avoid exposing the speaker to dust, dirt, or sand.

9. Troubleshooting

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect to a power source and try again. Check the power switch position.
Cannot pair via Bluetooth.	Ensure the speaker is in Bluetooth mode and within range (approx. 10 meters). Turn off and on Bluetooth on your device. Forget the device from your Bluetooth list and try pairing again.
No sound from speaker.	Check volume levels on both the speaker and your connected device. Ensure the correct mode (Bluetooth, AUX, USB, TF) is selected. Check cable connections for AUX mode.
Microphone not working.	Ensure the microphone is securely plugged into the MIC input. Check the microphone's own power/volume switch if applicable.

Problem	Possible Solution
TWS pairing fails.	Ensure both speakers are K8330 models and are not connected to any other Bluetooth device. Try resetting both speakers and repeating the TWS pairing steps.

10. Specifications

Feature	Detail
Model Number	K8330
Connectivity Technology	Bluetooth
Audio Input	3.5mm AUX, USB, Micro SD/TF card
Power Source	Battery Powered
Battery Type	Product Specific (Rechargeable)
Product Dimensions (L x W x H)	6.9 x 6 x 14.6 inches (17.4 x 15.3 x 37 cm)
Item Weight	2.73 pounds (1.24 kg)
Material	Plastic
Special Features	Multi-color Light Effects, Microphone Input, True Wireless Stereo (TWS) Function
UPC	841874028710

11. Warranty and Support

This product is covered by a standard manufacturer's warranty. For warranty claims or technical support, please refer to the contact information provided on the product packaging or the official LEXiBOOK website. Keep your proof of purchase for warranty service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHH33SL4

More documents and user manuals: **https://manuals.plus/**