Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic NN-ST22QBYPQ

Panasonic NN-ST22QBYPQ 20L Solo Microwave Oven

Model: NN-ST22QBYPQ | **Brand:** Panasonic

1. Introduction

Thank you for purchasing the Panasonic NN-ST22QBYPQ 20L Solo Microwave Oven. This manual provides essential information for the safe and efficient operation of your appliance. Please read these instructions thoroughly before use and retain them for future reference.



Image 1.1: Front view of the Panasonic NN-ST22QBYPQ Microwave Oven.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, burns, or injury to persons.

- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Always ensure proper ventilation around the microwave.
- Do not heat liquids or other foods in sealed containers since they are liable to explode.
- Never use metal utensils or foil in the microwave, as this can cause arcing and damage the appliance.

3. Product Features

The Panasonic NN-ST22QBYPQ microwave oven is designed for convenience and efficiency in your kitchen. Key features include:

- **20L Solo Microwave:** Compact yet spacious for daily use.
- **10 Pre-programmed Auto Menus:** Simplifies cooking for various dishes.
- **Quick & Auto Defrost by Weight:** Efficiently thaws frozen foods.
- **Quick 30:** Convenient quick timer setting for instant heating.
- **5 Adjustable Power Levels:** Up to 800W for precise cooking control.
- **Compact Design:** Fits easily into any kitchen space.



Image 3.1: The microwave is designed for easy cooking and daily meal preparation.

4. Setup and Installation

4.1 Unpacking

Carefully remove the microwave oven and all packing materials from the carton. Ensure all components, including the glass tray, are present and undamaged.

4.2 Placement

Place the microwave oven on a flat, stable surface such as a countertop. Ensure there is adequate ventilation around the unit:

- Leave a minimum of 10 cm (4 inches) of space at the rear.
- Leave a minimum of 20 cm (8 inches) of space on the top.
- Leave a minimum of 5 cm (2 inches) of space on both sides.

Do not block any ventilation openings. Do not place the oven near heat sources like stoves or radiators.



Image 4.1: The compact design allows for flexible placement on kitchen countertops. Dimensions: 33D x 44.3W x 25.8H cm.

4.3 Power Connection

Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the microwave oven (240 Volts).

5. Operating Instructions

5.1 Setting the Clock

Upon first plug-in or after a power outage, the display will show '0:00'. To set the clock:

1. Press the **Timer/Clock** button once.
2. Use the **Up** and **Down** buttons to set the current hour.
3. Press the **Timer/Clock** button again.
4. Use the **Up** and **Down** buttons to set the current minutes.
5. Press the **Timer/Clock** button to confirm.

5.2 Basic Microwave Cooking

To cook food using microwave power:

1. Place food in a microwave-safe container on the glass tray.
2. Close the oven door securely.
3. Press the **Micro Power** button repeatedly to select the desired power level (e.g., High, Med-High, Medium, Med-Low, Low). The oven has 5 adjustable power levels up to 800W.
4. Use the **Up** and **Down** buttons to set the cooking time.
5. Press the **Start/Set** button to begin cooking.



Image 5.1: The microwave offers adjustable power levels to suit various cooking needs.

5.3 Auto Menus

The oven features 10 pre-programmed auto menus for common dishes. To use an auto menu:

1. Place food in a microwave-safe container.
2. Press the **Auto Menu** button repeatedly to select the desired menu number. Refer to the label inside the oven door for specific menu items.
3. Use the **Up** and **Down** buttons to adjust the weight or quantity if applicable.
4. Press the **Start/Set** button to begin.



Image 5.2: Utilize the automatic programs for a variety of dishes.

5.4 Defrosting

The microwave offers Quick & Auto Defrost by Weight for efficient thawing.

1. Place the frozen food on the glass tray.
2. Press the **Auto Defrost** button.
3. Use the **Up** and **Down** buttons to enter the weight of the food.
4. Press the **Start/Set** button. The oven will automatically calculate the defrosting time.



Image 5.3: Quickly and automatically defrost frozen items.

5.5 Quick 30 Function

For quick heating, use the Quick 30 function:

- Press the **Quick 30** button. Each press adds 30 seconds of cooking time at full power.
- Press **Start/Set** to begin, or simply press **Quick 30** multiple times to set the desired duration and it will start automatically.



Image 5.4: Use the Quick 30 function for fast and convenient heating.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave oven.

6.1 Exterior Cleaning

Wipe the exterior surface with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.

6.2 Interior Cleaning

Clean the interior cavity, door seals, and glass tray regularly. For stubborn food splatters, place a bowl of water with lemon slices inside and microwave for 2-3 minutes. The steam will loosen food particles, making them easier to wipe away. The glass tray can be removed and washed with warm, soapy water.

6.3 Turntable Care

Ensure the turntable and its support ring are clean and properly seated before operating the oven.

7. Troubleshooting

If you encounter issues with your microwave oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure plug is secure; Close door firmly; Check household fuse/circuit breaker.
Food not heating	Incorrect power level or cooking time set; Metal utensils used.	Adjust power/time; Remove all metal objects.

Problem	Possible Cause	Solution
Turntable not rotating	Turntable or support ring not correctly placed; Obstruction.	Reposition turntable/ring; Remove any obstructions.
Unusual noise during operation	Food container touching oven walls; Turntable not properly seated.	Ensure container clears walls; Re-seat turntable.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Specification
Brand	Panasonic
Model Name	NN-ST22QBYPQ
Capacity	20 Liters
Color	Black
Product Dimensions (D x W x H)	33D x 44.3W x 25.8H centimetres
Wattage (Output)	800 watts
Power Consumption	1250 Watts
Voltage	240 Volts
Material	Stainless Steel (exterior), Glass (inner material)
Controller Type	Touch
Number of Power Levels	5
Heating Method	Microwave Radiation
Defrost System Type	Auto Defrost
Included Components	Glass Tray
Item Weight	11 Kilograms

9. Warranty and Support

This Panasonic NN-ST22QBYPQ Microwave Oven comes with a**1 Year Manufacturer Warranty**.

For warranty claims, technical support, or service inquiries, please contact Panasonic customer service. Keep your purchase receipt as proof of purchase.

You can find more information and support on the official Panasonic website or by contacting their local service center.

© 2026 Panasonic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHK8DXG7

More documents and user manuals: **https://manuals.plus/**