Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome iBTW112

iHome iBTW112 Bluetooth Alarm Clock User Manual

Model: iBTW112

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your iHome iBTW112 Bluetooth Alarm Clock with Wireless Charger and USB Charging Station. Please read this manual thoroughly before using the device to ensure proper function and longevity.



Figure 1: iHome iBTW112 Bluetooth Alarm Clock with Wireless Charging

Setup

1. **Unpacking:** Carefully remove the iBTW112 unit and all accessories from the packaging. Ensure all components are present: the iBTW112 unit and AC power adapter.
2. **Power Connection:** Connect the supplied AC power adapter to the DC jack located on the back of the iBTW112 unit. Plug the other end of the adapter into a working wall outlet. The unit will power on and the display will illuminate.
3. **Battery Backup (Optional):** For backup of time and alarm settings during a power outage, install 2 AA batteries (not included) into the battery compartment on the bottom of the unit. Ensure correct polarity (+/-) as indicated.
4. **Initial Time Sync:** The clock time will automatically sync with your phone's time when a Bluetooth connection is established. For manual time setting, refer to the "Operating Instructions" section.

Operating Instructions

Time Setting

- **Automatic Time Sync:** When your smartphone is paired via Bluetooth, the iBTW112 will automatically synchronize its time with your phone's time. This ensures accurate time display.
- **Manual Time Adjustment:** To manually set the time, press and hold the Time Set button (refer to product diagram for button location). Use the +/- buttons to adjust the hours and minutes. Press the Time Set button again to confirm.

Alarm Setting

- **Setting the Alarm:** Press and hold the Alarm Set button. Use the +/- buttons to set the desired alarm time. Press the Alarm Set button again to confirm.
- **Alarm Source:** You can choose to wake to Bluetooth audio (if a device is connected and playing) or a built-in tone. Refer to the product's specific button functions for selecting the alarm source.
- **Snooze Function:** When the alarm sounds, press the Snooze button to temporarily silence the alarm for a set period. The alarm will sound again after the snooze duration.
- **Disabling the Alarm:** To turn off the alarm, press the Alarm On/Off button. The alarm icon on the display will disappear.

Wireless Charging

The iBTW112 features a wireless charging pad on its top surface. This pad is compatible with Qi-enabled devices, including many iPhone and Android smartphones.

1. Place your compatible device face up on the wireless charging pad.
2. Ensure the device is centered on the pad for optimal charging. A charging indicator (e.g., lightning bolt icon on the clock display or on your device) will appear when charging begins.
3. Remove any thick cases or metallic objects from your device, as these may interfere with wireless charging.



Figure 2: Using the Wireless Charging Pad

USB-C Charging

In addition to wireless charging, the iBTW112 includes a USB-C charging port on the back for charging other devices such as tablets, smartwatches, or non-Qi enabled phones.

- Connect one end of a USB-C charging cable (not included) to the USB-C port on the back of the iBTW112.
- Connect the other end of the cable to your device. Charging will begin automatically.



Figure 3: Utilizing the USB-C Charging Port

Bluetooth Speaker Function

The iBTW112 can stream audio wirelessly from your Bluetooth-enabled devices.

1. **Pairing:** Power on the iBTW112. Enable Bluetooth on your device (e.g., smartphone, tablet). Select "iHome iBTW112" from the list of available Bluetooth devices. A confirmation tone or message will indicate successful pairing.
2. **Streaming Audio:** Once paired, you can play audio from your device, and it will stream wirelessly through the iBTW112 speaker.
3. **Volume Control:** Adjust the volume using the volume buttons on the iBTW112 unit or directly from your paired Bluetooth device.



Figure 4: Bluetooth Audio Streaming

Display Dimmer

The display brightness can be adjusted to suit your preference, especially for bedroom use.

- Press the Dimmer button (refer to product diagram) repeatedly to cycle through different brightness levels (e.g., Max, High, Medium, Low, Off).

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. Do not use liquid cleaners or abrasive materials, as they may damage the finish.
- **Battery Replacement:** If the backup batteries are depleted, replace them with 2 new AA batteries. Ensure the unit is connected to AC power during battery replacement to avoid losing time and alarm settings.
- **Storage:** If storing the unit for an extended period, disconnect it from the power outlet and remove the backup batteries. Store in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Unit does not power on.	Power adapter not connected or outlet is not active.	Ensure the AC adapter is securely plugged into the unit and a working wall outlet. Test the outlet with another device.
Wireless charging is not working.	Device not Qi-compatible, not centered, or obstructed by a thick case/metal object.	Verify your device supports Qi wireless charging. Reposition the device on the pad. Remove any thick cases or metallic attachments.
USB-C charging is not working.	Cable is faulty or not properly connected.	Try a different USB-C cable. Ensure the cable is firmly inserted into both the unit and your device.
Bluetooth pairing fails or connection is unstable.	Device is too far, Bluetooth is off, or interference.	Ensure the unit and your device are within 100 feet. Turn Bluetooth off and on again on your device. Clear previous pairings on your device and try pairing again.
Alarm does not sound.	Alarm not set, volume too low, or alarm is disabled.	Verify the alarm time is set correctly and the alarm is enabled (alarm icon visible). Increase the volume.
Clock time is incorrect.	No Bluetooth sync or manual setting error.	Ensure your device is paired for automatic time sync. If manually setting, re-enter the correct time.

Specifications

Feature	Detail
Brand	iHome
Model Number	iBTW112
Display Type	Digital
Power Source	AC wall adapter (12VDC 2Amp)
Battery Backup	2 AA batteries (not included)
Product Dimensions	7.5"W x 2.7"H
Wireless Charging	Qi-compatible pad
USB Charging Port	USB-C
Bluetooth Range	Up to 100 feet
Special Features	Snooze, Bluetooth, Alarm, Charging Station, Auto Time Sync, Display Dimmer

Warranty Information

The iHome iBTW112 comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or visit the official iHome website. Keep your purchase receipt as proof of purchase for any warranty claims.

Support

For further assistance, technical support, or to view frequently asked questions, please visit the official iHome support website or contact their customer service. You can often find contact information and support resources on the manufacturer's website or within the product packaging.
You may also visit the iHome Brand Store on Amazon for additional product information and resources.

© 2025 iHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHW2MGMX

More documents and user manuals: **https://manuals.plus/**