Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK JG7440

Lexibook TV Game Console JG7440 User Manual

Model: JG7440

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Lexibook TV Game Console, model JG7440. Please read this manual thoroughly before use to ensure proper functionality and safety.

Important Safety Information

WARNING:

- Not suitable for children under 3 years due to small parts which may present a choking hazard.
- This toy produces flashes that may trigger epileptic seizures in sensitive individuals.

Always supervise children during play. Keep packaging materials away from children.

What's in the Box

Verify that all components are present:

- 1 x Lexibook TV Game Console (JG7440)
- 2 x Wireless Controllers
- 1 x TV Connector Cable
- 1 x Power Adapter
- 1 x Instruction Leaflet



Image: Contents of the Lexibook TV Game Console package, including the console, two wireless controllers, and connection cables.

Setup Guide

1. Console Overview



Image: The Lexibook TV Game Console and its two wireless controllers, showing the console's design and controller layout.

Familiarize yourself with the console and its ports. The console is designed for easy connection to your television.

2. Controller Battery Installation

Each wireless controller requires 2 AAA batteries (4 AAA batteries total, not included). To install:

1. Locate the battery compartment on the back of each controller.
2. Open the battery cover.
3. Insert 2 AAA batteries into each controller, observing the correct polarity (+/-).
4. Close the battery cover securely.



Image: Close-up of hands holding a Lexibook wireless controller, illustrating the button layout and ergonomic design.

3. Connecting to Your Television

The console connects to your TV using the provided TV connector cable. This model typically uses an AV (RCA) connection or HDMI, depending on the specific version. Refer to your TV's manual for port locations.

1. Connect one end of the TV connector cable to the corresponding port on the Lexibook console.
2. Connect the other end of the TV connector cable to the appropriate input ports on your television (e.g., yellow for video, red/white for audio for AV; or a single HDMI port for HDMI).
3. Connect the power adapter to the console's power input port.
4. Plug the power adapter into a wall outlet.
5. Turn on your television and select the correct input source (e.g., AV1, HDMI1) using your TV remote.

Operating Instructions

1. Powering On and Off

- To power on the console, ensure it is connected to power and your TV. The console should automatically power on when connected.
- To power off, disconnect the power adapter from the wall outlet.

2. Navigating Menus

Once powered on, the main menu will appear on your TV screen. Use the directional pad (D-pad) on your wireless controller to navigate through the game selections. Press the "Start" or "A" button to select a game.



Image: The Lexibook console displaying a selection of its 250 built-in games, including sports, arcade, and puzzle games.

3. Playing Games

The console includes 250 built-in games, featuring 30 interactive sports games and 220 mini-games and arcade classics. Many games support two players using the included wireless controllers.

- **Single Player:** Select a game from the menu and follow the on-screen instructions.
- **Multiplayer:** For games supporting two players, ensure both controllers are powered on and connected. Select a multiplayer game mode if available.



Image: Two children engaged in playing the Lexibook TV Game Console, demonstrating the multiplayer functionality with wireless controllers.



Image: A family enjoying the Lexibook TV Game Console, highlighting its appeal for shared entertainment.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the console and controllers. Do not use liquid cleaners or abrasive

materials.

- **Storage:** Store the console and accessories in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries from controllers if the console will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
No power to console.	Power adapter not connected or faulty outlet.	Ensure power adapter is securely plugged into console and a working wall outlet.
No image/sound on TV.	Incorrect TV input selected or loose cable connection.	Verify TV is on the correct input source (e.g., AV1, HDMI1). Check that the TV connector cable is securely plugged into both the console and the TV.
Controllers not responding.	Low or dead batteries, or not properly paired.	Replace controller batteries. Ensure controllers are within range of the console. Some models may require a pairing process (refer to leaflet if applicable).
Game freezes or crashes.	Temporary software glitch.	Turn off the console by unplugging it, wait a few seconds, then plug it back in and restart.

Specifications

- **Model:** JG7440
- **Brand:** LEXiBOOK
- **Product Dimensions:** 5.91"L x 1.38"W x 6.5"H
- **Item Weight:** 1.1 pounds (0.5 Kilograms)
- **Controller Type:** Push Button, Wireless
- **Power Source:** Battery Powered (controllers), AC Adapter (console)
- **Batteries Required:** 4 AAA batteries for controllers (not included)
- **Age Range (Description):** 6+ years (Manufacturer recommended: 3 years and up)
- **Material:** Plastic
- **Graphics:** 32-Bit
- **Built-in Games:** 250 (including 30 interactive sports games, 220 mini-games/arcade)

Warranty and Support

For warranty information and customer support, please refer to the included leaflet or contact Lexibook customer service directly. Keep your proof of purchase for warranty claims.
You can visit the official Lexibook website for further assistance:www.lexibook.com

© 2024 Lexibook. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHXPK27Z

More documents and user manuals: **https://manuals.plus/**