Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dpofirs Dpofirsg5p9ndy6mh-12

Dpofirs 4K Digital Camera User Manual

Model: Dpofirsg5p9ndy6mh-12

1. Safety Information

Please read all safety instructions carefully before using the Dpofirs 4K Digital Camera. Keep this manual for future reference.

- **Battery Safety:** Use only the specified battery type. Do not expose batteries to excessive heat, direct sunlight, or fire. Do not short-circuit or disassemble the battery. Keep batteries out of reach of children.
- **Water and Moisture:** This camera is not waterproof. Avoid exposing the camera to water, rain, or high humidity.
- **Temperature:** Operate the camera within the recommended temperature range (typically 0°C to 40°C / 32°F to 104°F). Avoid extreme hot or cold environments.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use harsh chemicals or solvents.
- **Disassembly:** Do not attempt to disassemble or repair the camera yourself. Refer all servicing to qualified personnel.

2. Package Contents

Verify that all items are present in your camera package:

- Dpofirs 4K Digital Camera (Brown)
- Rechargeable Battery
- USB Charging Cable
- Camera Strap
- Lens Cap
- Cleaning Cloth
- Storage Pouch
- User Manual (this document)



Image 2.1: The Dpofirs 4K Digital Camera shown with its complete set of accessories, including the camera body, battery, USB cable, strap, lens cap, cleaning cloth, and storage pouch.

3. Product Overview

Familiarize yourself with the main components and controls of your Dpofirs 4K Digital Camera.



Image 3.1: A detailed view of the Dpofirs 4K Digital Camera, highlighting its lens with 16X Powerful Zoom, Auto Focus, and F/2.2 f=3.37mm specifications, along with the flash and viewfinder.

Camera Components:

- **Lens:** Features 16X Powerful Zoom, Auto Focus, and F/2.2 f=3.37mm aperture.
- **Flash:** Provides illumination in low-light conditions.
- **Viewfinder:** For composing shots.
- **Shutter Button:** To capture photos.
- **Mode Dial:** Selects various shooting modes (Auto, Night Scene, Portrait, High Sensitivity).
- **Zoom Lever:** Controls the 16X digital zoom.
- **2.8-inch HD Screen:** For live view, menu navigation, and playback.
- **Navigation Buttons:** For menu control and settings adjustment.
- **Battery Compartment:** Located at the bottom for battery insertion.
- **USB Port:** For charging and data transfer.

4. Setup

4.1 Inserting the Battery

1. Open the battery compartment cover located at the bottom of the camera.
2. Insert the rechargeable battery according to the polarity indicators (+/-) inside the compartment.
3. Close the battery compartment cover securely.

4.2 Inserting a Memory Card

A memory card (not included) is required to store photos and videos.

1. Locate the memory card slot, usually next to the battery compartment.
2. Insert a compatible SD card into the slot with the metal contacts facing the correct direction until it clicks into place.
3. To remove, press the card gently until it springs out.

4.3 Charging the Battery

1. Connect the small end of the USB charging cable to the camera's USB port.
2. Connect the larger end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. It will turn off or change color when charging is complete.

4.4 Powering On/Off

Press and hold the Power button (usually located on the top or back of the camera) to turn the camera on or off.

5. Operating Instructions

5.1 Basic Photography (Auto Mode)

1. Turn on the camera.
2. Set the Mode Dial to 'Auto' for general shooting.
3. Frame your subject using the 2.8-inch screen or viewfinder.
4. Press the Shutter button halfway down to focus, then press it fully to capture the photo.

5.2 Using the Mode Dial

Rotate the Mode Dial on top of the camera to select different shooting modes:

- **Auto Mode:** For general point-and-shoot photography.
- **Night Scene:** Optimizes settings for low-light environments.
- **Portrait:** Enhances skin tones and blurs backgrounds for portraits.
- **High Sensitivity:** Improves performance in very dim conditions, potentially with increased image noise.
- **Video Mode:** For recording video.

5.3 Zoom Function

Use the Zoom Lever (often around the shutter button) to adjust the 16X digital zoom. Push the lever towards 'T' for telephoto (zoom in) and 'W' for wide-angle (zoom out).

5.4 Video Recording

1. Set the Mode Dial to Video Mode.
2. Press the Shutter button to start recording.
3. Press the Shutter button again to stop recording.

5.5 Self-Timer

Access the self-timer settings through the camera's menu. Options typically include 2-second, 5-second, and 10-second delays before capturing a photo.

5.6 Beauty Face Mode

This mode, accessible via the menu, automatically enhances facial features for smoother skin and improved appearance in portraits.

5.7 Webcam Function

Connect the camera to a computer using the USB cable. Select 'Webcam' mode on the camera (if prompted) to use it for video calls or streaming.

5.8 Viewing Photos and Videos

Press the Playback button (often indicated by a triangle icon) to enter playback mode. Use the navigation buttons to scroll through your captured media.

5.9 Transferring Files

Connect the camera to a computer using the USB cable. The camera should appear as a removable drive. You can then copy photos and videos to your computer.



Image 5.1: A collage demonstrating various photo styles achievable with the camera, including landscapes, portraits, and indoor scenes, possibly utilizing a 'Smart Creative Filter' feature.

6. Maintenance

6.1 Cleaning the Camera

- **Lens and Screen:** Use the provided cleaning cloth or a soft, lint-free cloth specifically designed for optics. Gently wipe in a circular motion. Avoid touching the lens or screen with your fingers.
- **Camera Body:** Wipe the camera body with a soft, dry cloth. Do not use liquid cleaners.

6.2 Battery Care

- Remove the battery if the camera will not be used for an extended period.
- Store batteries in a cool, dry place.
- Avoid fully discharging the battery frequently to prolong its lifespan.

6.3 Storage

When not in use, store the camera in its protective pouch in a dry, dust-free environment away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter issues with your camera, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Camera does not turn on.	Battery is depleted or incorrectly inserted. Ensure battery is charged and inserted correctly.
Photos are blurry.	Insufficient light, camera shake, or incorrect focus. Ensure good lighting, hold camera steady, and allow autofocus to engage. Check anti-shake setting.
Battery does not charge.	USB cable or power source issue. Try a different USB port or adapter. Ensure cable is securely connected.
Memory card error.	Card is full, corrupted, or incompatible. Try formatting the card (this will erase all data) or use a different compatible card.
Camera freezes.	Remove and reinsert the battery to reset the camera.

If the problem persists, please contact Dpofirs customer support.

8. Specifications

Feature	Specification
Model Number	Dpofirsg5p9ndy6mh-12
Image Resolution	48MP
Video Resolution	4K
Digital Zoom	16X
Screen Size	2.8 inch HD
Item Weight	1.02 pounds
Package Dimensions	6.69 x 5.51 x 1.57 inches
Manufacturer	Dpofirs

Feature	Specification
Date First Available	September 25, 2024

9. Warranty and Support

The Dpofirs 4K Digital Camera comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.
For technical support, troubleshooting assistance, or warranty claims, please contact Dpofirs customer service through the contact information provided on the product packaging or the official Dpofirs website.

© 2024 Dpofirs. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHY32TM7

More documents and user manuals: **https://manuals.plus/**