Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Milex 12L Air Fryer Oven

Milex 12L Air Fryer Oven With Rotisserie User Manual

1. Introduction

Thank you for choosing the Milex 12L Air Fryer Oven With Rotisserie. This appliance is designed to provide a versatile and efficient cooking experience, allowing you to air fry, roast, bake, and dehydrate with less oil. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.

2. Important Safety Instructions

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

- Adequate air circulation space should be maintained around the appliance.

3. Product Components

Familiarize yourself with the various parts of your Milex 12L Air Fryer Oven.



Image: Front view of the Milex 12L Air Fryer Oven, showcasing its digital control panel and the transparent viewing window.



Image: The Milex 12L Air Fryer Oven displayed alongside its essential accessories, including the rotisserie basket, drip tray, and two mesh trays.

What's in the Box:

- 1 x Air Fryer Oven with Rotisserie
- 1 x Rotisserie Basket
- 1 x Drip Tray
- 2 x Mesh Trays

4. Setup

1. **Unpacking:** Carefully remove all packaging materials and any promotional labels from the appliance.
2. **Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash all removable accessories (rotisserie basket, drip tray, mesh trays) with warm, soapy water. Rinse thoroughly and dry completely.
3. **Placement:** Place the air fryer oven on a stable, level, heat-resistant surface. Ensure there is at least 10-15 cm of clear space on all sides and above the appliance for proper ventilation. Do not place it directly against a wall or

under cabinets.

4. **Power Connection:** Ensure the power cord is securely plugged into a grounded electrical outlet.

5. Operating Instructions

5.1. Control Panel Overview

The Milex 12L Air Fryer Oven features an intuitive digital control panel for easy operation. The panel allows you to adjust temperature, cooking time, and select preset functions.

5.2. Basic Operation

1. **Power On:** Plug in the appliance. The display will illuminate.
2. **Preheating (Optional):** For best results, preheat the oven for 3-5 minutes at the desired cooking temperature.
3. **Loading Food:** Place food on the mesh trays, in the rotisserie basket, or on other suitable accessories. Do not overfill to allow for proper air circulation.
4. **Setting Temperature and Time:** Use the temperature and time adjustment buttons on the control panel to set your desired cooking parameters. The temperature range is typically between 80°C and 200°C, and the timer can be set up to 90 minutes.
5. **Start Cooking:** Press the Start/Pause button to begin the cooking cycle.
6. **Monitoring Progress:** Use the large viewing window to monitor your food without opening the door.
7. **Shaking/Turning Food:** For even cooking, some foods may require shaking or turning halfway through the cooking process.
8. **End of Cooking:** The appliance will beep when the cooking cycle is complete. Carefully remove food using heat-resistant tongs or oven mitts.

5.3. Preset Functions

The Milex Air Fryer Oven includes 8 preset cooking functions for common dishes. Select the desired preset icon on the control panel, and the appliance will automatically set the optimal temperature and time. These can be adjusted manually if needed.

5.4. Rotisserie Function

The built-in rotisserie function is ideal for roasting whole chickens or other meats, ensuring even cooking and a crispy exterior.



Image: The Milex 12L Air Fryer Oven with its door open, revealing a perfectly roasted whole chicken rotating on the internal rotisserie spit.



Image: A close-up view of the Milex 12L Air Fryer Oven's interior, showing a rotisserie basket actively cooking and browning french fries.

1. **Preparation:** Securely attach the food (e.g., a whole chicken) to the rotisserie spit. Ensure it is balanced and tied if necessary to prevent it from touching the heating elements.
2. **Installation:** Insert the rotisserie spit into the designated slots inside the oven.
3. **Activation:** Select the rotisserie function on the control panel. The spit will begin to rotate.
4. **Cooking:** Set the desired temperature and time, or use a relevant preset.
5. **Removal:** Use the rotisserie handle (if included) or heat-resistant mitts to carefully remove the hot rotisserie spit and food.

6. Cooking Guide

The Milex Air Fryer Oven is versatile for various cooking methods. Here are some general tips:

- **Oil Usage:** While air frying requires significantly less oil, a light spray or toss with oil can enhance crispiness and flavor for some foods.
- **Food Quantity:** Avoid overcrowding the cooking area. Cook in batches if necessary to ensure even air circulation and crisp results.
- **Temperature and Time:** Cooking times and temperatures may vary based on food type, quantity, and desired doneness. Always refer to a reliable recipe or food safety guidelines.
- **Frozen Foods:** Many frozen foods can be cooked directly in the air fryer. Adjust cooking time as needed.
- **Baking:** Use oven-safe bakeware that fits inside the appliance.

7. Cleaning and Maintenance

Regular cleaning ensures the longevity and optimal performance of your Milex Air Fryer Oven.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
3. **Interior:** Wipe the interior with a damp cloth and mild detergent. For stubborn food residue, a non-abrasive sponge can be used. Ensure the interior is dry before next use.
4. **Accessories:** The rotisserie basket, drip tray, and mesh trays should be washed with warm, soapy water. Rinse thoroughly and dry completely. While the main unit is not dishwasher safe, these accessories are designed for easy cleaning.
5. **Heating Element:** Gently clean the heating element with a soft brush to remove any food particles.
6. **Storage:** Store the appliance in a cool, dry place once it is clean and dry.

8. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; Power outlet malfunction; Appliance malfunction	Ensure power cord is securely plugged in; Try a different outlet; Contact customer support if issue persists.
Food not cooked evenly	Overcrowding; Incorrect temperature/time; Food not shaken/turned	Cook in smaller batches; Adjust temperature/time settings; Shake or turn food halfway through cooking.
White smoke coming from appliance	Grease/oil residue; Fatty food cooking	Clean the appliance and accessories thoroughly; Ensure drip tray is in place for fatty foods.
Rotisserie not rotating	Food too heavy/unbalanced; Rotisserie not properly installed	Ensure food is balanced and not exceeding weight limit; Re-install rotisserie spit correctly.

9. Specifications

- **Brand:** Milex
- **Model:** 12L Air Fryer Oven With Rotisserie
- **Capacity:** 12 Liters
- **Power:** 1500 Watts
- **Voltage:** 220-240V, 50Hz
- **Colour:** Silver
- **Special Features:** Temperature Control, Built-in Rotisserie, Large Viewing Window
- **Item Weight:** 8.56 kg
- **Product Dimensions:** 38D x 43W x 38H centimetres

10. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact Milex customer service. Keep your proof of purchase for any warranty claims.
Customer Service: Please visit the official Milex website or contact your retailer for support.

© 2024 Milex. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHZNC49B

More documents and user manuals: **https://manuals.plus/**