Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PROSCAN PLED3274

PROSCAN PLED3274 32 inch Class 720p HD LED TV User Manual

Model: PLED3274

1. Introduction

This manual provides essential information for the safe and efficient operation of your PROSCAN PLED3274 32 inch Class 720p HD LED TV. Please read this manual thoroughly before using the television and retain it for future reference. Proper installation, setup, and maintenance will ensure optimal performance and longevity of your device.

2. Important Safety Information

Observe the following safety precautions to prevent damage and ensure safe operation:

- **Power Source:** Connect the TV only to a 110 VAC, 60 Hz power supply.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block ventilation openings.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Heat Sources:** Keep the TV away from radiators, heat registers, stoves, or other heat-producing appliances.
- **Cleaning:** Unplug the TV from the wall outlet before cleaning. Use a soft, dry cloth.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Mounting:** Use appropriate mounting hardware for table or wall mounting. Ensure the mounting surface can support the TV's weight.

3. Package Contents

Please check that all items are present:

- PROSCAN PLED3274 32 inch Class 720p HD LED TV
- Remote Control
- TV Stand (2 pieces)
- Screws for TV Stand
- Power Cord

- User Manual (this document)

4. Setup

4.1 Unpacking

Carefully remove the TV from its packaging. It is recommended to keep the original packaging for future transport or servicing needs.

4.2 Attaching the Stand

If you are placing the TV on a table, attach the included stand feet:

1. Place the TV face down on a soft, flat surface to prevent screen damage.
2. Align each stand foot with the corresponding slots on the bottom of the TV.
3. Secure each stand foot with the provided screws. Ensure they are tightened firmly.



This image shows the PROSCAN PLED3274 32 inch Class 720p HD LED TV from the front, featuring a black bezel and two black stand feet. The screen displays a vibrant image of a surfer riding a large blue wave, with a clear blue sky and distant land in the background. The PROSCAN logo is visible on the bottom center bezel.

4.3 Wall Mounting

For wall mounting, the TV supports a VESA Mount Standard of 100 x 100 mm. Wall mount hardware is not included. Please consult a professional for wall mounting installation to ensure safety and proper setup.

4.4 Connecting Peripherals

Connect your external devices to the TV using the appropriate ports:

- **HDMI:** For high-definition video and audio from devices like Blu-ray players, gaming consoles, or cable/satellite boxes. The TV has HDMI audio input.
- **Antenna/Cable:** Connect an antenna or cable TV feed for over-the-air or cable channels. The TV supports ATSC/DVB signal formats.
- **USB:** For connecting USB storage devices to play media files (if supported by the TV's firmware).

4.5 Initial Power On

After connecting all desired devices and the power cord, plug the TV into a wall outlet. Press the power button on the remote control or on the TV itself to turn it on. Follow the on-screen instructions for initial setup, including language selection and channel scanning.

5. Operating the TV

5.1 Remote Control Overview

The TV is primarily controlled via the included remote control. Familiarize yourself with the buttons for power, volume, channel, input selection, and menu navigation.

5.2 Basic Functions

- **Power:** Press the **POWER** button to turn the TV on or off.
- **Volume:** Use the **VOL +/-** buttons to adjust the sound level.
- **Channel:** Use the **CH +/-** buttons to change channels.
- **Mute:** Press the **MUTE** button to temporarily silence the sound.

5.3 Menu Navigation

Press the **MENU** button to access the on-screen display (OSD) menu. Use the arrow buttons (**UP**/**DOWN**/**LEFT**/**RIGHT**) to navigate through options and the **OK**/**ENTER** button to confirm selections. Press **EXIT**/**BACK** to return to the previous menu or exit the OSD.

5.4 Input Source Selection

Press the **INPUT**/**SOURCE** button on the remote to cycle through available input sources (e.g., HDMI1, HDMI2, TV, AV). Select the desired input for your connected device.

5.5 Picture and Sound Settings

Within the OSD menu, you can adjust various settings:

- **Picture:** Adjust brightness, contrast, color, sharpness, and select picture modes (e.g., Standard, Dynamic, Movie).
- **Sound:** Adjust bass, treble, balance, and select sound modes (e.g., Standard, Music, Movie). The TV features a 2.0 surround sound channel configuration.

5.6 Channel Scan

If you are using an antenna or cable connection, you will need to perform a channel scan to find available channels. Navigate to the 'Channel' or 'Setup' menu and select 'Auto Scan' or 'Auto Tuning'.

6. Maintenance

6.1 Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner (ensure it is safe for LED screens) and wipe gently. Do not spray liquid directly onto the screen.

6.2 Cleaning the Cabinet

Wipe the TV cabinet with a soft, dry cloth. Avoid using abrasive cleaners or solvents.

6.3 Storage

If storing the TV for an extended period, unplug it from the power outlet and cover it to protect against dust. Store in a cool, dry place.

7. Troubleshooting

Before contacting support, try the following solutions for common issues:

- **No Power:** Ensure the power cord is securely plugged into both the TV and the wall outlet. Check if the outlet is working by plugging in another device.
- **No Picture/Sound:** Verify the correct input source is selected. Check all cable connections (HDMI, antenna). Ensure the volume is not muted or set to zero.
- **Remote Control Not Working:** Check the batteries in the remote control and replace them if necessary. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Poor Picture Quality:** Check antenna/cable connections. Adjust picture settings in the OSD menu. If using an external device, check its output resolution.
- **No Channels Found:** Perform an auto channel scan. Ensure your antenna is properly connected and positioned.

8. Specifications

Feature	Specification
Brand	PROSCAN
Model	PLED3274
Aspect Ratio	16:9
Mounting Type	Table Mount, Wall Mount
Audio Input	HDMI
Signal Format	HDMI, ATSC/DVB
Warranty Type	Limited
Surround Sound Channel Configuration	2.0
Control Method	Remote
Line Voltage	110 VAC 60 Hz
VESA Mount Standard	100 x 100 mm

9. Warranty and Support

9.1 Limited Warranty

This PROSCAN TV comes with a limited warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration. The warranty typically covers manufacturing defects under normal use.

9.2 Customer Support

If you encounter issues that cannot be resolved using the troubleshooting guide, or if you require further assistance, please contact PROSCAN customer support. Contact information can usually be found on the PROSCAN website or on the warranty card.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK4BG398

More documents and user manuals: **https://manuals.plus/**