Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Workzone 1

Workzone Electronic Digital Home Safe User Manual

Model: 1

1. Introduction

Thank you for choosing the Workzone Electronic Digital Home Safe. This manual provides essential information for the safe and efficient operation of your new safe. Please read these instructions carefully before installation and use, and retain them for future reference.
This safe is designed to protect your valuables, such as documents, jewelry, and other important items, from unauthorized access. Its robust steel construction and programmable digital keypad offer reliable security for your home or office.

2. Safety Information

- Do not store the emergency keys inside the safe. Keep them in a secure, separate location.
- Ensure the safe is securely mounted to a wall or floor to prevent removal.
- Keep the safe locked when not in use.
- Do not expose the safe to extreme temperatures or humidity.
- Replace batteries promptly when the low battery indicator appears to ensure continuous operation.

3. Package Contents

Please check the package for the following items:

- 1 x Workzone Electronic Digital Home Safe
- 2 x Emergency Opening Keys
- 2 x AA Batteries
- 2 x Fixing Bolts (for mounting)
- Mounting Material (screws, anchors)
- User Manual

4. Product Overview

The Workzone Electronic Digital Home Safe features a robust alloy steel construction and a user-friendly digital keypad. It is designed for secure storage in various environments.



Image 1: Interior view of the Workzone Electronic Digital Home Safe, showing a camera and watch stored inside. The door is open, revealing the locking mechanism and keypad on the inside of the door.



Image 2: Exterior view of the Workzone Electronic Digital Home Safe, highlighting its dimensions: 31 cm length, 20 cm width, and 20 cm height. The digital keypad is visible on the front panel.

Key Features:

- **Robust Steel Construction:** Made from high-quality alloy steel for enhanced security.
- **Programmable Digital Keypad:** Offers up to 1000 different code combinations for personalized security.
- **Emergency Key Access:** Two emergency keys are provided for manual override in case of forgotten code or battery failure.
- **Pre-drilled Anchor Points:** Allows for secure mounting to walls or floors.
- **Compact Design:** Ideal for discreet placement in homes, offices, or hotels.

5. Setup and Installation

5.1. Battery Installation

1. Open the safe door using the emergency key (refer to section 6.3 if needed).
2. Locate the battery compartment on the inside of the safe door.
3. Insert the 2 AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover.
5. The safe is now powered and ready for code programming.

5.2. Mounting the Safe

The safe can be securely mounted to a wall or floor using the pre-drilled anchor points and included mounting hardware.

1. Choose a suitable location for the safe, ensuring it is a solid surface (e.g., concrete wall, wooden stud, or floor).

2. With the safe door open, mark the positions of the pre-drilled holes on the wall or floor.
3. Drill pilot holes at the marked positions using an appropriate drill bit for your surface type.
4. Align the safe with the drilled holes and insert the fixing bolts through the safe's anchor points.
5. Securely tighten the bolts using the provided mounting material. Ensure the safe is firmly attached and does not wobble.

6. Operating Instructions

6.1. Setting Your Personal Code

It is recommended to set a new personal code immediately after battery installation.

1. With the safe door open, press the red reset button located on the inside of the door, near the hinge. You will hear a beep, and the yellow indicator light will illuminate.
2. Within 5 seconds, enter your desired personal code (3 to 8 digits) on the keypad.
3. Press the "#" button to confirm your code. You will hear a confirmation beep, and the yellow light will turn off.
4. Test your new code with the door open before closing it. Enter your code, then press "#". The green light should illuminate, and you should be able to turn the knob to open.

6.2. Opening the Safe with Your Code

1. Enter your personal code on the keypad.
2. Press the "#" button. The green light will illuminate.
3. Within 5 seconds, turn the knob clockwise to open the safe door.

6.3. Using the Emergency Key

The emergency key provides manual access to the safe in case of forgotten code, battery failure, or electronic malfunction.

1. Locate the emergency keyhole, usually hidden behind a small cover on the keypad panel.
2. Remove the cover.
3. Insert the emergency key into the keyhole and turn it counter-clockwise.
4. While holding the key turned, rotate the main knob clockwise to open the safe door.
5. Once open, remove the emergency key and replace the cover.

Important: Do not store the emergency keys inside the safe.

7. Maintenance

- **Cleaning:** Wipe the safe's exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** When the red "LOW BATTERY" indicator light illuminates, replace the batteries promptly. Use 2 new AA batteries.
- **Lock Mechanism:** Periodically check the locking bolts for smooth operation. Do not lubricate the electronic components.

8. Troubleshooting

Problem	Possible Cause	Solution
Safe does not open with code.	Incorrect code entered. Batteries are low or dead. Code not confirmed with "#".	Re-enter code carefully. Replace batteries. Ensure "#" is pressed after code.
Keypad does not respond.	Batteries are dead or incorrectly installed.	Replace batteries, checking polarity.
Red "LOW BATTERY" light is on.	Batteries are low.	Replace all 2 AA batteries immediately.
Cannot set a new code.	Reset button not pressed correctly. Code not entered within 5 seconds.	Ensure the red reset button is pressed firmly. Enter code and "#" quickly after pressing reset.
Safe door does not close properly.	Obstruction in the door frame. Locking bolts are extended.	Check for any items blocking the door. Ensure the knob is turned to retract bolts before closing.

9. Specifications

Model Number:	1
Brand:	Workzone
Exterior Dimensions (L x W x H):	31.0 x 20.0 x 20.0 cm (approx.)
Interior Dimensions (L x W x H):	30.8 x 14.0 x 19.8 cm (approx.)
Weight:	4.1 kg
Capacity:	8.5 Liters
Material:	Alloy Steel
Lock Type:	Electronic, Key
Power Source:	2 x AA Batteries (included)
Mounting Type:	Wall Mountable
Special Features:	Anti-theft, Programmable Combination Lock (3-8 digits, 1000 combinations)

10. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK5MNVZC

More documents and user manuals: **https://manuals.plus/**