Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vibekio ZX-SS20E-X-fba

Vibekio 20V 12.2-Inch Cordless Snow Shovel

Model: ZX-SS20E-X-fba

Introduction

This manual provides essential instructions for the safe operation, assembly, maintenance, and troubleshooting of your Vibekio 20V 12.2-Inch Cordless Snow Shovel. Please read this manual thoroughly before first use and retain it for future reference.


20V
Lithium-ion 20V
Lithium-ion 20V

Image: The Vibekio 20V 12.2-Inch Cordless Snow Shovel, including the main unit, 20V lithium-ion battery, and quick charger.

Important Safety Instructions

To reduce the risk of injury, always follow these safety precautions:

- Always keep hands and other body parts away from moving parts.
- Wear appropriate safety gear, including gloves and eye protection, during operation.
- Store the snow shovel and battery pack in a cool, dry place when not in use.
- Always follow the manufacturer's instructions for operation and maintenance.
- Ensure the dual-safety start button is engaged correctly to prevent accidental startups.

Package Contents

Verify that all items are present and in good condition upon unpacking:

- Vibekio Cordless Snow Shovel Main Unit
- 20V Lithium-ion Battery Pack (4.0 Ah)
- Quick Charger
- Adjustable Handle
- Instruction Manual



Image: An illustration showing the Vibekio Cordless Snow Shovel, battery, charger, and instruction manual as included in the product packaging.

Assembly and Setup

1. Handle Assembly

The snow shovel features a 2-step quick assembly for the handle. Align the handle sections and secure them firmly. Ensure all connections are tight before use.



Image: Visual guide for the two-step quick assembly of the snow shovel's handle.

The handle is ergonomically designed and adjustable to reduce strain during operation. Adjust it to a comfortable height for your use.



Image: Close-up of the ergonomic adjustable handle, highlighting its design for user comfort.

2. Battery Charging and Installation

Before first use, fully charge the 20V Lithium-ion battery pack using the included quick charger. Insert the charged battery into the designated slot on the snow shovel handle until it clicks securely into place.



Image: Diagram detailing the internal structure and safety features of the 20V Lithium-ion battery, including overheat, over-voltage, and short-circuit protection.

Operation

1. Starting the Snow Shovel

To start the snow shovel, press the safety button (Step 1) and then hold the On/Off trigger (Step 2). Release the trigger to stop the unit.



Image: Instructions for the two-step safe start mechanism, indicating the safety button and On/Off trigger.

2. Clearing Snow

The Vibekio Cordless Snow Shovel is designed to clear a path 12.2 inches wide and up to 6 inches deep, throwing snow up to 17 feet. For optimal performance, push the shovel steadily through the snow.



Image: A visual representation of the snow shovel's 12-inch wide and 6-inch deep clearing capability.



Image: A user demonstrating the snow shovel's power, clearing snow and throwing it a significant distance.

3. Adjustable Directional Plate

Utilize the adjustable directional plate to control the direction of snow discharge. This allows for precise clearing and prevents snow from being thrown into unwanted areas.



Image: Illustration of the adjustable directional plate, indicating its range of motion for controlling snow discharge.

Maintenance

- **Cleaning:** After each use, ensure the unit is turned off and the battery is removed. Clean any snow or debris from the auger and housing using a damp cloth. Do not use harsh chemicals.
- **Storage:** Store the snow shovel in a cool, dry place. Its compact design allows for easy storage in tight spaces.
- **Battery Care:** Store the battery in a charged state. Avoid storing fully discharged batteries for extended periods.



Image: The snow shovel stored compactly, illustrating its space-saving design.

Troubleshooting

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Unit does not start	Battery not charged or improperly installed. Safety button not pressed.	Ensure battery is fully charged and securely inserted. Press the safety button before engaging the trigger.
Reduced snow throwing distance	Wet, heavy snow. Excessive snow depth.	Clear smaller sections at a time. For wet snow, proceed at a slower pace.

Problem	Possible Cause	Solution
Unit stops during operation	Battery depleted. Overload protection activated.	Recharge the battery. Reduce the load by clearing less snow per pass.

Product Specifications

Feature	Detail
Brand	Vibekio
Model Number	ZX-SS20E-X-fba
Power Source	20V Lithium-ion Battery
Battery Capacity	4.0 Ah
Clearing Width	12.2 inches
Clearing Depth	Up to 6 inches
Max Snow Throwing Distance	17 feet
Item Weight	12.92 pounds (5.87 kg)
Product Dimensions (L x W x H)	10 x 8.99 x 52 inches
Material	Metal (Blade), Plastic (Handle)
Color	Green and Black

Warranty and Customer Support

For warranty information, technical assistance, or customer support, please refer to the contact details provided with your product packaging or visit the official Vibekio website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2025 Vibekio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DKH2NJFG

More documents and user manuals: **https://manuals.plus/**