Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ForeverPRO WR02X13685

ForeverPRO WR02X13685 Wheel for GE Refrigerator Instruction Manual

Introduction

This instruction manual provides essential information for the installation, maintenance, and compatibility of the ForeverPRO WR02X13685 Refrigerator Wheel. This product is designed as a replacement part for specific GE refrigerator models.

Product Overview

The ForeverPRO WR02X13685 Refrigerator Wheel is a high-quality replacement component engineered to meet or exceed original equipment manufacturer (OEM) specifications. It is designed to restore the mobility and stability of your compatible GE refrigerator.



Image showing the ForeverPRO WR02X13685 replacement wheel for GE refrigerators.

Compatibility

This ForeverPRO WR02X13685 Refrigerator Wheel is compatible with various GE refrigerator models. Please verify your refrigerator's model number against the list below to ensure proper fitment. This part is also compatible with certain General Electric, Hotpoint, RCA, and Sears/Kenmore appliance models that use the WR02X13685 wheel.
Compatible GE Refrigerator Models include:

- CFE28TP2MBS1
- CFE28TP2MCS1
- CFE28TP2MDS1
- CFE28TP2MES1
- CFE28TP2MFS1
- CFE28TP2MGS1
- CFE28TP2MHS1

- CFE28TP2MIS1
- CFE28TP2MJS1
- CFE28TP2MKS1
- CFE28TP2MLS1
- CFE28TP3MBD1
- CFE28TP3MBW2
- CFE28TP3MCD1
- CFE28TP3MDD1
- CFE28TP3MED1
- CFE28TP3MFD1
- CFE28TP3MGD1
- CFE28TP3MHD1
- CFE28TP3MID1
- CFE28TP3MJD1
- CFE28TP3MKD1
- CFE28TP3MLD1
- CFE28TP4MBW2
- CFE28TP4MCW2
- CFE28TP4MDW2
- CFE28TP4MEW2
- CFE28TP4MFW2
- CFE28TP4MGW2
- CFE28TP4MHW2
- CFE28TP4MIW2
- CFE28TP4MJW2

Installation (Setup)

Replacing a refrigerator wheel typically involves lifting the appliance and securing the new wheel. Due to variations in refrigerator designs, it is highly recommended to consult your specific GE refrigerator's original service manual for detailed, model-specific instructions before proceeding with installation.

1. **Safety First:** Always unplug the refrigerator from its power source before attempting any repairs or installations to prevent electrical shock.
2. **Access the Wheel:** Depending on your refrigerator model, you may need to tilt the appliance backward or forward to access the wheels. It is advisable to have assistance when moving or tilting a refrigerator to prevent injury or damage.
3. **Remove Old Wheel:** Carefully remove the old or damaged wheel. This may involve unscrewing bolts or releasing clips. Note the orientation and attachment method of the old wheel.
4. **Install New Wheel:** Position the ForeverPRO WR02X13685 wheel in the same manner as the old one. Secure it firmly using the appropriate fasteners. Ensure it is properly seated and aligned.
5. **Test Stability:** Gently lower the refrigerator and check its stability. Ensure all wheels are making proper contact with the floor and the appliance moves smoothly.
6. **Reconnect Power:** Once the installation is complete and the refrigerator is stable, plug it back into the power source.

Maintenance

To ensure the longevity and smooth operation of your refrigerator wheels, consider the following maintenance tips:

- **Regular Cleaning:** Periodically clean any dust, debris, or food particles that may accumulate around the wheels. This can prevent obstructions and ensure smooth movement.
- **Check for Wear:** Inspect the wheels occasionally for signs of wear, cracks, or damage. Replace the wheel if significant wear is observed to maintain proper appliance stability and mobility.
- **Avoid Overloading:** Ensure the refrigerator is not excessively overloaded, as this can put undue stress on the wheels and potentially lead to premature wear.

Troubleshooting

If you encounter issues after installing the new refrigerator wheel, consider these common troubleshooting steps:

- **Refrigerator Not Moving Smoothly:**
  - Check for debris caught in the wheel mechanism.
  - Ensure the wheel is properly seated and secured.
  - Verify that the floor surface is clean and level.
- **Refrigerator Wobbles or is Unstable:**
  - Confirm that all wheels are installed correctly and making firm contact with the floor.
  - Check if the refrigerator's leveling feet (if applicable) are properly adjusted.
  - Inspect for any damage to the wheel or its mounting point.
- **Unusual Noise from Wheel:**
  - Clean the wheel and its axle to remove any foreign objects.
  - Ensure the wheel is not rubbing against any part of the refrigerator frame.

If problems persist, consult a qualified appliance technician or contact ForeverPRO customer support.

Specifications

Manufacturer	ForeverPRO
Brand	ForeverPRO
Model Number	WR02X13685
Item Weight	8 ounces
Product Dimensions	9 x 6 x 4 inches
UPC	197771504278
OEM Part Number	WR02X13685

Warranty and Support

ForeverPRO is a USA-based company committed to providing durable, OEM-specification parts. For specific warranty information regarding the WR02X13685 Refrigerator Wheel, please refer to the documentation included with your purchase or contact ForeverPRO directly through their official website or customer service channels. For technical

assistance or inquiries, please reach out to ForeverPRO customer support.

This manual is for informational purposes only. Always prioritize safety and consult professional assistance if unsure about any repair procedures.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DL3TKRRL

More documents and user manuals: **https://manuals.plus/**