Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

eufy T2070

eufy Robot Vacuum 3-in-1 E20 Instruction Manual

Model: T2070

Introduction

The eufy Robot Vacuum 3-in-1 E20 is a revolutionary cleaning solution designed for modern homes. It combines the convenience of a robotic vacuum with the versatility of a handheld and stick vacuum, offering comprehensive cleaning for various scenarios. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

Figure 1: The eufy FlexiONE Combo Vacuum in action, demonstrating its versatile 3-in-1 functionality.

Key features include powerful suction capabilities, a self-emptying station for up to 75 days of hands-free cleaning, and advanced filtration for a healthier environment. Its smart navigation and obstacle avoidance ensure efficient and thorough cleaning across different floor types and around household items.

Setup

Before first use, ensure all packaging materials are removed from the robot vacuum and the self-empty station. Place the self-empty station on a hard, flat surface against a wall, ensuring there are no obstacles within 1.5 meters (4.9 ft) in front and 0.5 meters (1.6 ft) on either side for optimal docking and emptying.



Figure 2: Recommended placement and clearance for the self-empty station.

Connect the power cord to the self-empty station and plug it into a wall outlet. The station's light will turn white when properly connected. Fully charge the robot vacuum before its initial use. A full charge takes approximately 2.5 hours.

Download the 'eufy Clean' app from your smartphone's app store. Follow the in-app instructions to connect your robot vacuum to your home Wi-Fi network and complete the initial mapping of your home. This mapping process allows the robot to efficiently navigate and clean your space.

Operating Modes & Features

The eufy E20 offers three primary operating modes:

- **Robot Vacuum Mode:** For automated, hands-free cleaning of large areas. The robot uses Triple-LineLaser Obstacle Avoidance for precise navigation and detects obstacles as small as 15mm.
- **Stick Vacuum Mode:** Detach the main unit and attach the extension tube and floor brush cleaner head for upright vacuuming. Ideal for floors and carpets.
- **Handheld Vacuum Mode:** Detach the main unit and attach the 2-in-1 combination tool or crevice tool for targeted cleaning of furniture, stairs, and tight spaces.



Figure 3: The eufy E20 adapting to various cleaning needs.

Suction Power: The handheld mode provides up to 30,000 Pa of suction, while the robot vacuum mode offers 8,000 Pa. Adjust suction levels (ECO, Standard, Turbo, Maximum) via the eufy Clean app.

AeroTurbo Five-Stage Filtration: This advanced system captures 99.97% of particles as small as 0.3 microns, ensuring cleaner air. It includes a main cyclone, stainless steel mesh filtration, five cyclone structures, a high-precision filtration sponge, and a high-performance filter.



Figure 4: Breakdown of the AeroTurbo Five-Stage Filtration System.

App Control & Voice Commands: Use the eufy Clean app for customized cleaning modes, scheduling, setting no-go zones, carpet editing, multi-level mapping, and quick mapping. The E20 is compatible with Amazon Alexa and Google Assistant for convenient voice control.

Maintenance

Regular maintenance ensures your eufy E20 operates efficiently.

- **Self-Emptying:** The 3L dust bag in the self-empty station can hold debris for up to 75 days, depending on usage. All three vacuum modes automatically empty into the station.
- **Pro-Detangle Comb:** The robot vacuum features a Pro-Detangle Comb that automatically rotates in reverse to keep the brush clean and tangle-free.
- **Filter Cleaning:** Regularly clean and replace the filters as needed to maintain optimal suction power and air quality.



Figure 5: The self-empty station provides up to 75 days of maintenance-free operation.



Figure 6: The Pro-Detangle Comb ensures the brush remains tangle-free.

Troubleshooting

For common issues, refer to the following Q&A:

Q: What Should I Do Before Using the 3-in-1 E20 to Ensure Optimal Cleaning Performance?

A: Suction Adjustment: Use Turbo or Max mode and set a 15-minute self-emptying frequency in the eufy Clean App, especially for homes with pets or children. Cleaning Frequency: For heavy debris or pet hair, select the target area and schedule a double clean via the app. Carpet Cleaning: On first use, go to Map > Carpet Edit in the app to mark carpeted areas for improved cleaning. Use Additional Tools: Use the cordless stick vacuum with the dusting/crevice or 2-in-1 combination tool to clean wall edges, corners, and sofas. Use the floor brush head tool to clean under furniture and carpets where the robot cannot reach. Accessories Maintenance: Regularly clean and replace the robot's accessories to maintain optimal performance.

Q: How to Ensure the Self-Emptying Feature of the 3-in-1 E20 Works Correctly?

A: Base Station Placement: Place the base station on a hard, flat surface with the dock assist mat underneath. Ensure the robot can return smoothly to the base. Power Connection: Verify that the base station is plugged in. When properly connected, the station's light should turn white. For Pet Owners: Set the self-emptying frequency to 15-minute intervals to handle pet hair more effectively. Manual Self-Emptying: Use the eufy Clean App to trigger manual self-emptying. Noise Advisory: The self-emptying process can be noisy. To avoid disturbances during sleep, activate the Do Not Disturb option in the app.

Q: What Should I Do to Optimize the Performance of 3-in-1 E20 Robot Vacuum?

A: The 3-in-1 E20 uses laser radar and front/side sensors to identify obstacles and carpets for efficient navigation. Follow these tips to avoid interruptions: Clear the Floor: Remove objects like wires, toys, socks, and clothes to prevent the vacuum from getting stuck. Secure Carpet Edges: Fix the edges of thin carpets to avoid tangling or folding. Set No-Go Zones: Use the app to create no-go zones for furniture shorter than 120mm or carpets/mats thicker than 25mm. Clean these areas using the cordless stick vacuum with the floor brush head tool.

Q: How Should I Optimize 3-in-1 E20 for Multiple Floors?

A: The 3-in-1 E20 can clean multiple floors with one Omni Here's how to optimize multi-floor use: Use the Cordless Stick Vacuum: The 3-in-1 E20 is detachable. To clean another floor, remove the cordless stick vacuum and attach the floor brush head. Move the Robot: Move the robot to the new floor, create a map via the app, and press Clean to begin. This improves cleaning efficiency. Note: Since the base station remains on the original floor, the robot may display a positioning error or report it can't find the base station. This is normal. To streamline multi-floor use, consider purchasing an additional base station from eufy.

Specifications

Brand	eufy
Model Name	T2070
Color	Black
Product Dimensions	17.79"L x 15.35"W x 15.53"H
Item Weight	15.18 pounds
Battery Life	180 minutes
Capacity	3 Liters
Control Method	App, Voice
UPC	194644224912

Warranty & Support

For detailed warranty information and support, please refer to the officialUser Manual (PDF) or Instructions for Use (IFU) (PDF) provided with your product. You can also visit the officialeufy Store for additional resources and customer service.

Protection plans are available for purchase to extend coverage beyond the standard warranty:

- 2-Year Protection Plan: $36.99
- 3-Year Protection Plan: $48.99
- Complete Protect: One plan covers all eligible past and future purchases for $16.99/month.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLK1748Y

More documents and user manuals: **https://manuals.plus/**