Manuals+
Q & A | Deep Search | Upload

Hisense HAF1350DR

Hisense HAF1350DR 6.7L Hot Air Fryer User Manual

Model: HAF1350DR

Introduction

Thank you for choosing the Hisense HAF1350DR 6.7L Hot Air Fryer. This appliance is designed to cook your favorite foods with little to no oil, providing a healthier alternative to traditional deep frying. Please read this manual thoroughly before operating the appliance and keep it for future reference. Proper use and maintenance will ensure optimal performance and longevity of your air fryer.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs. Always use oven mitts or heat-resistant gloves when handling hot components.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other

appliances to allow proper air circulation.

- Do not block any ventilation openings.

Product Overview

The Hisense HAF1350DR Hot Air Fryer features a sleek, compact design with a large 6.7-liter capacity, making it suitable for preparing meals for families. It incorporates a user-friendly touch control panel and an integrated LED display for easy operation.

This image displays the Hisense HAF1350DR 6.7L Hot Air Fryer. The appliance is black with a sleek, cylindrical design. The control panel, located on the front, features a circular touch interface and the 'Hisense' brand logo.

Main Components:

- **Main Unit:** Houses the heating element and fan.
- **Frying Basket:** Removable basket with a non-stick coating for food placement.
- **Control Panel:** Touch-sensitive interface for setting temperature, time, and selecting preset programs.
- **LED Display:** Shows current settings and cooking status.

Setup

1. **Unpack:** Carefully remove all packaging materials from the air fryer.
2. **Initial Cleaning:** Before first use, wash the frying basket and any removable parts with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance to allow for proper air circulation. Do not place it directly against a wall or under cabinets.
4. **First Use (Optional):** For the first few uses, you may notice a slight plastic smell. This is normal and will dissipate. To minimize this, you can run the air fryer empty for about 10-15 minutes at 200°C (390°F) before cooking food. Ensure the area is well-ventilated during this process.

Operating Instructions

The Hisense HAF1350DR features intuitive touch controls and preset programs for various dishes.

Control Panel Functions:

- **Power Button:** Turns the appliance on/off.
- **Temperature Control:** Adjusts cooking temperature from 80°C to 200°C.
- **Timer Control:** Sets cooking time up to 60 minutes.
- **Preset Programs:** Selects from 10 pre-programmed cooking settings for common foods.

Cooking Process:

1. **Prepare Food:** Place your ingredients into the frying basket. Do not overfill the basket; ensure there is enough space for air to circulate.
2. **Insert Basket:** Slide the frying basket firmly into the main unit until it clicks into place.
3. **Power On:** Plug the air fryer into a grounded electrical outlet. The display will illuminate.
4. **Set Cooking Parameters:**
    - **Manual Setting:** Use the temperature and timer controls to set your desired cooking temperature (80-200°C) and time (up to 60 minutes).
    - **Preset Program:** Press the preset program button repeatedly to cycle through the 10 available programs. Once selected, the air fryer will automatically set the recommended temperature and time.
5. **Start Cooking:** Press the Start/Pause button to begin the cooking cycle. The fan and heating element will activate.
6. **Shake Basket (Optional):** For even cooking, especially with smaller items like fries, gently pull out the basket halfway through the cooking time and shake it. Then, slide the basket back into the air fryer. The appliance will resume cooking automatically.
7. **Completion:** The air fryer will beep when the cooking time is complete. Carefully pull out the basket.
8. **Remove Food:** Using heat-resistant tongs or gloves, carefully remove the cooked food from the basket. Avoid tipping the basket directly to prevent any residual oil from dripping.
9. **Power Off:** Unplug the appliance from the wall outlet after use.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your air fryer.

1. **Cool Down:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Clean Basket and Pan:** Remove the frying basket. Wash the basket and any removable parts with warm water and a mild dish soap. The non-stick coating allows for easy cleaning. For stubborn residue, soak in warm soapy water for 10-15 minutes before scrubbing with a non-abrasive sponge.
3. **Clean Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not use harsh chemicals or abrasive cleaners, as they may damage the surface.
4. **Clean Interior:** If necessary, gently wipe the interior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Ensure all parts are completely dry before storing the air fryer in a cool, dry place.

Troubleshooting

If you encounter any issues with your Hisense HAF1350DR Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; appliance malfunction.	Ensure the power cord is securely plugged into a working electrical outlet. Check your circuit breaker. If the issue persists, contact customer support.
Food is not cooked evenly.	Basket is overfilled; food not shaken; incorrect temperature/time.	Do not overfill the basket. Shake the basket halfway through cooking for even results. Adjust temperature and time as needed for specific recipes.
White smoke coming from the appliance.	Excess fat from food; residue from previous cooking.	This is usually normal if cooking fatty foods. Ensure the basket and pan are clean before use. If smoke is excessive or black, unplug immediately and contact support.
Oil leaking from the bottom of the unit.	Potential defect or damage to the unit's sealing.	If you observe oil leaking from the bottom of the air fryer, immediately unplug the unit and discontinue use. This indicates a potential internal issue. Do not attempt to repair it yourself. Contact Hisense customer support for assistance or replacement.

Specifications

- **Model:** HAF1350DR
- **Capacity:** 6.7 Liters
- **Power:** 1350 Watts
- **Temperature Range:** 80°C - 200°C (176°F - 390°F)
- **Timer:** Up to 60 minutes
- **Control Type:** Touch
- **Color:** Black

- **Dimensions (W x D x H):** Approximately 349 mm x 277 mm x 390 mm
- **Weight:** Approximately 5.8 kg (unit), 6.5 kg (packaged)
- **Non-stick Coating:** Yes
- **Exterior Material:** Polypropylene
- **Interior Material:** PTFE
- **Number of Programs:** 10 Preset Programs

Warranty and Support

For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official Hisense website. If you require technical support, have questions about operation, or need to report a defect, please contact Hisense customer service. Keep your purchase receipt as proof of purchase for warranty claims.