Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JH-3028

Generic 1000W Electric Juicer (Model JH-3028) User Manual

Introduction

Thank you for purchasing the Generic 1000W Electric Juicer, Model JH-3028. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.

This powerful juicer is designed to extract nutrient-rich juices from a variety of fruits and vegetables, offering a convenient way to enjoy fresh, healthy beverages at home.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the juicer.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is unplugged from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils away from moving parts during operation to prevent injury.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure the juicer cover is properly locked in place before operating.
- Do not feed hard seeds, ice, or frozen fruits into the juicer.

Product Overview

The Generic 1000W Electric Juicer consists of several key components designed for efficient juice extraction.



Image 1: Front view of the Generic Electric Juicer, showing the main unit, control dial, and an accompanying juice pitcher.

Key Components:

- **Pusher:** Used to guide fruits and vegetables into the feed chute.
- **Feed Chute:** Wide opening for inserting produce.
- **Cover:** Secures the juicing components.
- **Filter Basket (with Blade):** Stainless steel filter and cutting blade for juice extraction.
- **Juice Collector:** Collects the extracted juice.
- **Pulp Container:** Collects discarded pulp.
- **Motor Base:** Contains the 1000W motor and control dial.
- **Locking Bar:** Secures the cover to the motor base.
- **Control Dial:** For selecting speed settings (0, 1, 2).

Setup and Assembly

Before first use, wash all removable parts (pusher, cover, filter basket, juice collector, pulp container) in warm soapy water, rinse thoroughly, and dry. Wipe the motor base with a damp cloth.



Image 2: The Generic Electric Juicer fully assembled and ready for use, positioned on a wooden table next to a glass of freshly squeezed juice.

1. Place the motor base on a dry, stable, and flat surface.
2. Position the juice collector onto the motor base, ensuring the spout aligns with the juice outlet.
3. Place the stainless steel filter basket firmly into the juice collector. Ensure it is seated correctly.
4. Place the cover over the filter basket and juice collector, aligning the feed chute with the opening.
5. Lift the locking bar and secure it into the grooves on the cover. Ensure it clicks into place, indicating the cover is securely locked. The juicer will not operate if the locking bar is not engaged.
6. Place the pulp container under the pulp outlet.
7. Insert the pusher into the feed chute.
8. Plug the power cord into a 110V electrical outlet.







Image 3: The Generic Electric Juicer with its power cord, demonstrating the plug connection. Ensure the plug is fully inserted into a compatible outlet.

Operating Instructions

Prepare your fruits and vegetables by washing them thoroughly. For larger items, cut them into pieces that fit comfortably into the wide feed chute. Remove any hard pits or large seeds (e.g., from peaches, plums, mangoes) and tough skins (e.g., from pineapple, melon, citrus fruits).

1. Ensure the juicer is properly assembled and plugged in.
2. Place a glass or pitcher under the juice spout to collect the juice.
3. Turn the control dial to the desired speed setting:
    - **Speed 1 (Low):** Suitable for softer fruits and vegetables like oranges, grapes, tomatoes, and leafy greens.
    - **Speed 2 (High):** Ideal for harder fruits and vegetables such as apples, carrots, celery, and beets.
4. Gradually feed the prepared produce into the feed chute. Use the pusher to gently guide the produce down. Do not force the produce, as this can strain the motor and reduce juice yield.
5. Allow the juicer to process the produce. Juice will flow into your container, and pulp will collect in the pulp container.
6. Once juicing is complete, turn the control dial to "0" (off) and unplug the appliance from the power outlet.

Note: Do not operate the juicer continuously for more than 1 minute on hard produce or 2 minutes on soft produce. Allow the appliance to cool down for 2 minutes between cycles to prevent overheating.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your juicer. Always unplug the appliance before cleaning.

1. Turn the control dial to "0" and unplug the juicer.
2. Disengage the locking bar and remove the cover.
3. Carefully remove the filter basket, juice collector, and pulp container.
4. Empty the pulp container.
5. Rinse all removable parts under running water immediately after use to prevent pulp from drying and sticking.
6. Wash the removable parts (pusher, cover, filter basket, juice collector, pulp container) in warm soapy water. A brush may be helpful for cleaning the mesh of the filter basket.
7. All removable parts are dishwasher-safe (top rack recommended).
8. Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
9. Dry all parts thoroughly before reassembling or storing.

Storage: Store the assembled juicer in a dry, cool place, away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; locking bar not engaged; power outage.	Ensure plug is firmly in outlet; check locking bar is secured; check power supply.
Motor stops during operation.	Overload protection activated; too much produce forced into chute.	Turn off, unplug, remove excess produce, wait 2 minutes, then restart. Feed produce slowly.
Low juice yield or wet pulp.	Filter basket clogged; incorrect speed setting; produce fed too quickly.	Clean filter basket; use appropriate speed for produce; feed produce slowly and evenly.
Excessive vibration or noise.	Filter basket not properly seated; damaged filter basket.	Disassemble and reassemble filter basket correctly; inspect for damage and replace if necessary.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

- **Model:** JH-3028
- **Brand:** Generic
- **Maximum Power:** 1000 Watts
- **Capacity:** 1 Liter (Juice Collector)
- **Voltage:** 120 Volts
- **Number of Speeds:** 2
- **Blade Material:** Stainless Steel
- **Special Features:** Safety Lock, Stainless Steel Design, Wide Feed Chute
- **Product Dimensions:** 11"D x 8"W x 14"H
- **Item Weight:** 5 pounds
- **Manufacturer:** Zhongshan Liwei Electric Co., Ltd.



Image 4: The product packaging box, clearly displaying the model number JH-3028, confirming product identification.

Warranty and Support

This product is manufactured by Zhongshan Liwei Electric Co., Ltd. For warranty information, technical support, or service inquiries, please refer to the contact information provided on your purchase receipt or the product packaging. Please have your model number (JH-3028) and purchase date ready when contacting support.

© 2024 Generic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I obtain replacement parts for the Generic JH-3028 1000W Electric Juicer?

To obtain replacement parts for your Generic JH-3028 1000W Electric Juicer, you should contact the manufacturer or the retailer where the product was purchased. According to the manual, the manufacturer is Zhongshan Liwei Electric...

Read full answer

Open the live page

https://manuals.plus/asin/B0DM7PDHBY

More documents and user manuals: **https://manuals.plus/**