Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DeLUX M618ZD

DeLUX Left Handed Ergonomic Vertical Mouse

MODEL: M618ZD

Introduction

Thank you for choosing the DeLUX M618ZD Left Handed Ergonomic Vertical Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new mouse. Designed with a natural handshake grip, this vertical mouse aims to reduce wrist strain and discomfort associated with traditional mouse usage, making your computing experience more comfortable and productive.



Image: The DeLUX M618ZD Left Handed Ergonomic Vertical Mouse, showcasing its unique vertical design and black finish.

Key Features

Ergonomic Vertical Design

The mouse features a natural handshake design, specifically contoured for left-handed users. This ergonomic shape helps to maintain a neutral wrist and forearm posture, significantly reducing strain and discomfort, especially during prolonged use. The concave area for the thumb and extended bottom edge for the pinky finger provide a smoother movement and more comfortable grip.



Image: A visual comparison illustrating the difference between a traditional mouse grip (showing wrist pronation and potential strain) and the natural handshake posture promoted by the ergonomic vertical mouse (showing a neutral wrist position).

Built-in Rechargeable Battery

Equipped with a 500mAh Polymer Li-ion battery, the mouse offers extended usage on a single charge. A full charge takes approximately two hours and can provide stable operation for up to a week (based on 8 hours/day usage). It also features an auto energy-saving sleep mode to conserve power, allowing it to last for up to a month in standby.



Image: The DeLUX M618ZD mouse with a charging cable connected to its front-facing USB-C port, highlighting its rechargeable battery feature.

Multi-device Connectivity

The M618ZD supports both Bluetooth (BT) and 2.4G wireless connections. This allows for seamless switching between multiple devices, such as a laptop and a desktop computer, adapting to various usage conditions. The USB nano receiver for 2.4G connection is conveniently stored in the mouse's bottom compartment.



Image: The underside of the DeLUX M618ZD mouse, showing the mode switch button to toggle between 2.4G and Bluetooth connections, along with the storage slot for the USB nano receiver.

Adjustable DPI Settings

Customize your cursor speed and precision with five adjustable DPI levels: 800, 1200, 1600, 2400, and 4000. The DPI button is conveniently located above the backward button, allowing for quick and easy adjustments to suit your task, whether it's precise graphic design or fast-paced browsing.



Image: A close-up view of the DeLUX M618ZD mouse, pointing out the DPI button located on the top surface, near the scroll wheel, for easy sensitivity adjustments.

Quiet Clicks

The mouse is designed with silent click buttons, minimizing noise distractions. This feature is particularly beneficial in quiet environments, ensuring a more focused and undisturbed work experience for you and those around you.



Image: A hand resting comfortably on the DeLUX M618ZD mouse, illustrating its ergonomic design and the benefit of quiet clicks for a peaceful work environment.

Comfortable Thumb and Pinky Rest

The mouse incorporates a dedicated concave area for the thumb and a slightly extended bottom edge for the pinky finger. These design elements enhance comfort and provide better support, allowing for smoother movement and a more relaxed grip throughout the day.



Image: A hand demonstrating the natural and comfortable grip on the DeLUX M618ZD mouse, highlighting the thumb and pinky rest areas.

Setup

1. **Charging the Mouse:** Before first use, fully charge the mouse using the included USB-C cable. Connect the cable to the charging port on the front of the mouse and to a USB power source (e.g., computer USB port, wall adapter). The indicator light will show charging status.
2. **Power On/Off:** Locate the power switch on the bottom of the mouse. Slide it to the 'ON' position to power on the mouse.
3. **Connecting via 2.4G Wireless:**
   - Take out the USB nano receiver from the compartment at the bottom of the mouse.
   - Plug the receiver into an available USB port on your computer.
   - Slide the mode switch button on the bottom of the mouse to the '2.4G' position. The mouse should automatically connect.

4. **Connecting via Bluetooth (BT):**
    - Slide the mode switch button on the bottom of the mouse to the 'BT' position.
    - On your computer or device, open Bluetooth settings.
    - Search for new devices and select 'DeLUX M618ZD' (or similar name) from the list to pair.
    - Follow any on-screen prompts to complete the pairing process.

Operating Instructions

Basic Functions: The mouse features standard left-click, right-click, and scroll wheel functions.

DPI Adjustment: Press the DPI button (located above the backward button) to cycle through the five DPI settings (800/1200/1600/2400/4000). Select the sensitivity that best suits your needs.

Forward/Backward Buttons: The two side buttons (typically located near the thumb rest) function as forward and backward navigation in web browsers and file explorers. *Note: These buttons may have limited functionality or not be available on Mac OS.*

Mode Switching: Use the mode switch button on the bottom of the mouse to easily switch between 2.4G wireless and Bluetooth connections for multi-device workflow.

Maintenance

Cleaning: Use a soft, dry cloth to clean the surface of the mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no liquid enters the mouse.

Battery Care: To prolong battery life, avoid fully discharging the mouse frequently. Recharge when the battery low indicator appears.

Storage: When not in use for extended periods, turn off the mouse to conserve battery. Store in a cool, dry place.

Avoid Extreme Conditions: Do not expose the mouse to extreme temperatures, direct sunlight, or excessive moisture.

Troubleshooting

Problem	Solution

Problem	Solution
Mouse not responding	• Ensure the mouse is powered on. • Check battery level and recharge if necessary. • For 2.4G connection, ensure the USB receiver is securely plugged in and the mouse is in 2.4G mode. • For Bluetooth connection, ensure Bluetooth is enabled on your device and the mouse is paired and in BT mode. Try re-pairing if needed. • Try connecting to a different USB port or device to rule out port/device issues.
Cursor movement is erratic or slow	• Clean the optical sensor on the bottom of the mouse. • Ensure you are using the mouse on a clean, non-reflective surface. • Adjust the DPI setting to a higher value using the DPI button. • Check for signal interference from other wireless devices.
Mouse disconnects frequently	• Ensure the mouse is within the effective range of your device (typically 10 meters for Bluetooth/2.4G). • Check for low battery. • Minimize obstacles between the mouse and the receiver/device. • Try re-pairing the Bluetooth connection or re-inserting the 2.4G receiver.
Side buttons not working on Mac	• The backward and forward buttons may have limited or no functionality on Mac OS due to system limitations. This is normal behavior.

Specifications

Feature	Detail
Model Number	M618ZD
Connectivity	Bluetooth, 2.4G Wireless (with USB Receiver)
DPI Levels	800 / 1200 / 1600 / 2400 / 4000
Battery Type	Built-in 500mAh Polymer Li-ion Battery
Charging Time	Approx. 2 hours
Operating Time	Up to 1 week (8 hours/day usage)

Feature	Detail
Compatibility	Windows 7/8/10, Mac OS (limited functionality for side buttons on Mac)
Item Weight	4.2 ounces
Dimensions	4.33 x 3.66 x 2.99 inches (Package Dimensions)



Image: A chart providing hand length recommendations for different mouse sizes, including the M618ZD, to help users determine the best fit.

Warranty and Support

DeLUX products are manufactured to high quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the official DeLUX website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 DeLUX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DN6DH41B

More documents and user manuals: **https://manuals.plus/**