LED29A6500S L67H-8 GCBL TV20A-C35

Remote Control User Manual

For Changhong LED29A6500S, L67H-8, GCBL, TV20A-C35 Smart LCD HDTV TV

Introduction

This document serves as a user manual for the Generic replacement remote control, designed for use with specific Changhong Smart LCD HDTV models, including LED29A6500S, L67H-8, GCBL, and TV20A-C35. This remote is a dedicated replacement and may not replicate all functions of your original remote control. It operates using Infrared (IR) wireless communication.

Product Overview

The remote control is designed for ease of use, featuring a compact size and a comfortable grip. It provides essential functions for controlling your compatible Changhong television.

Figure 1: Front view of the remote control, displaying all buttons and their respective labels. The remote is black with clearly marked white and red button functions.

Figure 2: Angled perspective of the remote control, showcasing its ergonomic design and the arrangement of its buttons.

Figure 3: Top-down view of the remote control, offering a comprehensive look at all button functions and their layout.

Key Features:

- Dedicated replacement remote control.
- No programming or setup required; simply install batteries.
- Constructed from durable ABS material.
- Stable performance with long transmission distance.

Setup

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open.
3. Insert two (2) AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Important: Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.

Initial Use:

This replacement remote control requires no programming or complex setup. Once batteries are correctly installed, it is ready for immediate use with compatible Changhong TV models.

Operating Instructions

Point the remote control directly at the infrared receiver on your television. Ensure there are no obstructions between the remote and the TV.

Common Button Functions:

- **POWER:** Turns the TV on or off.
- **SOURCE:** Selects input sources (e.g., HDMI, AV, TV).
- **MENU:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **ENTER:** Confirms selections.
- **EXIT:** Exits the current menu or screen.
- **VOL+/-:** Adjusts the volume level.
- **CH+/-:** Changes channels.
- **Number Buttons (0-9):** Directly enters channel numbers.
- *Other buttons (e.g., SLEEP, LIST, INDEX, EPG, AUDIO, CC/SUB):* Functions may vary based on your specific TV model and may not be fully supported by this replacement remote.

Note: As a replacement remote, some advanced or specific functions of your original remote may not be available or may operate differently. This is not indicative of a defective product.

Maintenance

Cleaning:

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, solvents, or alcohol, as these can damage the remote's surface or internal components.

Battery Care:

- Replace batteries when the remote's responsiveness decreases.
- Always replace all batteries at the same time.
- Dispose of used batteries according to local regulations.

Troubleshooting

Remote Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh AAA batteries if necessary.
- **Line of Sight:** Make sure there are no objects blocking the path between the remote control and the TV's

infrared receiver.

- **Distance:** Ensure you are within the effective operating range of the remote control.

Some Functions Not Working:

This remote is a replacement unit and is designed to provide primary control for compatible Changhong TV models. It may not support all advanced or specific functions that were available on your original equipment manufacturer (OEM) remote control. This is a normal characteristic of replacement remotes and does not indicate a defect.

Specifications

Feature	Description
Model Compatibility	Changhong LED29A6500S, L67H-8, GCBL, TV20A-C35 Smart LCD HDTV TV
Wireless Communication	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Material	ABS/Plastic
Color	Black or White (color sent randomly)
Manufacturer	fortune store
ASIN	B0DP4N7YLT

Warranty and Support

This product is a replacement remote control. Specific warranty information is not provided in this manual. For any operational issues not covered in the troubleshooting section, or for further assistance, please contact the seller or manufacturer directly through your purchase platform.

© 2024 Generic. All rights reserved.