Manuals+
Q & A | Deep Search | Upload

POWERTEC TR-6600

POWERTEC TR-6600 Professional Hair Clipper User Manual

Model: TR-6600

1. Introduction

Thank you for choosing the POWERTEC TR-6600 Professional Hair Clipper. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your device. Please read these instructions carefully before first use and keep them for future reference.

2. Important Safety Instructions

To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions:

- Keep the appliance dry. Do not use it near water or in wet conditions.
- Do not disassemble the unit. For service, contact qualified personnel.
- Keep out of reach of children.
- Use only the charging cable provided with the device.
- Unplug the appliance before cleaning or performing maintenance.
- Do not operate the appliance if it has a damaged cord or plug, or if it is not working properly.

3. Package Contents

Verify that all items are present in the package:

- POWERTEC TR-6600 Hair Clipper
- Multiple Guide Combs (various sizes)
- USB Type-C Charging Cable
- Cleaning Brush
- Blade Oil

Image: Included accessories for the TR-6600 hair clipper.

4. Product Overview

Familiarize yourself with the components of your POWERTEC TR-6600 hair clipper:

Image: Front view of the TR-6600 hair clipper, highlighting its design and blade.

- **Blade Set:** Precision-engineered blades for efficient cutting.
- **Power Button:** To turn the clipper on or off.
- **Digital Display:** Shows battery level and RPM (rotations per minute).
- **USB Type-C Charging Port:** For recharging the internal battery.

- **Lever:** For adjusting blade taper (if applicable).

Image: Detailed view of the digital display on the clipper.

5. Setup

5.1 Initial Charging

Before first use, fully charge the clipper. Connect the USB Type-C charging cable to the clipper's charging port and plug the other end into a compatible USB power adapter (not included). The digital display will indicate the charging status. A full charge typically takes approximately 3 hours.

5.2 Attaching Guide Combs

Select the desired guide comb for your preferred cutting length. Align the comb with the clipper blade and push it firmly until it clicks into place. To remove, gently pull the comb away from the blade.

6. Operating Instructions

6.1 Turning On/Off

Press the power button once to turn the clipper on. Press it again to turn the clipper off.

6.2 Hair Cutting

1. Ensure hair is clean and dry.
2. Attach the appropriate guide comb.
3. Start cutting from the bottom of the head, moving upwards against the direction of hair growth.
4. Use slow, even strokes.
5. Regularly clear hair from the guide comb and blades during use.

6.3 Beard Trimming

For beard trimming, use a suitable guide comb. Trim in the direction of hair growth for a neater finish, or against the growth for a closer trim. Use the clipper without a comb for precise edging and detailing.

7. Maintenance

7.1 Cleaning the Blades

After each use, turn off the clipper and remove the guide comb. Use the provided cleaning brush to remove any loose hairs from the blades and the clipper body. For a more thorough cleaning, the blade set can be carefully detached (refer to specific instructions if provided with the product for blade removal).

7.2 Oiling the Blades

Regular oiling ensures optimal performance and extends blade life. After cleaning, apply 1-2 drops of the

provided blade oil onto the teeth of the blades. Turn the clipper on for a few seconds to distribute the oil evenly, then turn it off and wipe off any excess oil with a soft cloth.

7.3 Storage

Store the clipper in a dry, cool place, away from direct sunlight and moisture. Ensure the clipper is clean and oiled before storing.

8. Troubleshooting

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper fully.
Poor cutting performance.	Blades are dirty or dull.	Clean and oil the blades. If dull, consider blade replacement.
Clipper makes unusual noise.	Blades are not properly aligned or oiled.	Check blade alignment and apply blade oil.
Battery not charging.	Charging cable or adapter faulty.	Try a different USB Type-C cable or power adapter. Ensure connections are secure.

9. Specifications

- **Model:** TR-6600
- **Brand:** POWERTEC
- **Power Source:** Battery Powered (USB Type-C Rechargeable)
- **Product Dimensions:** 12 x 5 x 4 cm; 510 grams
- **Material:** Plastic (with Metal Casing)
- **Key Features:** Ergonomic Design, Fast Charging, Rechargeable, Charge Indicator Light
- **Manufacturer:** POWERTEC
- **Country of Origin:** China

10. Warranty and Support

10.1 Warranty Information

This product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase or contact your retailer for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

10.2 Customer Support

For technical assistance, spare parts, or any questions regarding your POWERTEC TR-6600 hair clipper, please contact your retailer or visit the official POWERTEC website for support contact information.

© 2026 POWERTEC. All rights reserved.