Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GWMF8140SRG

Geepas GWMF8140SRG Advanced Front Load Washing Machine User Manual

1. Introduction

This manual provides essential instructions for the safe and efficient operation of your Geepas GWMF8140SRG Advanced Front Load Washing Machine. Please read it thoroughly before first use and keep it for future reference. Understanding these instructions will ensure optimal performance and extend the lifespan of your appliance.

2. Safety Information

Important Safety Instructions:

- Read all instructions before using the appliance.
- Do not allow children to play on or in the appliance. Close supervision is necessary when the appliance is used near children.
- Ensure the appliance is properly grounded to reduce the risk of electric shock.
- Do not install or store the appliance where it will be exposed to the weather or to freezing temperatures.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in the user-maintenance instructions or in published user-repair instructions that you understand and have the skills to carry out.
- Always unplug the washing machine from the power supply before cleaning, performing maintenance, or making repairs.
- Do not wash articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances, as they emit vapors that could ignite or explode.

3. Product Overview

The Geepas GWMF8140SRG is an advanced front-load washing machine designed for efficient and thorough cleaning. Key features include a BLDC Inverter Motor for energy efficiency, Steam Wash technology for deep cleaning and sanitization, and a user-friendly LED Digital Display for easy program selection.

Components and Features:

- **BLDC Inverter Motor:** Ensures energy efficiency and quiet operation.
- **Steam Wash Technology:** Provides deep cleaning and sanitization for various fabric types.
- **LED Digital Display:** Simplifies cycle selection and monitoring.

- **Stainless Steel Inner Tub:** Durable construction for long-lasting performance.
- **530mm Jumbo Drum:** Accommodates larger loads, saving time and effort.
- **Control Panel:** Intuitive touch controls for program and option selection.
- **Detergent Dispenser:** Compartments for pre-wash, main wash detergent, and fabric softener.



Figure 1: Front view of the Geepas GWMF8140SRG washing machine. This image displays the overall design, including the control panel, door, and detergent dispenser.



Figure 2: The washing machine with its front door open, revealing the stainless steel inner drum. This view highlights the spacious interior and the door's design.



Figure 3: A close-up image of the detergent dispenser drawer, pulled out to show the compartments for detergent and fabric softener. This illustrates where to add washing agents.



Figure 4: A detailed view of the washing machine's control panel, featuring the program selection dial and the LED digital display. This shows the various options and settings available to the user.



Figure 5: An interior shot of the stainless steel drum, highlighting its textured surface designed for effective washing and the robust construction.

4. Setup and Installation

The Geepas GWMF8140SRG washing machine is designed for freestanding installation. Proper setup is crucial for safe and efficient operation.

4.1 Unpacking

- Remove all packaging materials, including the base packaging and any internal packing from the drum.
- Remove the transit bolts located at the rear of the machine. Keep these bolts for future transport if needed.

4.2 Location

- Place the washing machine on a firm, level floor.
- Ensure there is adequate space around the machine for ventilation and maintenance.
- Avoid direct sunlight or extreme temperatures.

4.3 Leveling

- Adjust the leveling feet at the bottom of the machine until it is perfectly stable and level. Use a spirit level to verify.
- Ensure all four feet are firmly on the ground to prevent vibration and noise during operation.

4.4 Water Connection

- Connect the inlet hose to a cold water tap with a 3/4-inch thread. Ensure the connection is tight to prevent leaks.
- Place the drain hose into a standpipe or over the edge of a sink, ensuring it is securely fixed to prevent dislodgement during draining. The drain hose should be positioned at a height between 60 cm and 100 cm from the floor.

4.5 Power Connection

- Plug the power cord into a properly grounded electrical outlet.
- Ensure the voltage matches the specifications of the appliance (refer to the specifications section).

5. Operating Instructions

Follow these steps for typical washing machine operation:

5.1 Preparing Laundry

- Sort laundry by fabric type, color, and degree of soiling.
- Check garment care labels for specific washing instructions.
- Empty pockets and close zippers or hooks to prevent damage to clothes and the drum.

5.2 Loading Laundry

- Open the washing machine door.
- Place laundry loosely into the drum, ensuring not to overload. The 8KG capacity refers to dry weight.
- Close the door firmly until it clicks.

5.3 Adding Detergent and Softener

- Pull out the detergent dispenser drawer.
- Add appropriate amounts of detergent to the main wash compartment and fabric softener to its designated compartment. Refer to detergent packaging for dosage recommendations.
- Push the dispenser drawer back in completely.

5.4 Selecting a Wash Program

Turn the program selection dial on the touch control console to choose the desired wash program. The LED Digital Display will show the selected program and estimated time.
Available cycle options include:

- **Heavy Duty:** For heavily soiled items.
- **Quick Wash:** For lightly soiled items or small loads requiring a fast cycle.
- **Rinse:** For an extra rinse cycle.
- **Speed Wash:** A faster wash cycle for everyday items.
- **Tub Clean:** A self-cleaning program for the drum.

Special features can be selected via the touch buttons:

- **Drum Clean:** Activates the self-cleaning cycle for the drum.
- **Hard Water Wash Programme:** Optimized for areas with hard water.
- **Hygiene Steam:** Adds steam for enhanced sanitization.
- **Inbuilt Heater:** Ensures precise temperature control for various wash programs.
- **Time Remaining Display:** Shows the estimated time until the cycle finishes.
- **Vibration Reduction:** Minimizes machine movement during spin cycles.

5.5 Starting the Wash Cycle

- Press the 'Start/Pause' button to begin the selected wash cycle.
- The display will show the remaining time and current cycle status.

5.6 After the Wash Cycle

- Once the cycle is complete, the machine will signal, and the door will unlock.
- Open the door and remove the laundry promptly to prevent wrinkles and odors.
- Leave the door slightly ajar to allow the drum to air dry and prevent mildew.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your washing machine.

6.1 Cleaning the Detergent Dispenser

- Pull out the dispenser drawer completely.
- Remove any removable parts and rinse them under running water to remove detergent residue.
- Clean the dispenser housing with a brush.
- Reassemble and reinsert the drawer.

6.2 Cleaning the Door Seal

- Regularly wipe the rubber door seal with a damp cloth to remove lint, dirt, and detergent residue.
- Ensure the area is dry to prevent mold and mildew growth.

6.3 Cleaning the Drain Filter

- Locate the drain filter, usually at the bottom front of the machine.
- Place a shallow container beneath the filter to catch any residual water.
- Carefully unscrew and remove the filter.
- Clean any lint, debris, or foreign objects from the filter.
- Screw the filter back in securely.

6.4 Using the Drum Clean Function

- Periodically run the 'Tub Clean' or 'Drum Clean' program to clean the interior of the drum and remove any buildup.
- Follow the instructions for this specific program, which may involve adding a descaling agent or washing machine cleaner.

7. Troubleshooting

This section addresses common issues you might encounter with your washing machine. For problems not listed here, contact customer support.

7.1 Machine Does Not Start

- **Check Power:** Ensure the power cord is securely plugged into a working outlet.
- **Check Door:** Make sure the door is fully closed and latched.
- **Check Water Supply:** Verify that the water taps are open.
- **Program Selection:** Ensure a wash program has been selected and the 'Start' button pressed.

7.2 Water Not Draining

- **Check Drain Hose:** Ensure the drain hose is not kinked or blocked.
- **Clean Drain Filter:** A clogged drain filter can prevent proper drainage. Refer to Section 6.3.

7.3 Excessive Vibration or Noise

- **Leveling:** Ensure the machine is properly leveled. Refer to Section 4.3.
- **Load Balance:** An unbalanced load can cause vibration. Redistribute laundry evenly in the drum.
- **Transit Bolts:** Confirm that all transit bolts have been removed. Refer to Section 4.1.

7.4 Detergent Residue on Clothes

- **Detergent Amount:** Reduce the amount of detergent used, especially with soft water.
- **Detergent Dispenser:** Clean the dispenser to ensure proper flow. Refer to Section 6.1.
- **Overloading:** Do not overload the machine, as this can prevent proper rinsing.

8. Specifications

Brand	Geepas
Model Info	GWMF8140SRG
Capacity	8 Kilograms
Product Dimensions (D x W x H)	67 x 57.3 x 88.8 cm
Item Weight	60 Kilograms
Installation Type	Freestanding
Access Location	Front Load
Control Console	Touch
Voltage	144 Kilovolts (Please verify local power supply requirements)
Material Type	Metal, Stainless Steel
Special Features	Drum Clean, Hard Water Wash Programme, High Efficiency, Hygiene Steam, Inbuilt Heater, Time Remaining Display, Vibration Reduction
Cycle Options	Heavy Duty, Quick Wash, Rinse, Speed Wash, Tub Clean

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or contact your retailer. Keep your purchase receipt as proof of purchase.
For technical support or service inquiries, please contact Geepas customer service or your authorized service center. Contact details can typically be found on the manufacturer's website or in your product documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question