Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dpofirs Dpofirshtkgua12n3-12

Dpofirs Handheld Game Console RK3326 User Manual

Model: Dpofirshtkgua12n3-12

1. Introduction

Thank you for purchasing the Dpofirs Handheld Game Console. This device is designed to provide a portable gaming experience with support for various emulators. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new console.





Image 1.1: Front view of the Dpofirs Handheld Game Console.

2. Product Overview

2.1 Components and Controls

The Dpofirs Handheld Game Console features a compact design with intuitive controls for an optimal gaming experience.

- **4-inch IPS Screen:** A high-resolution (720x720) fully laminated color screen designed to reduce eye fatigue.
- **Dual 3D Control Sticks:** Provides precise control for various game types.
- **Directional Pad (D-pad):** For traditional directional input.
- **ABXY Buttons:** Standard action buttons.

- **L/R Buttons:** Spring-loaded shoulder buttons on the back for enhanced grip and finger release.
- **RK3326 Chipset:** A powerful 1.5GHz, 64-bit processor capable of handling 2D and some 3D games.
- **4000mAh Battery:** Built-in rechargeable battery offering up to 6 hours of gameplay.
- **Memory Card Slot:** For expanding storage for games, videos, and other media.



Image 2.1: Detailed view of the console's front controls and side profile, highlighting the D-pad, ABXY buttons, dual analog sticks, and the ergonomic L/R shoulder buttons.




BATTERY: Li-Po 3.8V 4000mAh
ADAPTERINPUT: 5V ⎓ ≥1.5A
Li-Po
Built in rechargeable li-po battery
Only can use certified charger
The battery may explode in the fire
MADE IN CHINA
R1
R2
L2
L1

Image 2.2: Rear view of the console, displaying the R1, R2, L1, L2 buttons and regulatory information including battery specifications.

3. Setup

3.1 Package Contents

Before starting, ensure all items are present in the package:

- Handheld Game Console
- Charging Cable
- Game Console Storage Bag
- Screen Protector Film
- Small Memory Card (pre-installed or included separately)



Image 3.1: The complete package contents, showing the console, USB charging cable, protective carrying case, and screen protector film.

3.2 Initial Charging

It is recommended to fully charge the console before first use. Connect the provided charging cable to the console's charging port and a compatible USB power adapter (not included). The battery features dual protection for safe charging.

3.3 Memory Card Installation

The console comes with a small memory card. If it is not pre-installed, locate the memory card slot on the device and gently insert the card until it clicks into place. Ensure the card is inserted correctly to avoid damage.

4. Operating Instructions

4.1 Powering On/Off

- **To Power On:** Press and hold the Power button until the screen illuminates.
- **To Power Off:** Press and hold the Power button, then follow the on-screen prompts to shut down the system. A quick press of the Power button may put the device into sleep mode.

4.2 Navigating the Interface

Use the D-pad or the left analog stick to navigate through menus and select options. The A/B/X/Y buttons are typically used for selection and confirmation, while other buttons may serve as back or menu functions depending on the system's configuration.

4.3 Loading Games

The console supports over 60 emulators, including MD, CPS, and SMD. Games are typically stored on the memory card. Navigate to the game selection menu, browse through the available emulators or game lists, and select a game to launch it.



Image 4.1: The console screen showcasing various game titles, illustrating its broad emulator compatibility.

4.4 Using Controls

The console offers flexible control options:

- **Directional Pad and Dual 3D Control Sticks:**Choose the input method that best suits the game you are playing.
- **L/R Buttons:** These spring-loaded buttons provide tactile feedback and are ergonomically designed for comfort during extended play.



Image 4.2: A user holding the console, highlighting the comfortable grip and accessibility of all controls during gameplay.

5. Maintenance

5.1 Screen Care

To maintain the clarity of the 4-inch screen, use a soft, lint-free cloth to gently wipe away dust and fingerprints. Avoid using harsh chemicals or abrasive materials that could scratch the screen.

5.2 Battery Care

The 4000mAh battery is designed for longevity. To maximize battery life:

- Avoid extreme temperatures.

- Do not allow the battery to fully discharge frequently.
- Use only the provided charging cable or a compatible charger with appropriate voltage (5V, 1.5A).

5.3 Storage

When not in use, store the console in the provided storage bag to protect it from dust and minor impacts. Keep it in a cool, dry place away from direct sunlight.

6. Troubleshooting

Issue	Possible Cause	Solution
Console does not power on.	Low battery; faulty charging cable/adapter.	Charge the console for at least 30 minutes. Ensure the charging cable and adapter are working correctly.
Games do not load or crash.	Corrupted game file; memory card issue; unsupported game format.	Ensure game files are not corrupted. Reinsert the memory card. Verify the game format is supported by the console's emulators.
Controls are unresponsive.	Software glitch; physical damage.	Restart the console. If the issue persists, contact customer support.
Screen flickering or display issues.	Software issue; hardware malfunction.	Restart the console. If the problem continues, contact customer support.

7. Specifications

Feature	Detail
Model Number	Dpofirshtkgua12n3-12
Screen Size	4 inches
Screen Resolution	720 x 720
Chipset	RK3326, 1.5GHz, 64-bit
Battery Capacity	4000mAh (Li-Po 3.8V)
Battery Life	Up to 6 hours (on full charge)
Supported Emulators	60+ (e.g., MD, CPS, SMD)
Product Dimensions	7.09 x 5.12 x 1.97 inches

Feature	Detail
Item Weight	13.3 ounces

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Dpofirs customer service through their official channels. Keep your proof of purchase for warranty claims.
For further assistance, you may visit the Dpofirs Store on Amazon.

© 2023 Dpofirs. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQPKYJF1

More documents and user manuals: **https://manuals.plus/**