Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BT9565

Braun Series 9 BT9565 Electric Beard Trimmer User Manual

Model: BT9565 | Item Number: 7500435244824

1. Introduction

Welcome to the user manual for your new Braun Series 9 BT9565 Electric Beard Trimmer. This device is engineered for professional precision and maximum efficiency, offering a versatile range of tools for trimming, shaving, contouring, and detailing. Please read these instructions carefully before using the appliance to ensure safe and optimal performance. Keep this manual for future reference.

2. Important Safety Instructions

- This appliance is suitable for cleaning under running water.
- Do not use the appliance with a damaged foil or cord.
- Keep the appliance dry when charging.
- This appliance contains batteries that are non-replaceable.
- Do not open the appliance.
- Keep out of reach of children.
- Only use the power supply provided with the appliance.
- Unplug the appliance before cleaning.

3. Product Components

Your Braun Series 9 BT9565 comes with a comprehensive set of tools for all your grooming needs. Familiarize yourself with the components:



Image: Braun Series 9 BT9565 Electric Beard Trimmer with all included accessories, including various comb attachments, precision heads, charging stand, and travel case.

- 1x Beard Trimmer Unit
- 6x Comb Attachments (various lengths)
- 3x Precision Attachments (e.g., ProDetail, ProContour, Shave head)
- 1x Beard Stencil
- 1x Charging Stand
- 1x Soft Bag
- 1x Travel Case
- 1x Cleaning Brush
- 1x Power Supply

4. Setup and Initial Use

4.1 Charging the Trimmer

1. Ensure the trimmer is switched off.
2. Connect the power supply to the charging stand or directly to the trimmer.
3. Plug the power supply into an electrical outlet.
4. The charging indicator light will illuminate. A full charge provides up to 180 minutes of cordless operation.

4.2 Attaching and Detaching Combs/Attachments

- To attach: Align the desired comb or attachment with the trimmer head and push until it clicks into place.
- To detach: Gently pull the comb or attachment away from the trimmer head.

5. Operating Instructions

5.1 Powering On/Off

Press the power button to turn the trimmer on or off.

5.2 Adjusting Trimming Length

The precision wheel allows for 52 length settings in 0.25 mm increments. Rotate the wheel to select your desired trimming length. The selected length will be displayed on the trimmer.

5.3 Trimming Techniques

- **Beard Trimming:** Attach a comb guide. For best results, trim against the direction of hair growth.
- **Contouring and Detailing:** Remove the comb guide and use the precision shaving head or specific detailing attachments for sharp lines and edges.
- **PowerBoost Extra Mode:** Activate this mode for tackling denser beards. The trimmer automatically adjusts power with AutoSense technology to maintain consistent performance.
- **ProBlade:** The ultra-sharp ProBlade is designed to capture even difficult hairs for a clean and precise cut.

6. Cleaning and Maintenance

6.1 Cleaning the Trimmer

1. Ensure the trimmer is switched off and unplugged from the power supply.
2. Remove any attached comb or precision head.
3. Brush away loose hairs from the trimmer head and attachments using the provided cleaning brush.

4. Since the trimmer is 100% waterproof, you can rinse the trimmer head and attachments under warm running water.
5. Allow all parts to air dry completely before reassembling or storing.

6.2 Storage

Store the trimmer and its accessories in the provided soft bag or travel case to protect them from damage and dust.

7. Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer for at least 1 hour.
Poor trimming performance.	Hair buildup in the cutting element; dull blade.	Clean the trimmer head thoroughly. Ensure the blade is not damaged.
Trimmer stops during use.	Battery is low.	Recharge the trimmer.

If the problem persists after attempting these solutions, please contact Braun customer service.

8. Technical Specifications

Brand: Braun

Model: BT9565

Item Model Number: 7500435244824

Product Dimensions: 16 x 7 x 25.2 cm

Item Weight: 524 Grams

Power Source: Battery (Li-ion)

Cordless Operation Time: Up to 180 minutes

Special Features: AutoSense Technology, PowerBoost Extra Mode, ProBlade, Waterproof, Wireless

Recommended Use: Beard

Color: Titanium

9. Warranty and Support

This Braun product is manufactured to the highest quality standards. For detailed warranty information specific to your region, please refer to the warranty card included in your product packaging or visit the official Braun website. For further assistance, product registration, or to find authorized service centers, please visit www.braun.com.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQWHKHN2

More documents and user manuals: **https://manuals.plus/**