Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BG3530

Braun Body Groomer Series 3 BG3530 Instruction Manual

Model: BG3530

1. Introduction

Thank you for choosing the Braun Body Groomer Series 3 BG3530. This device is designed for safe and effective body grooming, featuring SkinGuard technology for sensitive areas and a waterproof design for versatile use. Please read this instruction manual thoroughly before using the appliance to ensure proper operation and to maximize its performance and lifespan. Keep this manual for future reference.



Image 1: Braun Body Groomer Series 3 BG3530. This image displays the main body groomer unit in grey, highlighting its ergonomic design and power button.

2. Safety Information

Always keep the product away from water while charging. Do not use the product while it is charging. Allow the product to cool down before charging to prevent overheating. Always unplug the charger from the power source when not in use. Be cautious when using the product near water, even if it is waterproof. Always follow the cleaning instructions to prevent bacterial growth and ensure optimal performance. The product's SkinGuard technology and sensitive comb attachment should be used to minimize the risk of cuts and skin irritation.

3. Package Contents

The Braun Body Groomer Series 3 BG3530 package typically includes the following items:

- 1 x Braun Body Groomer BG3530
- 1 x Body comb (3 mm)
- 1 x Sensitive comb (1 mm)
- 1 x Cleaning brush
- 1 x Charger (not explicitly listed but implied for a refillable device)



Image 2: Braun Body Groomer BG3530 with accessories. This image shows the body groomer alongside its two comb attachments

(3mm body comb and 1mm sensitive comb) and a cleaning brush.

4. Product Overview

The Braun Body Groomer BG3530 is engineered for comfort and efficiency. Key features include:

- **SkinGuard Technology:** Designed to minimize nicks and cuts, providing a safer trimming experience, especially in sensitive areas.
- **Sensitive Comb Attachment:** A dedicated 1mm comb that prevents direct blade contact with the skin, enhancing comfort for delicate regions.
- **100% Waterproof:** Allows for convenient use in the shower and easy cleaning under running water.
- **Long-lasting Battery:** Provides up to 80 minutes of cordless operation on a full charge.
- **Multiple Lengths:** Includes a 3mm body comb and a 1mm sensitive comb for various grooming preferences.





Image 3: Braun Body Groomer SkinGuard Technology and Sensitive Trim. This image illustrates the SkinGuard blade design for safety and shows the sensitive comb attachment, along with examples of the groomer being used on the body.

5. Setup and Charging

5.1 Initial Setup

Before first use, ensure the device is fully charged. Unpack all components and inspect them for any damage. Refer to the 'Package Contents' section to confirm all items are present.

5.2 Charging the Device

1. Ensure the groomer is switched off.
2. Connect the charger to the groomer's charging port.
3. Plug the charger into a suitable electrical outlet.
4. The charging indicator light will illuminate, typically green, to show that the device is charging.
5. Allow the device to charge completely. A full charge provides approximately 80 minutes of cordless operation.
6. Once fully charged, unplug the charger from both the outlet and the groomer.

Important: Do not use the groomer while it is connected to the charger. Always ensure the device is dry before charging.

6. Operating Instructions

6.1 General Operation

To turn the groomer on or off, press the power button. For optimal results, ensure your skin is clean and dry before grooming, unless using for wet shaving.

6.2 Using the Body Comb (3 mm)

Attach the 3mm body comb to the groomer head. This comb is suitable for general body hair trimming to a uniform length. Move the groomer against the direction of hair growth for an even trim. Apply gentle pressure.

6.3 Using the Sensitive Comb (1 mm)

Attach the 1mm sensitive comb for trimming hair in delicate or sensitive areas. This comb provides an extra layer of protection against direct blade contact. Use slow, controlled movements and apply minimal pressure.

6.4 Wet and Dry Use

The Braun Body Groomer BG3530 is 100% waterproof, allowing for both dry and wet use, including in the shower. For wet use, you may apply shaving foam or gel for added comfort. Always rinse the groomer head thoroughly after wet use.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your body groomer.

1. **After Each Use:** Turn off the groomer. Remove any attached comb. Rinse the groomer head and the comb under warm running water until all hair and debris are removed.
2. **Deep Cleaning:** For a more thorough clean, use the provided cleaning brush to remove stubborn hair from the blade area.
3. **Drying:** Shake off excess water and allow the groomer and attachments to air dry completely before storing or reattaching combs.
4. **Lubrication:** Periodically, apply a drop of light machine oil (not included) to the blades to maintain their sharpness and smooth operation.

Caution: Do not use abrasive cleaners or harsh chemicals on the groomer, as this can damage the device.

8. Troubleshooting

If you encounter issues with your Braun Body Groomer BG3530, consider the following:

- **Device not turning on:** Ensure the device is fully charged. Check if the charging cable is properly connected.
- **Poor trimming performance:** The blades may be clogged with hair. Clean the groomer head thoroughly as described in the 'Maintenance and Cleaning' section. Ensure the comb attachment is correctly secured.
- **Reduced battery life:** Over time, battery performance may decrease. Ensure you are charging the device fully each time.
- **Skin irritation:** Ensure you are using the appropriate comb attachment, especially the sensitive comb for delicate areas. Apply gentle pressure and move the groomer against the direction of hair growth.

If problems persist, please contact Braun customer service for further assistance.

9. Specifications

Model Name	BG 3530
Brand	Braun
Power Source	Refillable Battery
Battery Life	Up to 80 minutes
Special Features	Cordless, SkinGuard Technology, Waterproof

Recommended Use	Body Grooming
Blade Material	Stainless Steel
Item Weight	137 Grams
Color	Grey

10. Warranty and Support

Braun products are manufactured to high quality standards. For detailed warranty information, please refer to the warranty card included with your product or visit the official Braun website. For product support, frequently asked questions, or to register your product, please visit www.braun.com. You may also find additional information and resources by scanning the QR code found on the product packaging, which links to uk.braun.com/qr-GlobalPackBG3-0923.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQWHNBMP

More documents and user manuals: **https://manuals.plus/**