Braun BT9520

Braun Series 9 Beard Trimmer Instruction Manual

Model: BT9520

Product Overview

The Braun Series 9 Beard Trimmer is engineered for professional precision and maximum efficiency. It features a PowerBoost mode for dense beards and AutoSense technology for consistent results. The ultra-sharp ProBlade ensures effective cutting, while the PrecisionLock button and PrecisionWheel offer 50 length settings in 0.25mm intervals for ultimate control. This premium trimmer includes versatile tools for mowing, shaving, defining contours, and fine-tuning details.

Key Features:

- **Professional Accuracy & Control:** Designed for mowing, shaving, defining contours, and detailing with premium tools.
- **Maximum Efficiency:** PowerBoost mode for thick beards and AutoSense technology for uniformity.
- **Perfect Cutting:** Ultra-sharp, wear-resistant ProBlade and PrecisionShave head for clean lines.
- **Precise Length Settings:** PrecisionLock button and PrecisionWheel with 50 length adjustments (0.25mm intervals).
- **Long-Lasting Use:** 100% waterproof with a long-life Li-ion battery providing up to 180 minutes of cordless runtime.

Package Contents

Carefully unpack your Braun Series 9 Beard Trimmer and ensure all components are present. The box contents include:

- 1 x Braun Series 9 Beard Trimmer (BT9520)
- 2 x Precision Combs (0.5-10mm, 10-20mm)
- 1 x PrecisionShave Head
- 1 x ProDetail Trimmer Head
- 1 x Beard Stencil
- 1 x Travel Case
- 1 x Cleaning Brush
- 1 x Charger



Image: The Braun Series 9 Beard Trimmer with its full set of accessories, including combs, shaving head, detail trimmer, beard stencil, travel case, and cleaning brush.

Setup

Initial Charging:

1. Before first use, fully charge the trimmer for approximately 1 hour. A full charge provides up to 180 minutes of cordless trimming.
2. Connect the charger to the trimmer and plug it into a power outlet. The charging indicator light will illuminate.
3. Once fully charged, the indicator light may change color or turn off, depending on the model.

Attaching Accessories:

- To attach a comb or trimmer head, align it with the trimmer's main body and press firmly until it clicks into place.
- To remove, gently pull the attachment away from the trimmer.



Image: The Braun Series 9 Beard Trimmer, ready for use, shown with its packaging.

Operating Instructions

Powering On/Off:

- Press the power button to turn the trimmer on.
- Press the power button again to turn the trimmer off.

Adjusting Length Settings:

- Use the PrecisionWheel to select your desired trimming length. The wheel allows for 50 length settings in 0.25mm intervals.
- Engage the PrecisionLock button to secure your chosen length setting, preventing accidental changes during use.

Using PowerBoost Mode:

- For denser beard areas or tougher hair, activate the PowerBoost mode. This provides additional power for efficient cutting.
- The trimmer's AutoSense technology automatically adapts power to beard thickness for optimal performance.

Utilizing Attachments:

- **Precision Combs:** Use the 0.5-10mm comb for shorter styles and the 10-20mm comb for longer beard lengths.
- **PrecisionShave Head:** For clean shaves and defining sharp lines around your beard.
- **ProDetail Trimmer Head:** Ideal for intricate detailing and creating precise contours.
- **Beard Stencil:** Use the included stencil to help achieve symmetrical and defined beard lines.





Image: A detailed illustration of the trimmer's advanced features, including the PowerBoost mode, ProBlade, PrecisionWheel for length control, and its waterproof capability.



Image: A visual guide to the various barbering tools and accessories included, such as the clean shave head, detail trimmer, precision combs, cleaning brush, and travel case.

Maintenance and Cleaning

Cleaning the Trimmer:

- The Braun Series 9 Beard Trimmer is 100% waterproof. After each use, you can rinse the trimmer head and combs under running water.
- For a more thorough cleaning, use the included cleaning brush to remove any trapped hairs from the blades and trimmer body.
- Ensure the trimmer is turned off before cleaning.
- Allow all parts to air dry completely before reassembling or storing.

Blade Care:

- The ProBlade is designed for lifetime sharpness. Regular cleaning helps maintain its performance.
- Do not use abrasive cleaners or harsh chemicals on the trimmer or its attachments.

Storage:

- Store the trimmer and its accessories in the provided travel case to protect them from damage and keep them organized.
- Store in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your Braun Series 9 Beard Trimmer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully.
Trimmer is not cutting effectively.	Blades are clogged with hair.	Clean the trimmer head and blades thoroughly using the cleaning brush or by rinsing under water.
Trimmer makes unusual noise.	Hair caught in the mechanism or attachment not properly secured.	Clean the trimmer and ensure all attachments are securely fastened. If the issue persists, contact customer support.
Battery life is shorter than expected.	Battery not fully charged or aging battery.	Ensure the trimmer is fully charged before each use. Over time, battery capacity may decrease.

If the problem persists after attempting these solutions, please contact Braun customer support for further assistance.

Technical Specifications

Feature	Specification
Model Number	BT9520
Manufacturer	Procter & Gamble
Product Dimensions	16 x 7 x 25.2 cm
Item Weight	382 Grams
Battery Type	1 Lithium Ion battery (included)
Runtime	Up to 180 minutes (cordless)
Power Source	Battery Powered
Special Features	Waterproof, Long Life Li-ion Battery, PowerBoost Mode, AutoSense Technology, PrecisionLock, PrecisionWheel
Blade Material	Stainless Steel (ProBlade)
Length Settings	50 (in 0.25mm intervals)
Recommended Use	Beard Trimming
Color	Chrome

Warranty and Support

Braun products are manufactured to meet high quality standards. For information regarding your product's warranty, please refer to the warranty card included in your package or visit the official Braun website.
You can also scan the QR code below for additional warranty information and product registration:



Image: QR code to scan for extra warranty and product information.

For further support, product registration, or to access digital versions of manuals, please visit the official Braun website: uk.braun.com

Manufacturer: Procter & Gamble

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question