Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PawPoll PW-D02

PawPoll Cat Water Fountain Replacement Filters User Manual

Model: PW-D02

1. Introduction

Thank you for choosing PawPoll Cat Water Fountain Replacement Filters. These filters are designed to ensure your pet always has access to clean, fresh, and healthy drinking water. This manual provides essential information on the product, its installation, maintenance, and specifications.



Image: PawPoll Cat Water Fountain Filters and Sponges. This image displays the complete set of replacement filters and foam sponges.

2. Package Contents

Each package contains the following items:

- 6 x Activated Carbon Filters
- 6 x Foam Sponges

3. Product Features and Filtration System

PawPoll replacement filters are engineered with a multi-layer filtration system to provide superior water quality for your pet.

Image: Diagram illustrating the 4-layer filtration system. This visual shows how each layer contributes to purifying the water.

The 4-layer filtration system includes:

1. **Non-Woven Fabric:** Effectively removes hair and food debris.
2. **Activated Carbon:** Filters out chlorine and heavy metals, improving water taste.
3. **Ion Exchange Resin:** Helps remove odors, bacteria, and softens the water.
4. **High-Density Cotton:** Filters out small dust particles and other foreign matter.

4. Installation and Preparation

Proper preparation of the filter is crucial for optimal performance and water quality.



Image: Step-by-step guide on preparing the filter. This image shows rinsing the filter under running water and then soaking it.

1. **Rinse the Filter:** Before first use, rinse the filter thoroughly under running water for at least 30 seconds to remove any loose carbon dust.
2. **Soak the Filter:** Submerge the filter in clean water for 5 minutes. This helps to activate the filter media and ensures proper water flow.
3. **Insert into Fountain:** Place the prepared filter into the designated slot in your PawPoll 3.2L wireless cat water fountain. Ensure it is seated correctly.
4. **Install Foam Sponge:** Place the foam sponge around the pump intake to prevent debris from entering the pump.

5. Operating (Filter Function)

Once installed, the filters continuously purify the water as it circulates through your PawPoll cat water fountain. The multi-layer system works to remove impurities, ensuring your pet drinks clean and fresh water throughout the day.

6. Maintenance and Replacement

Regular filter replacement is essential to maintain water quality and the longevity of your fountain.



Image: Visual reminder to replace filters every two weeks. This image highlights the recommended replacement frequency.

- **Filter Replacement Frequency:** It is recommended to change the activated carbon filter every **2 to 4 weeks**. This frequency may vary depending on the number of pets using the fountain and their water consumption habits.
- **Foam Sponge Replacement:** The foam sponge should also be replaced every 2 to 4 weeks, or sooner if it appears visibly dirty or clogged.
- **Fountain Cleaning:** Clean the fountain and pump regularly (at least once a week) to prevent mineral buildup and maintain hygiene.

7. Compatibility

These replacement filters are specifically designed for the**PawPoll 3.2L Wireless Cat Water Fountain with Motion Detector**. Please verify your fountain model (PW-D02) before purchasing to ensure a perfect fit.

8. Specifications

Image: Detailed dimensions of the filter and sponge. This image provides measurements for both components.

Feature	Detail
Model Number	PW-D02
Material	Activated Carbon, Ion Exchange Resin, Non-Woven Fabric, High-Density Cotton
Filter Dimensions (approx.)	8.8 cm (L) x 4.2 cm (W) x 2.2 cm (H) / 3.5 in (L) x 1.7 in (W) x 0.86 in (H)
Sponge Dimensions (approx.)	3 cm (L) x 2.2 cm (W) x 3 cm (H) / 1.2 in (L) x 0.9 in (W) x 1.2 in (H)
Weight (per filter)	Approx. 15g

9. Troubleshooting

If you notice reduced water flow or unusual odors, please check the following:

- **Clogged Filter:** The filter may be saturated with impurities. Replace the filter with a new one.
- **Dirty Sponge:** The foam sponge might be blocked with debris. Clean or replace the sponge.
- **Fountain Cleanliness:** Ensure the fountain and pump are clean and free of debris or mineral buildup.

10. Warranty and Support

PawPoll products come with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects. For any questions, concerns, or warranty claims, please contact PawPoll customer support through the retailer where you purchased the product or visit the official PawPoll website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRVLT8YP

More documents and user manuals: **https://manuals.plus/**