Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Edillas Edi8207B

Edillas Kids Digital Watch Instruction Manual

Model: Edi8207B

Introduction

Thank you for choosing the Edillas Kids Digital Watch. This watch is designed for children aged 4-15, featuring a durable, waterproof design with multiple functions including time display, alarm, stopwatch, and colorful LED lights. This manual will guide you through the setup and operation of your new watch.


Edillas
S M T W T F S
10:30
58
WR 30M
LIGHT
CHRONGRAPH
MODE
START
RESET

Figure 1: Edillas Kids Digital Watch (Black Model)

Watch Components and Buttons

Familiarize yourself with the watch's buttons and display areas:

- **LIGHT Button:** Activates backlight and changes light color.
- **MODE Button:** Switches between different functions (Time, Alarm, Stopwatch).
- **START Button:** Used for setting values and starting stopwatch.
- **RESET Button:** Used for switching values and resetting stopwatch.



Figure 2: Watch Button Layout

Setup

1. Setting Time and Date

Follow these steps to set the current time and date on your watch:

1. From the time display mode, press the**MODE** button three times to enter the time setting interface. The seconds will start flashing.
2. Press the **RESET** button to switch to minutes.
3. Press the **START** button to set the minute number.
4. Press the **RESET** button to switch to hours.
5. Press the **START** button to set the hour number (note AM/PM or 24H format).
6. Press the **RESET** button to switch to days.
7. Press the **START** button to set the day number.
8. Press the **RESET** button to switch to months.
9. Press the **START** button to set the month number.
10. Press the **RESET** button to switch to weeks.
11. Press the **START** button to set the week.
12. Press the **RESET** button to switch to seconds.
13. Press the **START** button to set the seconds.
14. Press the **MODE** button to save the settings and return to the main time display.

Your browser does not support the video tag.

Video 1: How to set the time and date on the Edillas 8207B Kids Watch.

2. Setting the Alarm

To set an alarm on your watch:

1. Press the **MODE** button twice to enter the alarm setting interface. The hour will flash.
2. Press the **START** button to set the desired alarm hour.
3. Press the **RESET** button to switch to minutes.
4. Press the **START** button to set the desired alarm minutes.
5. Press the **MODE** button to confirm the setting and return to the default interface.
6. To view the set alarm time, press and hold the**RESET** button.

Your browser does not support the video tag.

Video 2: How to set an alarm on the Edillas 8207B Kids Digital Watch.

Operating Instructions

1. Using the Stopwatch Function

The watch includes a stopwatch for timing activities:

1. Press the **MODE** button once to enter the stopwatch interface.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause the stopwatch.
4. Press the **START** button a third time to continue timing.
5. Press the **RESET** button to reset the stopwatch to zero.
6. Press the **MODE** button to exit the stopwatch function and return to the default interface.

Your browser does not support the video tag.

Video 3: How to use the stopwatch function on the Edillas 8207B Kids Watch.

2. Changing Light Color

The watch features colorful LED lights. To activate and change the light color:

- Press the **LIGHT** button to turn on the light.
- Long press the **LIGHT** button to switch between the 7 available light colors (blue, green, red, light blue, yellow, purple, white) and a colorful flashing mode.





Figure 3: Watch display with different colorful LED lights.

Your browser does not support the video tag.

Video 4: How to set the light on the Edillas 8207B Kids Watch.

3. Hourly Chime On/Off

To turn the hourly chime on or off:

- Begin with the time display mode.
- To turn the hourly chime off: Press and hold the **RESET** button and the **MODE** button simultaneously. A black border around the letters (SMTWTFS) indicates the chime is off.
- To turn the hourly chime on: Press and hold the **RESET** button and the **MODE** button simultaneously again. The black border will disappear, indicating the chime is on.

Your browser does not support the video tag.

Video 5: How to use the hourly chime on the Edillas 8207B Kids Watch.

4. Switching Time Format (12H/24H)

To switch between 12-hour (AM/PM) and 24-hour time formats:

1. Press the **MODE** button three times to enter the time setting interface.
2. Press the **RESET** button twice to navigate to the hour setting.
3. Press the **START** button to toggle between 12H (indicated by A for AM or P for PM) and 24H (indicated by H) formats.
4. Press the **MODE** button to save the setting and return to the main time display.

Your browser does not support the video tag.

Video 6: How to switch the time format on your Edillas 8207B kids watch.

Maintenance

Water Resistance

The Edillas Kids Digital Watch is 30M/3 ATM waterproof, suitable for daily life activities such as getting wet, sweating, washing hands, and cold baths. Dirty watches can be rinsed directly with cold water.
Important: Avoid pressing the watch buttons under water, as this can compromise the waterproof seal and damage the watch.



Figure 4: Watch being used in water.

Troubleshooting

Hourly Chime Issues

If your hourly chime is not working as expected, please refer to the "Hourly Chime On/Off" section in this manual. Ensure the chime is properly activated. If issues persist, please contact customer support.

General Issues

For any other issues not covered in this manual, such as problems with the battery or movement, please contact Edillas customer support for assistance. We are committed to providing satisfactory service.

Specifications

Feature	Detail
Product Dimensions	8.66 x 0.55 x 0.39 inches
Item Weight	0.8 ounces
Model Number	Edi8207B
Water Resistance	30M / 3 ATM
Movement	Japan Imported Movement
Battery	1 Lithium Ion battery (included)
Display Type	Digital
Clasp Type	Buckle
Material	Soft strap, fine metal steel case, stainless steel case back, high-transparency resin glass



Figure 5: Watch Dimensions

Warranty and Support

Edillas is a professional brand committed to product quality and customer satisfaction. If you encounter any problems with the watch, especially concerning the battery or movement, we are ready to assist with replacements or support.
For any inquiries or support needs, please feel free to contact our sales team. Your satisfaction is our priority.
You can also refer to the officialUser Manual (PDF) for additional information.

© 2024 Edillas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DS5SZR3L

More documents and user manuals: **https://manuals.plus/**