Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SICOTAS Shoe Storage Cabinet

SICOTAS 5-Tier Rattan Entryway Shoe Storage Cabinet Instruction Manual

Model: Shoe Storage Cabinet (2-Piece Obsidian) | Brand: SICOTAS

1. Introduction

Thank you for choosing the SICOTAS 5-Tier Rattan Entryway Shoe Storage Cabinet. This manual provides detailed instructions for assembly, usage, and maintenance to ensure optimal performance and longevity of your product. This 2-piece unit combines rustic engineered wood with rattan mesh, offering a blend of natural vintage beauty and modern functionality for your entryway, hallway, living room, or closet.

Key features include a stable structure made from FSC-certified engineered wood, adjustable height shelves for versatile storage, a convenient bottom open shelf, and a spacious top surface for personal items.

2. Safety Information

WARNING: To prevent tipping, it is essential to securely attach the entryway cabinet to the wall using the provided anti-tip kits. Failure to do so may result in serious injury.

Always ensure all fasteners are tightened securely before use. Do not overload shelves. Keep small parts away from children during assembly.

3. Package Contents

Please verify that all parts and hardware are present before beginning assembly. Each part is numbered or lettered for easy identification.

Parts List (Panels)

- Panel 1: Top Panel
- Panel 2: Left Side Panel

- Panel 3: Right Side Panel
- Panel 4: Adjustable Shelves (Quantity: 2)
- Panel 5: Middle Vertical Panel
- Panel 6: Bottom Shelf
- Panel 7: Upper Back Panel
- Panel 8: Middle Back Support
- Panel 9: Lower Back Panel
- Panel 10: Left Door
- Panel 11: Right Door

Hardware List

- A: Cam Lock Bolts
- B: Cam Locks
- C: Wooden Dowels
- D: Wall Anchor Screws
- E: Wall Brackets
- F: Door Handles
- G: Handle Screws
- H: Back Panel Nails
- I: Magnetic Catches
- J: Magnetic Catch Screws
- K: Shelf Pins
- L: Hinges
- M: Hinge Screws
- N: Adjustable Feet
- P: Anti-Tip Kit (Straps)

4. Assembly Instructions

Follow these steps carefully. It is recommended to have two people for assembly.

Assembly Video Guide

▶ **Watch video online**
Assembly Instructions for Rattan Shoe Cabinet

Detailed video guide for assembling the SICOTAS Rattan Shoe Cabinet.

1. **Prepare the Top Panel (1):** Insert Cam Lock Bolts (A) into the designated holes on Panel 1. Attach Wall Brackets (E) to Panel 1 using screws (I). Secure Magnetic Catches (J) to Panel 1 using screws (I).
2. **Assemble Side Panels (2, 3) with Bottom Shelf (6) and Middle Vertical Panel (5):** Attach Cam Lock Bolts (A) to the bottom and middle sections of Side Panels (2 and 3). Connect the Bottom Shelf (6) and Middle Vertical Panel (5) to the Left Side Panel (2) using Wooden Dowels (C) and Cam Locks (B).
3. **Attach Back Support (8):** Secure the Middle Back Support (8) to the assembled structure using Cam Locks (B).

4. **Connect Right Side Panel (3):** Attach the Right Side Panel (3) to the assembled structure, securing it with Wooden Dowels (C) and Cam Locks (B).
5. **Install Adjustable Feet (N):** Screw the Adjustable Feet (N) into the bottom of the side panels (2 and 3).
6. **Attach Back Panels (7, 9):** Slide the Upper Back Panel (7) and Lower Back Panel (9) into the grooves on the back of the cabinet. Secure them using Back Panel Nails (H).
7. **Install Shelf Pins (K):** Insert Shelf Pins (K) into the desired holes on the side panels (2, 3) and middle vertical panel (5) to support the adjustable shelves.
8. **Place Adjustable Shelves (4):** Carefully place the Adjustable Shelves (4) onto the installed Shelf Pins (K).
9. **Attach Hinges (L) to Doors (10, 11):** Secure Hinges (L) to the Left Door (10) and Right Door (11) using Hinge Screws (M).
10. **Mount Doors (10, 11) to Cabinet:** Attach the doors (10, 11) to the cabinet frame by securing the hinges to the pre-drilled holes on the side panels using Hinge Screws (M). Adjust hinges as needed for proper door alignment.
11. **Install Door Handles (F):** Attach Door Handles (F) to the doors (10, 11) using Handle Screws (G).
12. **Final Step - Wall Anchoring:** For safety, attach the Anti-Tip Kit (P) to the back of the cabinet and secure it to a wall stud using Wall Anchor Screws (D).



Image: Fully assembled SICOTAS 2-Piece Shoe Storage Cabinet in Obsidian finish.

5. Operating Instructions

Adjustable Shelves

The cabinet features adjustable shelves to accommodate various shoe sizes and types, including flats, high heels, sneakers, and even knee-high boots. To adjust a shelf, remove any items, lift the shelf, reposition the shelf pins (K) to the desired height, and then place the shelf back onto the pins.



Image: Interior view of the cabinet showcasing adjustable and removable shelves.

Bottom Open Shelf

The bottom open shelf is designed for frequently worn shoes, providing easy access. It also allows for convenient cleaning underneath the cabinet.



Image: The bottom open shelf, ideal for daily footwear and allowing space for cleaning devices.

Top Surface

The spacious top surface can be used to hold keys, wallets, decorative items, or other personal belongings for quick access when entering or leaving your home.

6. Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Rattan Care:** The rattan elements can be gently wiped with a damp cloth. Avoid excessive moisture.

7. Troubleshooting

- **Wobbly Cabinet:** Ensure all cam locks and bolts are fully tightened. Verify that the adjustable feet are evenly extended to stabilize the unit on uneven floors.
- **Doors Not Aligning:** Adjust the hinges (L) on the doors (10, 11) to achieve proper alignment. Small adjustments to the hinge screws can correct gaps or unevenness.
- **Difficulty Closing Doors:** Check if any items inside the cabinet are obstructing the doors. Ensure the magnetic catches (J) are properly installed and aligned with the door.
- **Missing Parts:** If any parts are missing or damaged, please contact customer support immediately.

8. Specifications

Attribute	Detail
Brand	SICOTAS
Model Name	Shoe Storage Cabinet
Color	Obsidian
Material	Engineered Wood, Rattan
Product Dimensions (D x W x H)	14.17"D x 62.98"W x 38.97"H (for 2-piece unit)
Number of Tiers/Shelves	5 (including bottom open shelf)
Number of Doors	2 per cabinet (total 4 for 2-piece unit)
Installation Type	Freestanding
Required Assembly	Yes
Special Features	Adjustable Shelf, Rattan Doors, Anti-Tip Kit



Image: Detailed dimensions of a single SICOTAS Shoe Storage Cabinet.

9. Additional Product Videos

SICOTAS Rattan Shoe Cabinet Overview

▶ **Watch video online**

SICOTAS Rattan Shoe Cabinet

Video: A brief overview of the SICOTAS Rattan Shoe Cabinet, highlighting its design and features.

SICOTAS Rattan 5 Tier Shoe Cabinet Features

▶ **Watch video online**

SICOTAS Rattan 5 Tier Shoe Cabinet

Video: Showcasing the 5-tier design and storage capabilities of the SICOTAS Rattan Shoe Cabinet.

10. Customer Support

SICOTAS is committed to providing considerate customer support. If you encounter any problems during assembly or use of your shoe cabinet, please do not hesitate to contact us. Our team is ready to assist you.

For support, please visit the SICOTAS Store on Amazon or refer to your purchase documentation for direct contact information.

© 2026 SICOTAS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSKZ16ZR

More documents and user manuals: **https://manuals.plus/**