Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR 6077

VEVOR 4 Oz Popcorn Maker Instruction Manual

Model: 6077

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your VEVOR 4 Oz Popcorn Maker. Please read this manual thoroughly before first use and retain it for future reference.



Image: Front view of the VEVOR 4 Oz Popcorn Maker, showcasing its design and capacity for popped corn.

Safety Instructions

- Always ensure the popcorn maker is placed on a stable, level, and heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep hands and utensils away from the heating kettle during operation to prevent burns.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Components and Accessories

Your VEVOR Popcorn Maker comes with the following components and accessories:

- 1 x Popcorn Popper Machine
- 1 x Corn scoop
- 1 x Oil scoop
- 1 x Popcorn spatula
- 1 x Stirring stick assembly
- 1 x Pot lid assembly
- 1 x Popcorn shield (red)
- 1 x Pot assembly
- 1 x Instruction manual (this document)



Image: All included accessories for the popcorn maker, including scoops, spatula, and kettle components.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Placement:** Place the popcorn maker on a flat, stable, and heat-resistant countertop. Ensure there is adequate ventilation around the unit.
3. **Kettle Installation:** Ensure the pot assembly (kettle) is securely hung within the main unit. The stirring stick assembly should be properly connected to the motor.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the appliance.



Image: Close-up view of the kettle assembly inside the popcorn maker, showing the stirring mechanism.

Operating Instructions

1. **Preheat Kettle:** Close the magnetic door. Turn on the "HEAT" switch (usually red) to preheat the kettle for 3-5 minutes.

2. **Add Ingredients:** Once preheated, turn off the "HEAT" switch. Carefully open the kettle lid using the handle. Add the recommended amount of popcorn kernels (e.g., 4 oz) and oil (e.g., 1-2 tablespoons) to the kettle. Close the kettle lid.
3. **Start Popping:** Turn on both the "HEAT" and "TURN" (stirring) switches. The kettle will begin to heat and stir the kernels.
4. **Monitor Popping:** Popcorn will begin to pop and fall into the collection tray below. The internal light will illuminate the popcorn.
5. **Serving:** Once popping slows significantly (typically after 2-3 minutes), turn off both switches. Carefully open the magnetic door and use the provided popcorn scoop to serve the fresh popcorn.
6. **Empty Kettle:** Rotate the kettle handle to empty any remaining unpopped kernels or debris into the crumb tray.



Image: A hand pressing the power switch on the VEVOR Popcorn Maker, indicating ease of operation.

▶ **Watch video online**
VEVOR Tabletop Popcorn Popper Machine Red/Black

Video: This video demonstrates the VEVOR Popcorn Maker in operation, showing the popping process and serving of popcorn. It

highlights the machine's features and ease of use.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your popcorn maker.

1. **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Kettle Cleaning:** The stainless steel kettle features a nonstick coating. Remove the kettle from its hangers. Wipe the interior and exterior of the kettle with a damp cloth and mild detergent. Rinse thoroughly and dry completely. The wing nut on the kettle allows for easy removal of the lid for thorough cleaning.
3. **Crumb Tray:** The removable crumb tray at the bottom collects unpopped kernels and debris. Slide it out, empty its contents, and wash it with warm soapy water. Dry thoroughly before replacing.
4. **Exterior Cleaning:** Wipe the exterior surfaces of the machine, including the glass panels and red frame, with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
5. **Storage:** Store the popcorn maker in a clean, dry place when not in use.



Image: A hand cleaning the non-stick interior of the popcorn maker's kettle, demonstrating the ease of maintenance.

Troubleshooting

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power switch off; faulty outlet.	Ensure power cord is securely plugged in. Turn power switch to "ON". Test outlet with another appliance.
Popcorn not popping or very few kernels pop.	Insufficient preheating; old kernels; incorrect oil/kernel ratio.	Preheat kettle for 3-5 minutes. Use fresh popcorn kernels. Ensure correct oil and kernel measurements.
Popcorn burns.	Overheating; not emptying kettle promptly.	Turn off heat switch immediately after popping slows. Empty kettle after each batch.
Stirring arm not rotating.	"TURN" switch off; motor issue.	Ensure "TURN" switch is on. If problem persists, contact customer support.

Specifications

- **Brand:** VEVOR
- **Model Number:** 6077
- **Power:** 480W
- **Kettle Capacity:** 4 ounces
- **Batch Output:** Approximately 1.5 Gallons (4 quarts) per batch
- **Material:** Cold-rolled plate frame, Stainless steel kettle with non-stick coating
- **Color:** Red
- **Item Dimensions (L x W x H):** 10.8" x 9.4" x 19" (275mm x 240mm x 485mm)
- **Item Weight:** 7.28 lbs (3.3 kg)
- **UPC:** 197988482314





Image: Diagram showing the dimensions and key specifications of the VEVOR Popcorn Maker.

Warranty and Support

VEVOR products are designed for durability and performance. For warranty information, technical support, or service inquiries, please refer to the official VEVOR website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

You can visit the VEVOR Store for more information:VEVOR Official Store

© 2026 VEVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What is the voltage for the VEVOR 6077 popcorn machine? Is it 110V or 220V?

Based on the product specifications for the VEVOR 4 Oz Popcorn Maker (Model 6077), the machine operates at 480W. While the manual text provided does not explicitly state a single voltage for all regions,...

Read full answer

Open the live page

https://manuals.plus/asin/B0DSVJDG2Z

More documents and user manuals: **https://manuals.plus/**