Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giftsfaloy 8L

Giftsfaloy 2 Gallon Battery Powered Garden Sprayer (Model 8L) - Instruction Manual

Brand: Giftsfaloy | Model: 8L

Introduction

Thank you for choosing the Giftsfaloy 2 Gallon Battery Powered Garden Sprayer. This electric sprayer is designed to simplify your gardening tasks with its convenient USB-rechargeable handle, adjustable nozzles, and retractable wand. This manual provides essential information for safe and efficient operation, setup, maintenance, and troubleshooting.

Important Safety Information

Do not use with flammable, corrosive, or acidic chemicals. This sprayer is intended for use with water-based garden solutions only.

Package Contents

Please ensure all items are present before assembly:

- 2 Gallon Sprayer Tank
- Electric Handle with USB Charging Port and Battery Indicator
- Telescopic Wand
- Hose with Filter Head
- 3 Mist Nozzles (Sector, Cone, Six-Hole)
- Adjustable Shoulder Strap
- USB Charging Cable



Image: All components of the Giftsfaloy 2 Gallon Battery Powered Garden Sprayer included in the package.

Setup Guide

Follow these steps to assemble your sprayer:

1. **Attach Sprinkler Nozzle to Telescopic Rod:** Screw the desired nozzle onto the end of the telescopic rod.
2. **Connect Telescopic Rod to Electric Handle:** Attach the telescopic rod to the electric handle and tighten securely.
3. **Connect Hose:** Attach one end of the hose to the electric handle and the other end to the sprayer tank's outlet. Ensure both connections are tight to prevent leaks.
4. **Insert Suction Pipe:** Insert the suction pipe into the water tank and tighten the nut.
5. **Screw on the Lid:** Place the lid onto the tank and screw it on tightly.
6. **Attach Adjustable Shoulder Strap:** Fasten the mental buckles of the shoulder strap to the designated eyelet holes on the sprayer tank.



Image: Visual guide illustrating the assembly steps for the sprayer.

▶ **Watch video online**

2 Gallon Electric Sprayer

Video: A seller demonstration of the sprayer assembly process, showing how to connect the handle, wand, hose, and strap.

Charging the Battery

The sprayer features a 2200mAh built-in battery in the electric handle. Fully charge the battery before first use. The USB-C charging port is located on the handle, and an indicator light tracks battery power. A full charge typically takes 3.5 hours and provides 2.5-3 hours of continuous spraying.



Image: Close-up of the electric handle showing the USB charging port and battery level indicator.

Filling the Sprayer

The sprayer has a 2-gallon capacity. To fill, unscrew the lid and pour your water-based solution into the wide opening. The scaled water tank allows you to monitor the remaining solution for better work planning.



Image: The sprayer tank featuring a clear volume scale to help measure liquid levels.

Operating Instructions

Once assembled and filled, simply press the power button on the electric handle to begin spraying automatically. No manual pumping is required.

Adjusting Spray Modes

The sprayer comes with three interchangeable nozzles, offering five different spray modes to suit various needs:

- **Sector Nozzle:** Provides a wide, flat spray pattern, ideal for covering larger areas like lawns.
- **Cone Nozzle:** Delivers a conical mist, suitable for delicate plants or general coverage.
- **Six-Hole Nozzle:** Offers a gentle, shower-like spray, perfect for watering hanging baskets or sensitive foliage.

To adjust the intensity or pattern of the spray, twist the tightness of the nozzle head. This allows you to switch between fine mist and powerful stream settings.



Image: The three distinct nozzle types included with the sprayer, each offering a unique spray pattern.



Image: A user demonstrating the electric garden sprayer in action, highlighting its ease of use for various garden tasks.

▶ **Watch video online**

NO PUMP Power Sprayer for Garden & Lawn 5 Nozzles + Wand

Video: A seller demonstration showcasing the sprayer's operation and the different spray patterns from various nozzles.

Telescopic Wand

The telescopic rod can extend up to 23.62 inches, allowing you to easily reach and spray hard-to-access areas without excessive bending or stretching. To adjust the length, loosen the nut, extend the wand to the desired length, and then tighten the nut to secure it.



Image: Instructions for extending and securing the telescopic wand for optimal reach.

Carrying Options

The sprayer is designed for portability during long-term outdoor work. It can be carried by hand using the integrated handle on the lid or worn over the shoulder using the adjustable shoulder strap for hands-free operation.



Image: Demonstrating the two convenient ways to carry the sprayer: using the top handle or the adjustable shoulder strap.

Maintenance and Care

- After each use, rinse the sprayer thoroughly with clean water and drain completely to prevent residue buildup and blockages.
- When storing the sprayer for extended periods, ensure the battery is fully charged. Recharge the battery every two months to maintain its health.
- Do not use fast charging methods; if the battery is completely depleted, charge slowly first.
- Store the sprayer in a cool, dry place away from direct sunlight and extreme temperatures.



Image: Key points for attention, including charging instructions and post-use cleaning.

Troubleshooting

If you encounter issues with your sprayer, consider the following:

- **No Spray/Weak Spray:** Check if the battery is charged. Ensure all connections (hose, nozzle) are tight. Verify the filter head is not blocked.
- **Leaking:** Confirm all nuts and connections are securely tightened. Check for any damage to the hose or seals.
- **Battery Not Charging:** Ensure the USB cable is properly connected to both the handle and a power source. Try a different USB-C cable or power adapter.

Product Specifications

Feature	Specification
Brand	Giftsfaloy
Model Name	8L
Tank Volume	2 Gallons
Color	Blue-green
Power Source	Battery Powered (2200mAh)

Working Time	2.5-3 hours (continuous)
Charging Time	Approx. 3.5 hours
Nozzles Included	3 (Sector, Cone, Six-Hole)
Telescopic Rod Length	Up to 23.62 inches
Material	Acrylonitrile Butadiene Styrene (ABS), High Density Polyethylene (HDPE)
Item Weight	1.21 Pounds
Product Dimensions	6.3"W x 12"H

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Giftsfaloy customer service directly. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I obtain extra spraying tips for the Giftsfaloy 8L Battery Powered Garden Sprayer, specifically the cone-shaped nozzle?

To obtain extra or replacement spraying tips for your Giftsfaloy 8L Battery Powered Garden Sprayer, you should follow these steps: Contact the Manufacturer: The manual recommends contacting Giftsfaloy customer service directly for technical support...

Read full answer

What is the estimated maximum spray distance for the Giftsfaloy 2-Gallon Battery Powered Garden Sprayer cone nozzle, and can it reach 25 feet?

Based on the product specifications for the Giftsfaloy 2 Gallon Battery Powered Garden Sprayer (Model 8L), the manual does not explicitly state a maximum spray distance in feet. However, it is important to note...

Read full answer

Open the live page

https://manuals.plus/asin/B0DSVJGZRV

More documents and user manuals: **https://manuals.plus/**