Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MND23-BK

Minolta 48MP Digital Camera User Manual

Model: MND23-BK | Brand: Minolta

1. Introduction

The Minolta MND23-BL Digital Camera combines high-end imaging power with a user-friendly design to deliver an outstanding photography experience in any setting. Whether you're a hobbyist, traveler, or content creator, this camera offers premium features in a compact, easy-to-use package. With a 48-megapixel CMOS sensor, you'll capture crystal-clear photos with rich detail and vibrant color, ready for editing or printing without losing sharpness. The 4K Ultra HD video recording capability lets you shoot cinematic footage with stunning realism, while digital image stabilization helps reduce blur—even during handheld recording. The MND23's rear selfie lens is a standout feature, enabling you to snap sharp, well-lit selfies without needing extra equipment. Autofocus technology keeps your subjects in sharp focus, whether you're filming on the go or capturing stills in dynamic environments. Take full creative control with features like Slow Motion Recording, Time Lapse, and customizable Color Filters. Choose from nine scene modes that optimize camera settings for conditions like landscapes, portraits, or night shots—so your photos always look their best. The 16X digital zoom lets you get closer to the action without losing image quality, and the 2.8" LCD screen provides a clear, responsive view for framing and playback. Perfect for beginners and casual photographers alike, this camera offers a seamless blend of simplicity and performance. It includes everything needed to start shooting right away—a 32GB memory card, rechargeable battery, USB cable, protective pouch, and carrying strap. Compact, stylish, and reliable, the Minolta MND23-BL is your all-in-one solution for capturing everyday moments and extraordinary adventures in breathtaking detail.

Key Features:

- **48 MP High-Resolution Photos:** Capture strikingly detailed 48MP photos with vivid color and clarity.
- **Ultra HD Video Recording:** Shoot lifelike videos in stunning 4K Ultra HD quality.
- **Rear Selfie Lens & Autofocus:** Ensures effortless self-portraits with sharp focus and natural lighting.
- **Smart Features:** Enjoy versatile tools like Slow Motion, Time Lapse, Color Filters, Digital Image Stabilization, and 9 Scene Modes.
- **Complete Package:** Includes a 32GB memory card, rechargeable lithium-ion battery, USB cable, pouch, and wrist strap.

2. What's in the Box

Your Minolta 48MP Digital Camera package includes the following items:

- Minolta MND23 Digital Camera Body
- 32GB Memory Card
- Rechargeable Lithium-Ion Battery
- USB Cable
- Protective Pouch
- Carrying Strap
- User Manual



Image: All items included in the Minolta 48MP Digital Camera package.

3. Setup

3.1 Charging the Battery

1. Insert the rechargeable lithium-ion battery into the camera's battery compartment. Ensure it clicks into place.
2. Connect the camera to a power source using the provided USB cable and power adapter.

3. The charging indicator light will illuminate. Charging is complete when the light turns off or changes color (refer to camera display for exact status).

3.2 Inserting the Memory Card

1. Locate the memory card slot on the side of the camera.
2. Insert the 32GB memory card with the metal contacts facing the correct direction (usually towards the front of the camera). Push until it clicks into place.
3. To remove, gently push the card in again until it springs out.

3.3 Powering On/Off

- To power on, press and hold the Power button located on the top of the camera.
- To power off, press and hold the Power button again until the screen turns off.



Image: Front and rear views of the Minolta MND23 Digital Camera, highlighting key components.

4. Operating Instructions

4.1 Taking Photos

1. Turn on the camera.
2. Frame your shot using the 2.8-inch LCD screen.
3. Press the Shutter button halfway down to activate autofocus.
4. Once focused, press the Shutter button all the way down to capture the image.



Image: Capturing a detailed 48MP photo with the Minolta camera.

4.2 Recording 4K Ultra HD Video

1. Switch the camera to video mode (usually via a dedicated button or menu option).
2. Press the Record button to start recording. Press again to stop.
3. Ensure sufficient lighting for optimal 4K video quality.

4.3 Using the Rear Selfie Lens and Autofocus

The camera features a dedicated rear selfie lens for easy self-portraits and vlogging. The autofocus system ensures your subjects remain sharp.



Image: Utilizing the dedicated selfie lens for self-portraits.



Image: Capturing group photos with face and smile detection.

4.4 Special Features

- **Slow Motion Recording:** Capture dramatic slow-motion video for creative effects.
- **Time Lapse:** Condense long events into short, captivating videos.
- **Color Filters:** Apply various color filters to enhance the mood and style of your photos and videos.
- **Digital Image Stabilization:** Reduces blur caused by camera shake, especially useful during handheld recording.
- **Scene Modes:** Choose from 9 optimized scene modes (e.g., Landscape, Portrait, Night) to automatically adjust camera settings for different environments.
- **16X Digital Zoom:** Magnify your subject up to 16 times for closer shots. Note that digital zoom may reduce image quality compared to optical zoom.

4.5 Webcam Functionality

The Minolta MND23 can be used as a webcam for video calls or streaming. Connect the camera to your computer using the USB cable. Select the camera as your video input device in your communication software.



Image: Using the Minolta camera as a webcam for remote meetings or streaming.

5. Maintenance

5.1 Cleaning the Camera

- Use a soft, lint-free cloth to gently wipe the camera body.
- For the lens and LCD screen, use a specialized lens cleaning cloth and solution. Avoid abrasive materials.
- Do not use organic solvents or strong chemicals for cleaning.

5.2 Battery Care

- Charge the battery fully before first use.
- Store the battery in a cool, dry place when not in use.
- Avoid exposing the battery to extreme temperatures.

5.3 Storage

- When storing the camera for extended periods, remove the battery.
- Keep the camera in its protective pouch to prevent dust and scratches.
- Store in a dry environment, away from direct sunlight and high humidity.

6. Troubleshooting

Problem	Possible Cause	Solution
Camera does not turn on.	Battery is depleted or not inserted correctly.	Charge the battery fully. Ensure the battery is inserted with correct polarity.
Photos are blurry.	Insufficient lighting, camera shake, or subject out of focus.	Ensure adequate lighting. Hold the camera steady or use a tripod. Allow autofocus to lock before pressing the shutter fully.
Memory card error.	Card not inserted correctly, card is full, or card is corrupted.	Reinsert the memory card. Delete unnecessary files or use a new card. Format the card (this will erase all data).
Short battery life.	Frequent use of flash, video recording, or cold environment.	Reduce flash usage. Limit continuous video recording. Keep battery warm in cold conditions.

7. Specifications

Feature	Detail
Model Name	MND23-BK
Maximum Webcam Image Resolution	48 MP
Effective Still Resolution	48 MP
Video Resolution	4320p (4K Ultra HD)
Optical Zoom	1x
Digital Zoom	16x
Screen Size	2.8 Inches
Display Type	LCD
Photo Sensor Technology	CMOS
Memory Storage Capacity	32 GB (included)
Battery Type	Lithium Ion
Connectivity Technology	USB
Autofocus	Yes
Image Stabilization	Yes
File Format	JPEG

Feature	Detail
Water Resistance Level	Not Water Resistant

8. Warranty and Support

8.1 Manufacturer's Warranty

The Minolta 48MP Digital Camera comes with a**1 Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Minolta customer support. Visit the official Minolta website for the most up-to-date contact information and support resources.
You can also find additional information and FAQs on theMinolta Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question