Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MND23-BL

Minolta 48MP Digital Camera User Manual

Model: MND23-BL

1. Overview

The Minolta MND23-BL Digital Camera is designed to provide a high-quality photography and videography experience in a compact and user-friendly package. Featuring a 48-megapixel CMOS sensor and 4K Ultra HD video recording, it captures clear, vibrant images and stunning footage. Its intuitive design, including a rear selfie lens and autofocus, makes it suitable for both beginners and casual photographers.

Key Features:

- **48 MP High-Resolution Photos:** Capture strikingly detailed 48MP photos with vivid color and clarity.
- **4K Ultra HD Video Recording:** Shoot lifelike videos in stunning 4K Ultra HD quality.
- **Rear Selfie Lens & Autofocus:** Ensures effortless self-portraits with sharp focus and natural lighting.
- **Smart Features:** Includes Slow Motion, Time Lapse, Color Filters, Digital Image Stabilization, and 9 Scene Modes.
- **Complete Package:** Comes with a 32GB memory card, rechargeable battery, USB cable, pouch, and wrist strap.

2. What's in the Box

Verify that all the following items are included in your Minolta MND23-BL Digital Camera package:

- Minolta MND23-BL Digital Camera
- 32GB Memory Card
- Rechargeable Lithium-Ion Battery
- USB Cable

- Protective Pouch
- Wrist Strap
- User Manual
- AC Adapter



Image: Minolta MND23 Digital Camera and its complete set of accessories.

3. Product Components

Familiarize yourself with the various parts of your Minolta MND23-BL Digital Camera.



Image: Front and Rear views of the Minolta MND23-BL Digital Camera.

Front View:

- **Lens:** Main optical component for capturing images.
- **Flash:** Provides illumination in low-light conditions.
- **Microphone:** Records audio during video recording.

Rear View:

- **LCD Screen:** Displays live view, menus, and playback.
- **Selfie Lens:** Dedicated lens for self-portraits.
- **Control Buttons:** Navigation, menu, mode, zoom, and playback controls.
- **Shutter Button:** Captures photos.
- **Video Record Button:** Starts and stops video recording.

4. Getting Started

Battery Installation:

1. Open the battery compartment cover located on the bottom of the camera.
2. Insert the rechargeable lithium-ion battery, ensuring the correct orientation as indicated inside the compartment.
3. Close the battery compartment cover securely until it clicks into place.

Memory Card Insertion:

1. Locate the memory card slot, usually next to the battery compartment.
2. Insert the 32GB memory card with the metal contacts facing the correct direction (refer to the diagram near the slot).
3. Push the card gently until it clicks into place. To remove, push it again until it springs out.

Charging the Battery:

1. Connect the USB cable to the camera's USB port.
2. Connect the other end of the USB cable to the provided AC adapter.
3. Plug the AC adapter into a power outlet. The charging indicator light will illuminate.
4. Charging is complete when the indicator light turns off or changes color (refer to camera display for exact status).

5. Operating the Camera

Power On/Off:

Press and hold the Power button (usually located on the top or rear of the camera) for a few seconds to turn the camera on or off.

Taking Photos:

1. Turn on the camera.
2. Frame your shot using the LCD screen.
3. Press the Shutter button halfway down to allow the camera to autofocus. A green frame indicates focus lock.
4. Press the Shutter button all the way down to capture the photo.

Recording Videos:

1. Turn on the camera.
2. Press the dedicated Video Record button to start recording. A red indicator or timer will appear on the screen.
3. Press the Video Record button again to stop recording.

Using the Rear Selfie Lens:

The Minolta MND23-BL features a rear selfie lens for convenient self-portraits and vlogging. To activate, switch to selfie mode via the 'Mode' button or a dedicated 'Selfie' button on the camera's rear controls. The LCD screen will typically flip or adjust to face forward, allowing you to frame yourself.



Image: Dedicated Selfie Lens in use, perfect for vlogging and self-portraits.

Digital Zoom:

Use the zoom controls (often marked 'W' for Wide and 'T' for Telephoto) to adjust the 16X digital zoom. Press 'T' to zoom in on your subject and 'W' to zoom out. Note that digital zoom may reduce image quality compared to optical zoom.



Image: Demonstration of 16X Digital Zoom, extending your reach.

Scene Modes:

The camera offers nine scene modes to optimize settings for different shooting conditions. Access these modes via the 'Mode' button and navigate through options like Landscape, Portrait, Night Shot, Sports, etc. Select the mode that best suits your environment for optimal results.

Special Features:

- **Slow Motion Recording:** Capture dramatic slow-motion video by selecting the Slow Motion option in video mode.



Image: Slow Motion recording, turning ideas into reality.

- **Time Lapse:** Create captivating time-lapse videos by setting the interval and duration in the camera's menu.



Image: Time-Lapse photography, capturing changes over time.

- **Color Filters:** Apply various color filters to your photos and videos directly from the camera's settings to enhance mood or style.

Webcam Functionality:

The Minolta MND23-BL can be used as a webcam for video calls or streaming. Connect the camera to your computer using the USB cable. Select 'Webcam Mode' on the camera's display when prompted, or through the camera's settings menu. Your computer should then recognize it as a webcam device.



Image: Webcam Versatility, great for remote meetings and content creation.

6. Maintenance and Care

General Care:

- Keep the camera clean by wiping it with a soft, dry cloth.
- Avoid exposing the camera to extreme temperatures, humidity, dust, or direct sunlight for prolonged periods.
- Use the protective pouch when transporting the camera to prevent scratches and impacts.

Cleaning the Lens and Screen:

- For the lens, use a lens brush or a soft, lint-free microfiber cloth specifically designed for optical surfaces. Gently wipe in a circular motion.
- For the LCD screen, use a clean, soft cloth. For stubborn smudges, a screen cleaning solution designed for

electronics can be used sparingly.

- Never use abrasive cleaners or solvents on any part of the camera.

Battery Care:

- Fully charge the battery before first use.
- Store the battery in a cool, dry place when not in use.
- If the camera will not be used for an extended period, remove the battery to prevent leakage.

7. Troubleshooting Guide

Problem	Possible Cause	Solution
Camera does not turn on.	Battery is low or not inserted correctly.	Charge the battery fully. Reinsert the battery correctly.
Images are blurry.	Lens is dirty; camera not focusing; insufficient light; camera shake.	Clean the lens. Ensure autofocus locks before shooting. Use flash in low light. Hold camera steady or use a tripod.
Cannot record video.	Memory card is full or not inserted.	Delete unnecessary files or insert a new memory card. Ensure card is properly inserted.
Battery drains quickly.	Frequent use of flash, LCD screen, or video recording. Old battery.	Reduce flash usage. Decrease screen brightness. Consider replacing old battery.
Camera freezes.	Software glitch or memory card issue.	Remove and reinsert the battery. Format the memory card (backup data first).

8. Technical Specifications

Feature	Specification
Brand	Minolta
Model Name	MND23-BL
Maximum Webcam Image Resolution	48 MP
Photo Sensor Technology	CMOS

Feature	Specification
Photo Sensor Resolution	48 MP
Video Resolution	4320p (4K Ultra HD)
Optical Zoom	1 x
Digital Zoom	16X
Image Stabilization	Digital
Screen Size	2.8 Inches
Display Type	LCD
Memory Storage Capacity	32 GB (included)
Battery Type	Lithium Ion
Connectivity Technology	USB
Supported File Format	JPEG
Focal Length	3.37mm
Aperture	F2.2
Color	Blue

9. Warranty and Support

Warranty Information:

The Minolta MND23-BL Digital Camera comes with a **1 Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, troubleshooting beyond this guide, or warranty inquiries, please visit the official Minolta website or contact their customer support. Refer to the packaging or the official Minolta website for the most current contact information.

You can also visit the Minolta Store on Amazon for additional product information and support resources.

© 2025 Minolta. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT56W1FH

More documents and user manuals: **https://manuals.plus/**