Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Inalsa Robot Inox 1350 Blend N Forth

INALSA Robot INOX 1350 Blend N Froth Hand Blender Mixer User Manual

Model: Robot Inox 1350 Blend N Forth

1. Important Safeguards

Please read all instructions carefully before using the appliance and retain them for future reference. Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Do not immerse the motor unit, cord, or plug in water or other liquids.
- **Children and Vulnerable Persons:** This appliance should not be used by children. Close supervision is necessary when any appliance is used near children.
- **Blades and Moving Parts:** Blades are sharp. Handle with extreme care. Avoid contact with moving parts during operation.
- **Usage Environment:** Do not use the appliance outdoors. Place the appliance on a stable, flat, heat-resistant surface.
- **Maintenance:** Unplug from the outlet before cleaning or when not in use. Do not attempt to repair the appliance yourself; contact qualified service personnel.
- **Overheating:** Do not operate the appliance continuously for more than 1 minute. Allow it to cool down before resuming use.

2. Product Overview

The INALSA Robot INOX 1350 Blend N Froth is a versatile hand blender designed for various kitchen tasks. Familiarize yourself with its components:



Figure 2.1: Overview of the INALSA Hand Blender and its versatile attachments.

Included Components:

- **Motor Unit:** The main body containing the 1350W motor, speed control, and turbo button.
- **Stainless Steel Blending Stem:** For blending soups, smoothies, and purees.
- **Whisk Attachment:** For whipping cream, beating eggs, and mixing batters.
- **Frother Attachment:** For frothing milk for coffee and other beverages.
- **Chopper Attachment (650 ml):** Includes a chopper jar, lid, and stainless steel chopping blade for mincing, chopping, and dicing.
- **Multipurpose Jar (900 ml):** For measuring and blending ingredients.

3. Setup and Assembly

Before first use, clean all detachable parts as described in the 'Cleaning and Maintenance' section.

3.1 Attaching the Blending Stem

1. Align the blending stem with the motor unit.
2. Twist the blending stem clockwise until it locks securely into place.
3. To detach, twist counter-clockwise and pull apart.



Figure 3.1: Securely attach the blending stem to the motor unit.

3.2 Assembling the Chopper Attachment

1. Carefully place the chopping blade onto the central pin inside the chopper jar.
2. Add ingredients to the chopper jar. Do not overfill.
3. Place the chopper lid onto the jar, ensuring it is properly seated.
4. Attach the motor unit to the chopper lid by aligning and twisting clockwise until it locks.



Figure 3.2: The chopper attachment assembled and ready for use.

3.3 Attaching the Whisk and Frother

1. Insert the whisk or frother into its respective gear box.
2. Align the gear box with the motor unit and twist clockwise until it locks.



Figure 3.3: The whisk attachment connected to the motor unit.

4. Operating Instructions

Always ensure the appliance is unplugged before attaching or detaching accessories.

4.1 Power and Speed Control



Figure 4.1: The powerful 1350W motor for efficient processing.

- **Variable Speed Control:** The motor unit features a dial with 20 speed settings. Rotate the dial to select the desired speed for your ingredients. Lower speeds are suitable for softer ingredients or gentle mixing, while higher speeds are for tougher ingredients or faster processing.
- **Turbo Mode:** For an instant burst of maximum power, press and hold the 'Turbo' button. This is useful for quickly processing stubborn ingredients or achieving a finer consistency.



Figure 4.2: Digital display for speed control and turbo function.

4.2 Blending

1. Attach the blending stem to the motor unit.
2. Place ingredients in a tall container or the multipurpose jar.
3. Immerse the blending head into the ingredients before switching on.
4. Plug in the appliance. Select desired speed and press the power button to operate. Move the blender up and down gently for even blending.
5. Release the power button to stop. Unplug before removing the blender from the container.



Figure 4.3: The anti-splash design minimizes mess during blending.

4.3 Chopping

1. Assemble the chopper attachment as described in Section 3.2.
2. Ensure the chopper lid is securely in place and the motor unit is attached.
3. Plug in the appliance. Press the power button in short pulses for coarse chopping, or hold for finer results.
4. Release the power button to stop. Unplug before disassembling.

4.4 Whisking

1. Attach the whisk attachment to the motor unit.
2. Place ingredients in a bowl.
3. Plug in the appliance. Immerse the whisk into the ingredients.
4. Select a low speed initially, then gradually increase as needed.
5. Release the power button to stop. Unplug before removing the whisk.



Figure 4.4: The whisk attachment is ideal for whipping and beating.

4.5 Frothing

1. Attach the frother attachment to the motor unit.
2. Immerse the frother head just below the surface of the milk or liquid.
3. Plug in the appliance. Press the power button and move the frother gently up and down to create foam.
4. Release the power button to stop. Unplug before removing the frother.



Figure 4.5: Achieve perfect froth for beverages with the frother attachment.

5. Cleaning and Maintenance

Proper cleaning and maintenance ensure the longevity and optimal performance of your appliance.

- **Always unplug** the appliance from the power outlet before cleaning.
- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
- **Detachable Parts:** The blending stem, whisk, frother, chopper jar, chopper lid, chopping blade, and multipurpose jar are dishwasher safe. Alternatively, they can be washed by hand in warm, soapy water. Rinse thoroughly and dry immediately.
- **Blades:** Handle the chopping blade and blending stem blades with extreme care as they are very sharp.
- **Storage:** Store the appliance and its accessories in a dry place, away from direct sunlight and out of reach of children.

6. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; motor unit not properly attached to accessory.	Check power connection; test outlet with another device; ensure accessories are securely locked.
Motor stops during operation.	Overheating due to prolonged use or processing too hard ingredients; too much load.	Unplug and let cool for 15-20 minutes. Reduce ingredient quantity or cut into smaller pieces.

Problem	Possible Cause	Solution
Ingredients not blending/chopping effectively.	Too little liquid; ingredients too large; blades dull or obstructed.	Add more liquid; cut ingredients into smaller pieces; ensure blades are clear.
Excessive vibration or noise.	Accessory not properly attached; appliance not on a stable surface.	Re-attach accessory securely; place appliance on a flat, stable surface.

7. Specifications

Model Number	Robot Inox 1350 Blend N Forth
Power	1350W
Voltage	220-240V ~ 50/60Hz
Speed Settings	20 Variable Speeds + Turbo Mode
Chopper Capacity	650 ml
Multipurpose Jar Capacity	900 ml
Material	Stainless Steel (blending stem, blades, whisk), BPA-Free Plastic (jars)
Dimensions (Product)	6.5D x 8W x 41.8H Centimeters
Weight	1340 Grams

8. Warranty and Customer Support

Your INALSA Robot INOX 1350 Blend N Froth Hand Blender Mixer comes with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

The warranty does not cover:

- Damage caused by misuse, abuse, neglect, or accident.
- Normal wear and tear.
- Damage resulting from unauthorized repairs or modifications.

For warranty claims, technical assistance, or any product-related inquiries, please contact INALSA customer support. Keep your purchase receipt as proof of purchase.

Manufacturer: Tuareg Marketing Pvt. Ltd.

Contact Information: Refer to the contact details provided on the product packaging or the official Inalsa website for the most current support information.

© 2026 Inalsa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DYVHTX9M

More documents and user manuals: **https://manuals.plus/**