Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paladone 14710

Paladone Minecraft Creeper SquishyGlo Silicone Light User Manual

Model: 14710

Introduction

Thank you for purchasing the Paladone Minecraft Creeper SquishyGlo Silicone Light. This product is designed to provide a soft, adjustable light source with a unique, squishy texture, inspired by the iconic Minecraft Creeper character. This manual will guide you through the setup, operation, and maintenance of your new light.

Important Safety Information

- Keep this product away from water and excessive moisture.
- Do not attempt to disassemble or modify the light. This may cause damage and void the warranty.
- Use only the provided charging cable or a compatible USB charger.
- This product is not a toy. Adult supervision is recommended for young children.
- Avoid prolonged exposure to direct sunlight or extreme temperatures.

Package Contents

Ensure all items are present before proceeding with setup:

- 1 x Minecraft Creeper SquishyGlo Silicone Light
- 1 x USB Charging Cable
- 1 x Instruction Manual (this document)



The Minecraft Creeper SquishyGlo Silicone Light as packaged.

Setup

1. Initial Charging

Before first use, fully charge the Creeper light. Connect the provided USB charging cable to the charging port located at the base of the light and plug the other end into a compatible USB power source (e.g., computer, USB wall adapter). The light will indicate charging status (e.g., a red light may appear and turn off when fully charged).



The flexible silicone material allows for interaction, such as tapping to adjust brightness.

2. Base Assembly (if applicable)

The light consists of a soft silicone Creeper shell and a light base. Ensure the light base is securely seated within the silicone shell. If the base becomes loose, gently re-insert it into the silicone housing.

▶ **Watch video online**
Paladone Minecraft Creeper SquishyGlo Silicone Light

Official Paladone video demonstrating the Creeper light's features, including charging and operation.

Operating Instructions

1. Power On/Off

Locate the power switch at the bottom of the light base. Slide the switch to the 'ON' position to activate the light. To turn off, slide the switch to 'OFF'.



The Creeper light in its off state.

2. Adjusting Brightness

Once powered on, gently tap the silicone body of the Creeper light to cycle through different brightness levels. The light typically offers multiple brightness settings (e.g., 50%, 75%, 100%) and a pulsing mode.



The Creeper light glowing at an activated brightness level.

3. Auto-Off Timer

The light features an auto-off timer function. On the base, you can select a timer setting (e.g., 1 hour or 3 hours). When activated, the light will automatically turn off after the selected duration, conserving battery life.

Maintenance

Cleaning

To clean the silicone body, gently wipe it with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the charging port and base are dry before charging or operating.

Battery Care

To prolong battery life, avoid completely draining the battery frequently. Recharge the light when the brightness noticeably diminishes. If storing for an extended period, charge the light fully before storage and recharge every few

months.

Troubleshooting

- **Light does not turn on:**
  Ensure the power switch on the base is in the 'ON' position. Check if the battery is charged; connect to a power source using the USB cable.
- **Light does not hold a charge:**
  Verify the charging cable is securely connected to both the light and the power source. If the issue persists after several charging cycles, the battery may require service.
- **Light base becomes loose from silicone shell:**
  Due to the squishy nature of the silicone, the internal light base can sometimes shift. Gently remove the silicone shell, reposition the light base, and carefully re-seat the shell around it.
- **Brightness adjustment is unresponsive:**
  Ensure the light is fully charged. If the issue continues, try turning the light off and on again.

Specifications

Feature	Detail
Model Number	14710
Dimensions (D x W x H)	5.31" x 4.92" x 6.1" (13.5cm x 12.5cm x 15.5cm)
Item Weight	200 Grams
Material Type	Silicone
Light Source Type	LED
Power Source	Battery Powered (Rechargeable)
Additional Features	Cordless, Rechargeable, Touch Sensor, Auto-Off Timer



Key dimensions of the Minecraft Creeper SquishyGlo Silicone Light.

Warranty and Support

Paladone products are manufactured to high standards. For any questions, technical support, or warranty inquiries, please contact Paladone customer service through their official website or the retailer from whom the product was purchased. Please retain your proof of purchase for warranty claims.
For more information, visit: Paladone Official Store

© 2026 Paladone. All rights reserved. Minecraft is a trademark of Mojang Synergies AB.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZ6Q36G1

More documents and user manuals: **https://manuals.plus/**