Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DERCASS N708P248523

DERCASS Wood Bunk Bed with Tent Instruction Manual

Model: N708P248523

1. Important Safety Information

Please read all instructions carefully before assembling and using this bunk bed. Keep this manual for future reference.

- **Age Recommendation:** This bunk bed is recommended for users over 6 years old.
- **Weight Capacity:** The upper bed has a maximum weight capacity of 250 lbs (113 kg). Do not exceed this limit.
- **Mattress Thickness:** For the upper bed, use a mattress with a thickness between 4 to 6 inches (10-15 cm). Ensure the mattress surface is at least 5 inches (12.7 cm) below the top edge of the guardrails.
- **Guardrails:** Always use the guardrails on the upper bunk. Ensure they are properly installed and secured.
- **Ladder Safety:** Use the ladder for entry and exit from the upper bunk. Do not use the bed as a climbing frame.
- **No Jumping:** Do not allow jumping on the bed.
- **Assembly:** Ensure all parts are correctly assembled and all fasteners are tightened before use. Periodically check and re-tighten fasteners as needed.
- **Ventilation:** The semi-enclosed space under the bed is designed to ensure air circulation. Do not obstruct ventilation.

2. Setup and Assembly

Assembly of the DERCASS Wood Bunk Bed with Tent is required. All necessary hardware and tools are provided. It is recommended to assemble the bed with two adults.

2.1. Included Components

- Bed Frame (Plywood + Pinewood)
- Hardware (screws, bolts, etc.)
- Ladder
- Roof/Tent Fabric
- Slats (Plywood)

2.2. Assembly Steps (General)

1. Unpack all components and verify against the parts list provided in the separate assembly instructions.
2. Assemble the main bed frame structure according to the detailed diagrams.
3. Attach the ladder securely to the bed frame.
4. Install the plywood slats onto the bed frame to support the mattress.
5. Attach the tent fabric to the roof structure of the bed. The tent can be assembled or omitted based on preference.
6. Ensure all connections are tight and stable before use.



Figure 1: Overall dimensions of the bunk bed. Length: 78.8 inches, Width: 41.5 inches, Height: 79.1 inches.

3. Operating Instructions

This bunk bed is designed for sleeping and provides an additional semi-enclosed space underneath for play or storage.

- **Upper Bunk Usage:** Access the upper bunk using the provided ladder. Ensure the user meets the age and weight recommendations.

- **Lower Space Usage:** The area beneath the upper bunk can be used as a play area or for storage. The tent provides a unique environment.
- **Tent Feature:** The tent is an optional aesthetic and functional addition. It can be removed or reattached as desired.



Figure 2: Front view of the DERCASS bunk bed, showcasing the ladder and tent design.



Figure 3: Detail of the tent fabric attachment points on the bed frame.

4. Maintenance

Proper maintenance ensures the longevity and safety of your bunk bed.

- **Cleaning:** Wipe the wood surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Fastener Checks:** Periodically inspect all bolts, screws, and other fasteners. Re-tighten any loose hardware to maintain structural integrity.
- **Tent Care:** The tent fabric can be spot cleaned with a mild detergent and water. Allow to air dry completely.
- **Slats:** Ensure all bed slats are securely in place and undamaged. Replace any broken slats immediately.



Figure 4: Detail of the plywood bed slats, designed to support the mattress.

5. Troubleshooting

If you encounter any issues with your bunk bed, refer to the following common solutions:

- **Bed feels wobbly:** Check all assembly bolts and screws. Re-tighten any loose fasteners. Ensure the bed is on a level surface.
- **Squeaking noises:** This often indicates loose connections. Identify the source of the squeak and tighten the corresponding hardware. Applying a small amount of wax or lubricant to joints can also help.
- **Tent not fitting correctly:** Ensure the tent fabric is oriented correctly and all ties or attachment points are secured as per the assembly instructions.
- **Damaged parts:** Do not use the bed if any structural components are damaged. Contact customer support for replacement parts.

6. Specifications

Product Type	Bunk Bed
Model Number	N708P248523
Overall Product Dimensions	78.8" L x 41.5" W x 79.1" H
Upper Bed Weight Capacity	250 lbs (113 kg)
Recommended Mattress Thickness (Upper Bed)	4-6 inches (10-15 cm)
Recommended Age	Over 6 years old
Material	Plywood, Pinewood
Color	Espresso
Item Weight	102 lbs (46.2 kg)
Assembly Required	Yes
UPC	769818746028

7. Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact DERCASS customer support directly.
If you have any questions, require assistance with assembly, or need to report damaged/missing parts, please contact DERCASS customer service. We are committed to resolving any issues you may encounter.
Contact information for DERCASS customer support can typically be found on the product packaging or the official DERCASS website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZ6WGGXZ

More documents and user manuals: **https://manuals.plus/**