Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

sytiry TR6702

sytiry Walking Pad Treadmill TR6702 User Manual

Model: TR6702

1. Setup and Assembly

The sytiry Walking Pad Treadmill TR6702 is designed for minimal assembly. Most components are pre-assembled. Follow these steps for initial setup:

1.1 Unboxing and Component Check

Carefully remove all components from the packaging. Verify that all parts listed in the package contents are present. The package typically includes the walking pad treadmill, lubricating oil, a remote control, a tool kit, and this user manual.

Figure 1: Included Components

1.2 Handlebar Assembly

While the main body is pre-assembled, the handlebars may require attachment. Insert the handlebar posts into the designated slots on the treadmill base and secure them using the provided screws and tools from the tool kit. Ensure all connections are tight and stable before use.

▶ **Watch video online**
SYTIRY Treadmills with WiFi Touchscreen Installation video

Video 1: SYTIRY Treadmills with WiFi Touchscreen Installation video. This video demonstrates the assembly process of the sytiry Walking Pad Treadmill, including attaching the uprights and console.

1.3 Safety Key Connection

Locate the red safety key and attach it to the designated slot on the console. The treadmill will not operate without the safety key properly inserted. Attach the clip end of the safety key to your clothing during operation for emergency stops.

2. Operating Instructions

Familiarize yourself with the treadmill's controls and features before beginning your workout.

2.1 Power On/Off

- Connect the power cord to a grounded outlet.
- Flip the main power switch located at the front of the treadmill to the 'ON' position.
- To power off, flip the main power switch to the 'OFF' position and unplug the unit.

2.2 Console and Display

The treadmill features a multi-functional LED display that shows various workout metrics:

- **Time:** Duration of your workout.
- **Distance:** Total distance covered.
- **Calories:** Estimated calories burned.
- **Speed:** Current speed in miles per hour (mph).



Figure 2: Multi-functional LED Display

2.3 Workout Modes and Speed Adjustment

The treadmill supports various activity levels:

- **Working Mode:** 0.6-1.6 mph (for light activity while working).
- **Walking Mode:** 1.6-2.6 mph (for brisk walking).
- **Running Mode:** 2.6-3.7 mph (for jogging or light running).

Adjust the speed using the remote control or the speed buttons on the handlebars. The remote control allows for precise speed adjustments and starting/stopping the treadmill.



Figure 3: Treadmill Modes and Speed Ranges

3. Maintenance

Regular maintenance ensures the longevity and optimal performance of your treadmill.

3.1 Lubrication

The running belt requires periodic lubrication to reduce friction and wear. Use the provided lubricating oil. Refer to the

detailed instructions in the included user manual for the correct lubrication procedure and frequency.

3.2 Belt Adjustment

Over time, the running belt may become misaligned or loose. Use the wrench from the tool kit to adjust the belt tension and alignment as needed. Consult the detailed instructions in the user manual for proper belt adjustment procedures.

3.3 Cleaning

Wipe down the treadmill surfaces with a damp cloth after each use to remove sweat and dust. Avoid using abrasive cleaners or solvents that could damage the finish.

4. Troubleshooting

This section addresses common issues you might encounter with your treadmill.

4.1 E07 Error Code

If the display shows an "E07" error, it typically indicates that the safety key is not properly inserted or has become dislodged. Ensure the safety key is firmly placed in its slot on the console. If the error persists, power cycle the treadmill by turning it off and on again.

▶ **Watch video online**
What a great and entertaining workout!!

Video 2: What a great and entertaining workout!! This video demonstrates the display features and shows how to resolve an E07 error by re-inserting the safety key.

4.2 Remote Control Issues

If the remote control is not responding, check its battery and replace it if necessary. Ensure there are no obstructions between the remote and the treadmill's console. If the issue continues, refer to the user manual for remote pairing instructions.

5. Specifications

Feature	Detail
Brand	sytiry
Model Number	TR6702
Product Dimensions	45.27"D x 20"W x 4.17"H
Item Weight	20.8 Kilograms
Material	Alloy Steel
Maximum Speed	4 Miles per Hour
Minimum Speed	0.6 Miles per Hour
Maximum Horsepower	2.5 Horsepower

Feature	Detail
Maximum Weight Recommendation	300 Pounds
Display	LED
Special Features	Compact Design, Portable, Shock Absorbent, Wheeled
Included Components	Lubricant, Remote Control, Tool Kit, User Manual

6. Warranty and Support

6.1 Warranty Information

The sytiry Walking Pad Treadmill TR6702 comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product meets quality standards.

6.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact sytiry customer service. 24/7 support is available to assist you.

The product is certified to SGS CE, ROHS, CB, EN957, and IEC standards.

7. Storage

The compact design and built-in wheels make the sytiry Walking Pad Treadmill easy to move and store. It can be stored under furniture like sofas or beds, or against a wall when not in use.



Figure 4: Storage Options

© 2023 sytiry. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZHLJ5PH

More documents and user manuals: **https://manuals.plus/**