Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CyberChill SM-FS200C

CyberChill SM-FS200C Frozen Drink Maker User Manual

Introduction

This manual provides essential instructions for the safe and efficient operation of your CyberChill SM-FS200C Frozen Drink Maker. Please read this manual thoroughly before initial use and retain it for future reference. While the product title refers to an 'Ice Maker Machine', this appliance is specifically designed to prepare frozen beverages from liquid ingredients, eliminating the need for pre-made ice.



Image: The CyberChill SM-FS200C Frozen Drink Maker, a compact appliance for preparing frozen beverages.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions before operating the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

Familiarize yourself with the components of your CyberChill SM-FS200C Frozen Drink Maker.

- Main Unit Body
- Mixing Chamber
- Dispensing Spout
- Control Panel (Power Button, Start/Stop Button)
- Lid
- Drip Tray

Setup

1. Unpacking

Carefully remove all packaging materials and inspect the appliance for any damage. Retain packaging for future transport if needed.

2. Placement

Place the frozen drink maker on a stable, flat, and dry surface. Ensure there is adequate ventilation around the unit. Avoid placing it near heat sources or in direct sunlight.

3. Initial Cleaning

Before first use, wash all removable parts (mixing chamber, lid, drip tray) with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit body with a damp cloth.

4. Power Connection

Ensure the appliance is switched off before plugging it into a standard 120 Volt AC electrical outlet.

Operating Instructions

1. Preparing the Mixture

Prepare your desired frozen drink mixture according to your recipe. This machine is designed to create frozen beverages from liquid ingredients, eliminating the need for pre-made ice.

2. Filling the Mixing Chamber

Open the lid and carefully pour the prepared mixture into the mixing chamber. Do not exceed the maximum fill line indicated inside the chamber.

3. Starting the Freezing Process

Securely close the lid. Press the Power button to turn on the unit, then press the Start/Stop button to begin the freezing and mixing process. The machine will automatically churn and freeze the mixture.

4. Dispensing the Frozen Drink

Once the desired consistency is reached (typically indicated by a change in motor sound or a ready indicator light, if present), place a cup under the dispensing spout and pull the lever to dispense your frozen drink.

5. Stopping the Machine

To stop the machine at any time, press the Start/Stop button. Press the Power button to turn off the unit completely.

Maintenance and Cleaning

1. Daily Cleaning

After each use, unplug the appliance. Remove the mixing chamber, lid, and drip tray. Wash these parts with warm, soapy water, rinse, and dry thoroughly.

2. Cleaning the Main Unit

Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water.

3. Storage

Ensure all parts are clean and dry before storing the appliance. Store in a cool, dry place away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; Power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the Power button.
Mixture not freezing.	Too much mixture; Lid not properly closed; Ambient temperature too high.	Do not overfill the mixing chamber. Ensure the lid is securely closed. Operate in a cooler environment.
Machine is noisy.	Normal operation sound; Unit not on a flat surface.	Some operational noise is normal. Ensure the unit is on a stable, flat surface.
Drink dispenses too slowly.	Mixture too thick.	Allow the mixture to soften slightly or adjust recipe for thinner consistency.

Specifications

Feature	Detail
Model Number	SM-FS200C
Manufacturer	CyberChill
Voltage	120 Volts
Item Weight	11.8 kg (26 lbs)
Product Dimensions (L x W x H)	43.18 x 17.02 x 44.45 cm (17 x 6.7 x 17.5 inches)
Included Components	Frozen Drink Maker Body, User Manual, Recipe

Feature	Detail
ASIN	B0DZM9YVTS
UPC	860013643508

Warranty Information

This CyberChill product is covered by a limited manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact CyberChill customer support.

Contact information can typically be found on the CyberChill official website or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZM9YVTS

More documents and user manuals: **https://manuals.plus/**