Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic NN-GD35QBYPQ

Panasonic NN-GD35QBYPQ Microwave with Grill Function User Manual

Model: NN-GD35QBYPQ | Capacity: 29 Liters

1. Safety Information

Please read all instructions carefully before using this appliance to ensure safe and efficient operation. Keep this manual for future reference.

1.1 General Safety Precautions

- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door, or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the door, hinges, or seals.
- Only qualified service personnel should adjust or repair this appliance.
- Always use oven mitts when removing hot items from the microwave.



Image: Always use protective gloves when handling hot dishes from the microwave to prevent burns.

1.2 Electrical Safety

- Ensure the appliance is properly grounded.
- Do not immerse the cord, plug, or appliance in water or other liquid.

- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.

1.3 Microwave Specific Safety

- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Never use metal utensils or containers in the microwave mode, as this can cause arcing and damage the oven.
- Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens as they may explode, even after microwave heating has ended.
- Always pierce foods with skins (e.g., potatoes, apples, sausages) before cooking to prevent bursting.

2. Product Overview

The Panasonic NN-GD35QBYPQ is a 29-liter microwave oven with an integrated grill function, designed for versatile cooking. It features Inverter Technology for precise power control and even heating.

2.1 Components

- **Microwave Oven Unit:** Main appliance body.
- **Glass Turntable:** Rotates food for even cooking.
- **Turntable Ring:** Supports the glass turntable.
- **Wire Rack:** For use during grill and combination cooking.



Image: The spacious interior accommodates various dish sizes, with a usable width of 330mm.

2.2 Control Panel

The microwave features a simplified control panel with a clear white LCD display and intuitive controls for easy operation.

- **LCD Display:** Shows time, cooking settings, and menu options.
- **Dial Control:** Used to set cooking time, weight, and navigate menus.
- **Function Buttons:** Dedicated buttons for Microwave Power, Grill, Combination, Auto Defrost, Auto Menu, Quick Start/Add Time, Stop/Cancel, and Start/Set.



Image: The intuitive dial control allows for precise adjustments of cooking time and settings.



Image: Clearly labeled buttons provide direct access to various cooking functions.

3. Setup

3.1 Unpacking

1. Remove all packaging materials from inside and outside the oven.
2. Check the oven for any damage, such as dents or a misaligned door. Do not operate if damaged.
3. Ensure all accessories, including the glass turntable, turntable ring, and wire rack, are present.

3.2 Placement

- Place the oven on a flat, stable surface strong enough to hold the oven and the food being cooked.
- Ensure adequate ventilation: leave at least 10 cm of space at the rear, 20 cm at the sides, and 30 cm above the oven.
- Keep the oven away from heat sources and strong magnetic fields.

3.3 Initial Setup

1. Plug the oven into a grounded electrical outlet. The display will show "0:00".
2. **Setting the Clock:** Press the "Timer/Clock" button. Use the dial to set the hour, then press "Timer/Clock" again. Use the dial to set the minutes, then press "Timer/Clock" to confirm.

4. Operating Instructions

4.1 Basic Microwave Cooking

1. Place food in a microwave-safe container on the glass turntable.
2. Close the oven door.
3. Press the "Micro Power" button repeatedly to select the desired power level (e.g., High, Med-High, Med, Med-Low, Low).
4. Use the dial to set the cooking time.
5. Press "Start/Set" to begin cooking.

This model features **Inverter Technology**, which provides a continuous stream of cooking power at every setting. This ensures food is cooked evenly and retains more nutrients, unlike traditional microwaves that cycle power on and off.



Image: Inverter technology ensures consistent heating for better cooking results, preventing unevenly cooked food.

4.2 Grill Function

Use the grill function for browning and crisping food. Place food on the wire rack provided.

1. Place food on the wire rack.
2. Press the "Grill" button.
3. Use the dial to set the grilling time.
4. Press "Start/Set" to begin grilling.

4.3 Combination Cooking

Combination mode uses both microwave and grill functions to cook food faster and achieve a crispy finish.

1. Place food on the wire rack.
2. Press the "Combination" button repeatedly to select the desired combination mode (e.g., C1, C2, C3).
3. Use the dial to set the cooking time.
4. Press "Start/Set" to begin.

4.4 Auto Menus

The oven features 16 pre-programmed auto menus for various dishes, simplifying cooking. Refer to the oven door label or internal guide for specific menu numbers and corresponding foods.

1. Place food in the appropriate container.
2. Press the "Auto Menu" button.
3. Use the dial to select the desired menu number.
4. Press "Start/Set". The oven may prompt for food weight; use the dial to adjust if necessary, then press "Start/Set" again.



Image: The auto menus are designed to perfectly cook a variety of dishes, from baked potatoes to grilled fish.

4.5 Auto Defrost

This function automatically defrosts food based on its weight.

1. Place frozen food in a microwave-safe container.
2. Press the "Auto Defrost" button.
3. Use the dial to set the food weight.
4. Press "Start/Set" to begin defrosting.



Image: The Auto Defrost function efficiently thaws frozen foods like vegetables, ensuring they are ready for cooking.

4.6 Quick Start / Add Time

- **Quick Start:** Press "Quick Start / Add Time" to immediately start cooking at full microwave power for 30 seconds. Each subsequent press adds 30 seconds.
- **Add Time:** During any cooking cycle, press "Quick Start / Add Time" to add 30 seconds to the current cooking time.

5. Maintenance and Cleaning

5.1 General Cleaning

- Always unplug the oven before cleaning.
- Clean the oven interior and exterior with a damp cloth and mild detergent. Avoid abrasive cleaners.
- The glass turntable and turntable ring can be washed in warm soapy water or in a dishwasher.
- Wipe the door seals and surrounding areas regularly to remove spills and splatters.

5.2 Auto Clean Function

This microwave includes an Auto Clean function to assist with hygiene maintenance. Refer to the specific instructions in the full manual for detailed steps on using this feature.

6. Troubleshooting

Problem	Possible Cause	Solution
Oven does not start	Door not closed properly; Power cord unplugged; Fuse blown or circuit breaker tripped.	Ensure door is firmly closed; Check power cord connection; Check household fuse or reset circuit breaker.
Food not cooking evenly	Food not stirred or rearranged; Incorrect power level or cooking time; Turntable not rotating.	Stir or rearrange food during cooking; Adjust power level and time; Ensure turntable and ring are correctly placed and free of obstructions.
Light not working	Bulb needs replacement.	Contact qualified service personnel for bulb replacement.
Smoke or sparks inside oven	Metal objects inside; Food residue; Damaged oven interior.	Immediately turn off and unplug. Remove any metal objects. Clean oven interior. If damage persists, contact service.

If the problem persists after attempting these solutions, please contact Panasonic customer support.

7. Specifications

Model: NN-GD35QBYPQ

Capacity: 29 Liters

Power Output (Microwave): 1000 Watts

Special Features: Grill Function, Inverter Technology, Auto Clean, Auto Defrost

Control Type: Touchscreen with Dial

Material: Painted Metal

Color: Black

Product Dimensions (D x W x H): 37.8 cm x 43.5 cm x 23.2 cm

Included Components: Wire Rack

8. Warranty and Support

This Panasonic NN-GD35QBYPQ microwave oven comes with a **1-Year Manufacturer Warranty**.

For warranty claims, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Panasonic support website for your region.

Keep your purchase receipt as proof of purchase for warranty purposes.

© 2025 Panasonic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZMYT5XC

More documents and user manuals: **https://manuals.plus/**