Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

kejector FSD001

kejector FSD001 20-Inch Low Profile Ceiling Fan with Light User Manual

Model: FSD001 | Brand: kejector

1. Introduction

Thank you for choosing the kejector FSD001 20-inch Low Profile Ceiling Fan with Light. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before installation and keep them for future reference.
This innovative ceiling fan combines efficient air circulation with modern LED lighting, featuring a unique 360° oscillation function, remote control, and smartphone app compatibility for enhanced convenience.

2. Safety Information

- **Electrical Safety:** Always disconnect power at the circuit breaker before beginning installation or performing any maintenance. Ensure all wiring is in accordance with national and local electrical codes. If you are unsure about wiring, consult a qualified electrician.
- **Mounting:** The ceiling fan must be mounted to a structurally sound ceiling capable of supporting the fan's weight. Use only the hardware provided or suitable alternatives approved for ceiling fan installation.
- **Blade Clearance:** Ensure there is adequate clearance between the fan blades and any obstructions (walls, furniture, etc.) to prevent injury or damage.
- **Remote Control:** Keep the remote control away from children to prevent accidental operation.
- **Cleaning:** Do not use water directly on the fan or light fixture. Clean with a soft, damp cloth.

3. Package Contents

Carefully unpack your kejector FSD001 ceiling fan and ensure all items are present and undamaged. If any parts are missing or damaged, contact customer support.

- kejector FSD001 Ceiling Fan with Light
- Remote Control
- Mounting Bracket
- Installation Hardware (screws, anchors, wire nuts)

- User Manual

4. Setup and Installation

The kejector FSD001 ceiling fan is designed for simplified installation with most components pre-assembled. Follow these steps for a secure and functional setup.

1. **Prepare the Installation Area:** Turn off power at the circuit breaker. Ensure the ceiling junction box is securely mounted and capable of supporting the fan's weight.
2. **Install the Mounting Bracket:** Attach the provided mounting bracket to the ceiling junction box using the supplied screws. Ensure it is firmly secured.
3. **Hang the Fan:** Use the safety hook on the mounting bracket to temporarily hang the fan while making electrical connections. This allows for hands-free wiring.
4. **Make Electrical Connections:** Connect the fan's wires to your household wiring. Typically, this involves connecting live (black), neutral (white), and ground (green/yellow striped) wires. Use wire nuts to secure connections.
5. **Secure the Fan:** Once wiring is complete, carefully lift the fan and align it with the mounting bracket. Secure the fan to the bracket using the screws provided.
6. **Final Assembly:** Attach any remaining decorative covers or components as per the detailed instructions in the included user manual.



Image: Overview of the kejector FSD001 ceiling fan, highlighting its compact design and integrated light.



Image: Illustration of the flush mount installation process for the ceiling fan.



Image: Visual representation of the 360° oscillating airflow, demonstrating wider air distribution compared to fixed fans.

Video: A seller-provided video demonstrating the installation process and key features of the kejector ceiling fan with light.

5. Operating Instructions

Your kejector FSD001 ceiling fan can be controlled via the included remote control or a smartphone application.

5.1 Remote Control

The remote control allows you to manage all fan and light functions from anywhere in the room.

- **Power On/Off:** Turn the fan and light on or off.
- **Fan Speed:** Select from 6 adjustable fan speeds (1-6).
- **Light Brightness:** Adjust light brightness from 10% to 100% (smooth dimming).
- **Color Temperature:** Change the light color temperature (3000K Warm, 4500K Natural, 6000K Bright).
- **360° Oscillation:** Activate or deactivate the unique oscillating fan blades for wider air distribution.
- **Reversible Motor:** Switch between downdraft (summer) and updraft (winter) airflow modes.
- **Timer:** Set a shutdown timer for 1, 2, 4, or 8 hours.
- **Night Light:** Activate a low-brightness night light mode.



Image: The ceiling fan with its remote control and a smartphone displaying the app interface, illustrating multiple control options.



Image: Visual guide to the six fan speed settings, categorized into soft, natural, and strong wind modes.



Image: Demonstration of the light's adjustable color temperature (3000K, 4500K, 6000K) and 10%-100% dimming capability.

5.2 App Control

For advanced control and convenience, download the dedicated smartphone application. Ensure Bluetooth is enabled on your device before using the app.

- Scan the QR code provided in the packaging or visithttps://www.jasonghost.com/fanlamppro/ to download the app.
- The app offers similar functionalities to the remote control, including wind speed, direction, mode (natural/sleep), shutdown timer, light brightness, and color temperature adjustments.

5.3 Wall Switch Compatibility

The fan can be connected to a standard wall switch for basic ON/OFF functionality.**Do not connect it to a dimmer switch or a transmission switch for light brightness or wind speed adjustment.** Only use an ordinary ON/OFF switch.



Image: Guide to compatible standard ON/OFF wall switches and incompatible dimmer/transmission switches.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, dry cloth to clean the fan and light fixture. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** The bladeless design simplifies cleaning. Gently wipe the fan blades and surrounding areas to remove dust buildup.
- **Check Connections:** Periodically check all electrical connections and mounting screws to ensure they are secure.

7. Troubleshooting

If you encounter issues with your kejector FSD001 ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate	No power supply; Loose wiring; Remote control battery dead.	Check circuit breaker; Verify all wire connections; Replace remote control batteries.
Light does not work	No power supply; Loose wiring; LED driver issue.	Check circuit breaker; Verify light wiring connections; Contact customer support if LED driver is suspected.
Fan makes excessive noise	Loose mounting screws; Obstruction in fan path.	Tighten all mounting screws; Ensure no objects are interfering with the fan blades.
Remote control not responding	Battery dead; Remote not paired.	Replace remote batteries; Refer to the full user manual for remote pairing instructions.

8. Specifications

- **Brand:** kejector
- **Model Name:** FSD001
- **Size:** 20 Inch

- **Color:** Black
- **Material:** Acrylonitrile Butadiene Styrene
- **Light Source Type:** LED
- **Number of Light Sources:** 7
- **Controller Type:** Remote Control, App Control
- **Special Features:** LED Light, 360° Oscillation, Reversible Motor, 6 Speeds Fan, 1/2/4/8H Timer Setting, 3000K-6000K Color Temperature Selectable, 10%-100% Smooth Dimming
- **Item Weight:** 10.28 pounds (4.67 Kilograms)
- **Product Dimensions:** 20.87 x 20.87 x 8.6 inches
- **Assembly Required:** Yes

9. Warranty and Support

For any questions, technical assistance, or warranty claims, please contact kejector customer support through the Amazon messaging system or refer to the contact information provided in your product packaging.
GET MORE SUPPORT: Amazon Message

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZNMC652

More documents and user manuals: **https://manuals.plus/**