Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SCHLEICH 99179

SCHLEICH Advent Calendar Christmas 2025 Instruction Manual

Model: 99179

Introduction | Safety Information | Package Contents | Setup | Operating Instructions | Maintenance | Troubleshooting | Specifications | Customer Support

1. Introduction

This manual provides instructions for the SCHLEICH Advent Calendar Christmas 2025, Model 99179. This product is designed to offer a daily surprise leading up to Christmas, featuring figures and accessories from the SCHLEICH Horse Club world. The set encourages imaginative play and storytelling.



Image: The SCHLEICH Advent Calendar Christmas 2025 box, displaying the main figures, sleigh, and other components.

2. Safety Information

Warning! Choking Hazard - Small Parts. This product contains small parts that may pose a choking risk. It is **not suitable for children under 3 years of age** due to the risk of suffocation. Adult supervision is recommended during play, especially with younger children.

3. Package Contents

The SCHLEICH Advent Calendar Christmas 2025 (Model 99179) includes 31 individual pieces, revealed daily. These typically include:

- Two movable figures: Hannah and Sofia.
- One horse figure (Noriker Stallion).
- One reindeer figure.
- One dog figure (Ruby).

- One squirrel figure.
- One exclusive, decorated sleigh.
- Various accessories such as a treasure chest, blanket, golden bows, and green branches.



Image: All components of the Advent Calendar, including figures, sleigh, and accessories, displayed outside the packaging.



Image: The complete set assembled, showing the horse pulling the sleigh with Hannah and Sofia, accompanied by the reindeer, dog, and squirrel, against a winter backdrop.

4. Setup

1. **Unpack the Calendar:** Carefully remove the Advent Calendar from its outer packaging. The calendar itself is designed to be displayed.
2. **Locate Instructions:** The inner side of the outer cardboard sleeve may contain assembly instructions for certain components, such as the sleigh or figures. Retain this for reference.
3. **Position the Calendar:** Place the Advent Calendar in a suitable location where it can be easily accessed each day.



Image: A child's hands carefully opening one of the numbered doors on the Advent Calendar, revealing a surprise inside.

5. Operating Instructions

The Advent Calendar is designed for daily interaction leading up to Christmas. Follow these steps:

1. **Daily Reveal:** Starting from December 1st, open one numbered door each day. The number on the door

corresponds to the date.

2. **Retrieve Contents:** Carefully remove the figure or accessory found behind the opened door.
3. **Assembly (if required):** Some figures or accessories, such as the sleigh or the human figures, may require minor assembly. Refer to the instructions provided on the outer sleeve or within the calendar if needed.
4. **Engage in Play:** Integrate the newly revealed item into your SCHLEICH Horse Club play scenarios. The figures are designed to be robust and encourage imaginative storytelling.

6. Maintenance

To ensure the longevity of your SCHLEICH Advent Calendar figures and accessories:

- **Cleaning:** Wipe figures and accessories with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the figures and accessories in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation or color fading.
- **Handling:** While durable, avoid excessive force or bending of movable parts to prevent damage.

7. Troubleshooting

Issue	Possible Cause	Solution
Missing piece from a door.	Item may have shifted during transit or fallen out.	Check other compartments or the bottom of the calendar box. If still missing, contact customer support.
Figure or accessory appears damaged.	Manufacturing defect or damage during handling.	Do not attempt to repair if significantly damaged. Contact customer support for assistance.
Difficulty assembling a component.	Instructions may be unclear or parts misaligned.	Refer to the assembly instructions on the outer sleeve. Ensure parts are correctly oriented.

8. Specifications

Feature	Detail
Model Number	99179
Brand	SCHLEICH
Product Name	Advent Calendar Christmas 2025
Material	Plastic
Number of Pieces	31
Recommended Age	5 - 12 years (Manufacturer recommended)
Product Dimensions (L x W x H)	59 x 27 x 7 cm
Item Weight	2 Kilograms
Assembly Required	No (Minor assembly for some figures/sleigh may be needed)
Educational Objective	Foster creativity and cultural understanding

9. Customer Support

For any questions, concerns, or to report missing/damaged parts, please contact SCHLEICH customer service. Refer to the product packaging or the official SCHLEICH website for the most current contact information.

Manufacturer: Schleich

Website: www.schleich-s.com (General website, specific support contact may vary by region)

© 2025 SCHLEICH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F19CYXGK

More documents and user manuals: **https://manuals.plus/**