BEAUTURAL 722NA-0017

BEAUTURAL 2-in-1 Handheld Garment Steamer & Iron

Model: 722NA-0017

Powerful Burst Steam for Effective Deep Wrinkles Removal

Setup | Operating | Maintenance | Troubleshooting | Specifications

1. Setup

1.1 Filling the Water Tank

The BEAUTURAL 2-in-1 Steamer features a 200ml (6.76oz) removable water tank for easy refilling. To fill:

1. Press the unlock button located at the base of the steamer to detach the water tank.
2. Open the rubber gasket on the tank.
3. Fill the tank with distilled, purified, or filtered water. Avoid using oils, perfumes, or scented additives, as these can cause mineral buildup and affect performance.
4. Close the rubber gasket securely and reattach the water tank to the steamer until it clicks firmly into place.

Image: Detachable 200ml water tank for effortless refilling.

1.2 Powering On and Preheating

The steamer operates on 120V only. Ensure you are using a compatible outlet.

1. Plug the steamer into a 120V outlet. The extra-long 8ft (2.4m) power cord provides ample reach.
2. Press the power button located on the back of the steamer.
3. Allow the steamer to preheat for approximately 30 seconds until the power indicator light

becomes solid. For first-time use, some residual water from testing might be emitted from the steam head; this is normal and will quickly disappear.

Image: Ceramic heating plate with 1200W high-power and 30-second fast heat-up.

2. Operating Instructions

2.1 Continuous Steam Mode

For continuous steam, ideal for vertical steaming of hanging garments:

1. Once the steamer is preheated (indicator light solid), press the continuous steam button on the back of the handle.
2. Hold the steamer upright and move it slowly over the fabric, allowing the steam to penetrate and relax wrinkles.

Image: Vertically ironing a hanging garment with the steamer.

2.2 Burst Steam Mode (for Ironing)

For stubborn wrinkles or when using the steamer as an iron on a flat surface:

1. Before each use of the burst steam, press the burst steam button 6 times in a row.
2. Then, press the burst steam button at 5-second intervals to avoid dripping.
3. Turn off continuous steam before using burst steam for optimal results.
4. Place the garment on a flat, heat-resistant surface. Press the steamer plate onto the fabric and activate the burst steam as needed to smooth out wrinkles.

Image: Steamer emitting a powerful burst of steam to eliminate tough wrinkles.

Image: Horizontally ironing a shirt on an ironing board.

2.3 Fabric Compatibility

The 310°F thermostatic ceramic plate is gentle yet effective on a wide range of fabrics, including:

- Delicate silk
- Sturdy linen
- Wool
- Cotton
- Polyester
- Nylon
- Velvet
- Plush
- Blended fibers

Image: The steamer is suitable for various fabric types, including wool, silk, cotton, linen, nylon, and denim.

3. Maintenance

3.1 After Each Use

To ensure longevity and optimal performance of your steamer:

1. Unplug the steamer from the power outlet and allow it to cool completely.
2. Empty any remaining water from the detachable tank after each steaming session. This prevents mineral buildup and ensures continued clean steaming.
3. Store the steamer in a dry, safe place.

4. Troubleshooting

Refer to the table below for common issues and their solutions:

Issue	Possible Causes	Solution
There is no steam.	Steamer not plugged in or not switched on.	Plug in your steamer and switch it on.
	Water tank not clicked fully in place.	Ensure that the water tank is installed properly (i.e., clicked in place).
	Steamer is in auto-shut-off mode.	Press the continuous steam button or the power button to reactivate the steamer.
	Burst steam has not been activated.	Before each use, press the burst steam button 6 times in a row to activate the burst steam.
Not enough steam comes out.	Burst steam has been used too frequently.	Press the burst steam button at 5-second intervals.
	Steamer is not heated to full temperature.	Always allow the steamer to preheat until the indicator light stays solid.
	Steamer not plugged in or not switched on.	Plug in your steamer and switch it on.

Issue	Possible Causes	Solution
The steamer does not heat.	Steamer is in auto-shut-off mode.	Press the continuous steam button or the power button to reactivate the steamer.
	Used at the incorrect voltage of 220-240V. Only 120 volts are suitable for this steamer.	The steamer is malfunctioning. Please get in touch with customer service.
Water leaks.	Water tank not clicked fully in place, or cover not closed properly.	Ensure that the cover is closed and tank is installed properly.

5. Specifications

- **Brand:** BEAUTURAL
- **Model:** 722NA-0017
- **Style:** 2-in-1 Steam & Iron
- **Color:** Purple
- **Wattage:** 1200 watts
- **Voltage:** 120 Volts
- **Capacity:** 200 Milliliters (6.76oz)
- **Heating Plate:** 310°F Thermostatic Ceramic Plate
- **Heat-up Time:** 30 seconds
- **Safety Features:** Anti-drip technology, Auto Shut-off (after 30 minutes of inactivity)
- **Power Cord Length:** 8ft (2.4m)
- **Item Weight:** 2.18 pounds
- **Included Components:** Garment Steamer

Image: Product dimensions and specifications of the BEAUTURAL 2-in-1 Steamer.

6. Warranty and Support

6.1 Warranty Information

This BEAUTURAL product comes with a **2-year warranty**. Additionally, a **30-day return policy** is standard. For warranty registration or to extend your warranty, please refer to the information provided in your product packaging or contact customer service.

6.2 Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact BEAUTURAL customer service. Contact details can be found on the product packaging or the official BEAUTURAL website.

7. Official Product Video

Video: An official overview of the BEAUTURAL 2-in-1 Steamer & Iron, demonstrating its features and ease of use.

© 2026 BEAUTURAL. All rights reserved.