Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MGK5565

Braun MultiGroomer Series 5 MGK5565 Electric Groomer User Manual

Model: MGK5565

1. Introduction

The Braun MultiGroomer Series 5 MGK5565 is an 11-in-1 electric grooming device designed for easy maintenance of beards, hair, and body. It features durable metal blades for precise, stress-free styling and an integrated skin guard to protect your skin during use. This manual provides essential information for the safe and effective use of your new grooming device.



Image 1.1: The Braun MultiGroomer Series 5 MGK5565, showcasing the main unit and its comprehensive set of accessories within its packaging.

2. Safety Information

Please read all instructions carefully before using this appliance to ensure safe operation and optimal performance. Keep this manual for future reference.

- This appliance is suitable for cleaning under running water. Do not immerse the appliance in water for extended periods.
- Do not use the appliance with a damaged foil or comb, as this may result in injury.
- This appliance is equipped with a special cord set with an integrated Safety Extra Low Voltage power supply. Do not exchange or manipulate any part of it.
- Only use the power supply provided with the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or

mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.

- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 years and supervised.
- Always unplug the appliance before cleaning.

3. Package Contents

Verify that all items listed below are included in your package:



Image 3.1: All components of the Braun MultiGroomer Series 5 MGK5565, including the main unit and its various attachments and accessories.

- **Main Groomer Unit:** The core device for all grooming tasks.

- **Beard & Hair Comb (3-11mm):** For maintaining shorter beard and hair lengths.
- **Beard & Hair Comb (13-21mm):** For maintaining longer beard and hair lengths.
- **Fixed Comb (1mm):** For very short stubble or precise trimming.
- **Fixed Comb (2mm):** For short stubble or precise trimming.
- **Detail Trimmer Head:** For creating sharp lines and contours.
- **Ear & Nose Trimmer Head:** For safely removing unwanted ear and nose hair.
- **Body Groomer Head:** For efficient body hair removal.
- **Skin Guard:** Attaches to the body groomer head for enhanced skin protection.
- **Precision Trimmer Head:** For fine detailing and intricate styling.
- **Cleaning Brush:** For removing hair clippings from the device and attachments.
- **Charging Stand:** For convenient storage and charging of the groomer.
- **Pouch:** For storing and transporting the groomer and its accessories.

4. Setup

4.1. Charging the Device

Before first use, fully charge your MultiGroomer. The device is powered by a Lithium-ion battery.

1. Ensure the groomer is switched off.
2. Connect the special cord set to the charging stand, then plug it into an electrical outlet.
3. Place the groomer onto the charging stand. The charging indicator light will illuminate.
4. A full charge takes approximately **1.5 hours** and provides up to **120 minutes** of cordless trimming time.
5. Once fully charged, unplug the power supply from the outlet.

4.2. Attaching and Detaching Heads/Combs

To change attachments:

- To attach a head: Align the head with the main unit and press it down until it clicks into place.
- To detach a head: Pull the head upwards firmly to remove it from the main unit.
- To attach a comb: Slide the desired comb onto the trimmer head until it locks.
- To detach a comb: Gently pull the comb upwards to slide it off the trimmer head.



Image 4.1: Features such as Aqua Grip for 100% waterproof design, up to 120 minutes of battery life, and German engineering for durability.

5. Operating Instructions

The Braun MultiGroomer Series 5 MGK5565 is designed for versatile grooming. Always ensure your skin and hair are clean and dry before use for best results, unless using for wet shaving (if applicable).

5.1. Beard and Hair Trimming

Use the main trimmer head with the appropriate comb attachment for your desired length.

- Select the 3-11mm comb for shorter beard styles or hair.
- Select the 13-21mm comb for longer beard styles or hair.
- For very short stubble, use the 1mm or 2mm fixed combs.
- Move the trimmer against the direction of hair growth for an even trim.



Image 5.1: The metal blade system ensures precise and stress-free styling for both beard and hair trimming.

5.2. Body Grooming

Attach the Body Groomer Head with the Skin Guard for comfortable and safe body hair trimming.

- Ensure the Skin Guard is securely attached to the Body Groomer Head.
- Gently glide the groomer over the desired areas, moving against the direction of hair growth.
- The Skin Guard helps protect sensitive areas from nicks and irritation.



Image 5.2: The integrated skin guard provides protection for sensitive skin during body grooming.

5.3. Detail and Precision Trimming

Use the Detail Trimmer Head or Precision Trimmer Head for defining edges and intricate styling.

- Attach the Detail Trimmer Head for sharp lines around your beard, mustache, or sideburns.
- Use the Precision Trimmer Head for fine adjustments and detailed styling.

5.4. Ear and Nose Trimming

Attach the Ear & Nose Trimmer Head for safe and comfortable removal of unwanted hair.

- Gently insert the trimmer tip into your nostril or ear canal.
- Move the trimmer in a circular motion to trim hair. Do not insert too deeply.

6. Maintenance

6.1. Cleaning

The Braun MultiGroomer is 100% waterproof, allowing for easy cleaning under running water.

1. After each use, switch off the appliance and detach the trimmer head.
2. Rinse the trimmer head and the main unit under warm running water.
3. Use the provided cleaning brush to remove any stubborn hair clippings from the blades and combs.
4. Allow all parts to air dry completely before reassembling or storing.

6.2. Blade Care

For optimal performance, regularly oil the trimmer blades. A small drop of light machine oil (not included) on the blades after cleaning will help maintain their sharpness and smooth operation.

7. Troubleshooting

If you encounter any issues with your Braun MultiGroomer, refer to the following common problems and solutions:

- **Device not turning on:** Ensure the device is fully charged. If it's a new device, it might require an initial charge.
- **Poor trimming performance:** Clean the blades and comb attachments thoroughly. Ensure there are no hair blockages. The blades may also require oiling.
- **Charging indicator not working:** Check if the power adapter is correctly plugged into both the wall outlet and the charging stand/device. Ensure the device is properly seated on the charging stand.
- **Skin irritation:** Ensure you are using the correct attachment (e.g., skin guard for body grooming). Trim against the direction of hair growth for a closer cut, but be mindful of skin sensitivity.

If the problem persists, please contact Braun customer support or refer to the official Braun website for further assistance.

8. Specifications

Feature	Specification
Brand	Braun
Model Number	MGK5565
Power Source	Battery (Rechargeable)
Battery Type	Lithium-ion
Charging Time	Approx. 1.5 hours
Run Time	Up to 120 minutes
Wattage	4 W
Waterproof	100% Waterproof (Aqua Grip)
Recommended Uses	Face, Body

Feature	Specification
Target User	Men
Package Weight	0.52 kg
Package Dimensions	25.1 x 16.3 x 6.4 cm

9. Warranty and Support

Braun products are manufactured to meet high quality standards. In the unlikely event of a defect, this appliance is covered by a manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Braun website for detailed warranty terms and conditions specific to your region.

For customer support, spare parts, or additional information, please visit the official Braun website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2HH7CSS

More documents and user manuals: **https://manuals.plus/**