Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yalissey YS251201

Yalissey 7-Piece Metal Patio Furniture Set Instruction Manual

Model: YS251201

Introduction

Thank you for choosing the Yalissey 7-Piece Metal Patio Furniture Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture. Please read these instructions carefully before assembly and retain them for future reference.

Safety Information

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the furniture on a soft, clean surface to prevent scratches.
- Tighten all bolts and screws securely, but do not overtighten. Periodically check and retighten fasteners.
- Do not stand or jump on the furniture.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Place furniture on a level surface to prevent tipping.
- Maximum weight capacity per seat is 350 lbs (158 kg).

Package Contents

Your Yalissey 7-Piece Metal Patio Furniture Set includes the following components:

- 1 x Three-seater Sofa
- 2 x Swivel Rocking Chairs
- 2 x Ottomans
- 1 x Coffee Table
- 1 x Side Table

- Associated cushions for all seating pieces
- Assembly hardware (bolts, washers, Allen wrench)

Please verify all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

Assembly Instructions

Assembly is required for this furniture set. It is recommended that two adults assemble the furniture. Approximate assembly time: 1-2 hours.

General Assembly Tips:

- Lay out all components on a soft, non-abrasive surface.
- Do not fully tighten any bolts until all parts are loosely assembled.
- Refer to the included hardware pack for specific bolt and washer sizes.

Step-by-Step Assembly:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Identify each part against the package contents list.
2. **Assemble Sofa Frame:** Attach the backrest to the seat frame, then attach the armrests. Secure with bolts and washers.
3. **Assemble Swivel Chair Frames:** For each swivel chair, attach the backrest to the seat frame. Then, attach the chair base to the seat frame, ensuring the swivel mechanism is correctly aligned. Secure with bolts.
4. **Assemble Ottomans:** Attach the legs to the ottoman frame.
5. **Assemble Coffee Table:** Attach the legs to the tabletop and then attach the lower shelf. Secure with bolts.
6. **Assemble Side Table:** Attach the legs to the tabletop. Secure with bolts.
7. **Final Tightening:** Once all pieces are assembled, go back and fully tighten all bolts and screws on all furniture pieces.
8. **Place Cushions:** Position the seat and back cushions on the sofa, chairs, and ottomans. Ensure cushions are secured using any integrated non-slip anchoring systems or Velcro straps.



Image: This image displays the dimensions of each component of the Yalissey 7-Piece Patio Furniture Set, including the sofa, swivel chair, ottoman, coffee table, and side table. Dimensions are provided in inches.

Operating Instructions

Swivel Rocking Chairs:

The swivel rocking chairs are designed for smooth 360° rotation and a gentle 20° rocking motion. To operate, simply sit comfortably and gently push off with your feet to initiate rocking or rotate the chair to your desired direction. Ensure the chair is on a level surface for optimal performance and safety.



Image: This image highlights the features of the swivel rocking chair, including the ergonomic armrest and heavy-duty swivel base, demonstrating its 360-degree rotation and rocking capability.

Cushion Placement:

Place the seat and back cushions on their respective furniture pieces. The cushions feature a non-slip anchoring system and anti-slip Velcro straps to keep them securely in place during use. Ensure these are properly engaged to prevent cushions from sliding.

Maintenance and Care

Proper care will extend the life and appearance of your Yalissey patio furniture set.

- **Frame Care:** The rust-proof powder-coated steel frame and hand-woven wicker are designed for outdoor use. Clean the frame with a mild soap and water solution and a soft cloth. Rinse thoroughly and dry completely to prevent water spots. Avoid harsh chemicals or abrasive cleaners.
- **Cushion Care:** The cushions are made with 250g yarn-dyed fabric, which is UV-blocking and weather-resistant. The covers are removable for cleaning. Spot clean minor spills with a damp cloth and mild soap. For deeper

cleaning, remove covers and hand wash or machine wash on a gentle cycle with cold water. Air dry only; do not tumble dry. Ensure cushions are completely dry before storing or replacing to prevent mildew.

- **Weather Protection:** While designed for all-weather use, covering the furniture during prolonged periods of harsh weather (heavy rain, snow, intense sun) or when not in use will further protect it and extend its lifespan. Store cushions indoors during inclement weather.
- **Fastener Check:** Periodically check all bolts and screws to ensure they remain tight. Retighten as necessary to maintain stability and safety.



Image: This image illustrates the "Triple Protection Tubing Technology" used in the furniture frame, detailing the durable spray paint process, high-performance primer, and enhanced bottom layer for weather resistance.



Image: This image highlights the comfortable seating features, including 25D high rebound sponge and removable, waterproof 230g Aolifen fabric for the cushions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Furniture is wobbly.	Loose fasteners or uneven surface.	Ensure all bolts are tightened. Move furniture to a level surface.
Cushions slide off.	Non-slip anchors or Velcro straps not engaged.	Ensure all non-slip features are properly attached to the furniture frame.
Swivel chair does not rotate smoothly.	Obstruction in the swivel mechanism or uneven placement.	Check for debris under the base. Ensure the chair is on a flat, level surface.

Problem	Possible Cause	Solution
Minor scratches on frame.	Normal wear and tear or accidental damage.	Touch-up paint can be used for minor scratches. Consult customer support for recommendations.

Specifications

Feature	Detail
Model Number	YS251201-BG
Set Name	7 Pieces Metal Patio Furniture Set
Brand	Yalissey
Color	Beige
Material Type	Metal (Frame), Hand-woven Wicker, 250g Yarn-Dyed Fabric (Cushions)
Assembly Required	Yes
Style	Modern
Unit Count	7.0 Count
Maximum Weight Capacity (per seat)	350 lbs

Warranty and Support

For warranty information or assistance with your Yalissey 7-Piece Metal Patio Furniture Set, please contact Yalissey customer support. Details regarding warranty coverage and how to file a claim are typically provided with your purchase documentation or can be found on the official Yalissey website.
When contacting support, please have your model number (YS251201) and proof of purchase readily available.

© 2024 Yalissey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F3J2XJ45

More documents and user manuals: **https://manuals.plus/**